

2014 ELECTRICAL

Wiring Systems and Power Management - Component Locator - Door Component Views - Acadia, Enclave And Traverse

DOOR COMPONENT VIEWS

LEFT REAR DOOR




Fig. 1: Locating Left Rear Door Components
Courtesy of GENERAL MOTORS COMPANY

Items

- 1: A23LR Door Latch Assembly - Left Rear A23LR Door Latch Assembly - Left Rear (A45 or AXE)
2: S79LR Window Switch - Left Rear S79LR Window Switch - Left Rear
3: P19AL Speaker - Left Rear Door P19AL Speaker - Left Rear Door (UQA or UQS with W49)
P19AL Speaker - Left Rear Door (UOA or UOS without W49) P19AL Speaker - Left Rear Door

(UQF)

4: M74LR Window Motor - Left Rear **M74LR Window Motor - Left Rear**

5: B63LR Side Impact Sensor - Left Rear **B63LR Side Impact Sensor - Left Rear**

RIGHT REAR DOOR




Fig. 2: Locating Right Rear Door Components

Courtesy of GENERAL MOTORS COMPANY

Items

1: A23RR Door Latch Assembly - Right Rear **A23RR Door Latch Assembly - Right Rear (A45 or AXE)**

2: S79RR Window Switch - Right Rear **S79RR Window Switch - Right Rear**

3: P19AM Speaker - Right Rear Door **P19AM Speaker - Right Rear Door (UQA or UQS with W49)**
P19AM Speaker - Right Rear Door (UQA or UQS without W49) **P19AM Speaker - Right Rear Door (UQF)**

4: B63RR Side Impact Sensor - Right Rear **B63RR Side Impact Sensor - Right Rear**

5: M74RR Window Motor - Right Rear **M74RR Window Motor - Right Rear**

DRIVER DOOR SWITCHES (WITHOUT AXE)




Fig. 3: Driver Door Switches (without AXE)
Courtesy of GENERAL MOTORS COMPANY

Items

- 1: S13D Door Lock Switch - Driver ((without AXE)) **S13D Door Lock Switch - Driver (without AXE)**
2: S79D Window Switch - Driver ((without AXE)) **S79D Window Switch - Driver X1 (without AXE)**
S79D Window Switch - Driver X2 (without AXE)
3: S52 Outside Rearview Mirror Switch ((without AXE)) **S52 Outside Rearview Mirror Switch (without AXE)**

DRIVER DOOR

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Door Component Views - Acadia, Enclave And Traverse




Fig. 4: Identifying Driver Door Components
Courtesy of GENERAL MOTORS COMPANY

Items

- 1: A9A Outside Rearview Mirror - Driver A9A Outside Rearview Mirror - Driver (DL6 or DS3 or DM8) A9A Outside Rearview Mirror - Driver X1 (DNP) A9A Outside Rearview Mirror - Driver X2 (DNP)
- 2: S47D Seat Memory Switch - Driver ((A45)) S47D Seat Memory Switch - Driver (A45)
- 3: S79D Window Switch - Driver ((without AXE)) S79D Window Switch - Driver X1 (without AXE) S79D Window Switch - Driver X2 (without AXE)
- 4: P19AG Speaker - Left Front Door P19AG Speaker - Left Front Door (UQA or UQS) P19AG Speaker - Left Front Door (UQF)
- 5: B63LF Side Impact Sensor - Left Front B63LF Side Impact Sensor - Left Front
- 6: A23D Door Latch Assembly - Driver A23D Door Latch Assembly - Driver
- 7: M74D Window Motor - Driver M74D Window Motor - Driver (AXE) M74D Window Motor - Driver (without AXE)
- 8: E2LF Side Marker Lamp - Left Front ((X88 or Z88)) E2LF Side Marker Lamp - Left Front (W49)

E2LF Side Marker Lamp - Left Front (X88 or Z88)

PASSENGER DOOR




Fig. 5: Identifying Passenger Door Components
Courtesy of GENERAL MOTORS COMPANY

Items
1: A9B Outside Rearview Mirror - Passenger <u>A9B Outside Rearview Mirror - Passenger (DL6 or DS3 or DM8)</u> <u>A9B Outside Rearview Mirror - Passenger X1 (DNP)</u> <u>A9B Outside Rearview Mirror - Passenger X2 (DNP)</u>
2: E2LF Side Marker Lamp - Left Front ((X88 or Z88)) <u>E2LF Side Marker Lamp - Left Front (W49)</u> <u>E2LF Side Marker Lamp - Left Front (X88 or Z88)</u>
3: M74P Window Motor - Passenger <u>M74P Window Motor - Passenger (AXE)</u> <u>M74P Window Motor - Passenger (without AXE)</u>
4: A23P Door Latch Assembly - Passenger <u>A23P Door Latch Assembly - Passenger</u>
5: B63RF Side Impact Sensor - Right Front <u>B63RF Side Impact Sensor - Right Front</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Door Component Views - Acadia, Enclave And Traverse

6: P19AH Speaker - Right Front Door **P19AH Speaker - Right Front Door (UQA or UQS) P19AH Speaker - Right Front Door (UQF)**

7: S79P Window Switch - Passenger ((without AXE)) **S79P Window Switch - Passenger (without AXE)**