



2010 Audi A5 • S5

Quick Reference Guide




Fuel
(see label)



Fuel filler flap

Opening: Press the left side of the fuel filler flap.

Closing: Press the fuel filler flap in until it latches.



Tire pressures


(driver's side B-pillar)

Visible when the door is open or inside the fuel filler flap.



Engine oil

The engine oil specification is in the "Checking and filling" chapter and the engine oil capacity is in the "Data" chapter.



Dear driver,

This Quick Reference Guide provides you with a brief overview of selected procedures and functions in your vehicle. It does not replace the Owner's Manual with its important explanations and warnings.

The Owner's Manual provides detailed information about your vehicle. You can find everything you need to know about the radio, CD player, navigation system, TV, and telephone in the Infotainment/MMI Owner's Manual or Radio System Owner's Manual.

We hope you enjoy driving your new Audi and we wish you safe and pleasant motoring.

Sincerely, AUDI AG

Welcome

Cockpit

- ❶ Hood release
- ❷ Release button for luggage compartment
- ❸ Adjusting the exterior mirrors

Adjust the knob:

-  Left exterior mirror
-  Heating the exterior mirror
-  Right exterior mirror
-  Folding the exterior mirror

The mirror glass moves in the direction that the knob is pressed.

❹ Power windows

Setting the desired position:

Press/pull as far as the first level and hold.

Automatic up/down function:


Briefly press/pull as far as the second level.


WARNING

Be careful when closing the windows. Check to see that no one is in the way, or serious personal injury could result.

❺ Door handle and central locking switch

-  locked
-  unlocked





- ⑥ Memory seat buttons
- ⑦ Side assist warning display
- ⑧ Button for side assist
- ⑨ Light switch
- ⑩ Data Link Connector for On Board Diagnostics (OBD II)
- ⑪ Cruise control or Adaptive Cruise Control
- ⑫ Turn signal and high beam lever
- ⑬ Multifunction steering wheel controls
- ⑭ Instruments and indicator lights
- ⑮ Windshield wiper controls and trip computer buttons
- ⑯ Ignition lock
- ⑰ Sound system/MMI display

⑱ Button and indicator light for:

-  Emergency flashers
-  Passenger airbag deactivated

⑲ Sound system

⑳ Audi drive select buttons:

You can select from the following settings:

COMFORT

Choose this setting when you want a more comfortable driving style (for example, when driving long distances on the expressway)

AUTO

Choose this setting for everyday driving.

DYNAMIC

Choose this setting when you want a more sporty driving style.

㉑ Buttons for:

-  Sun shade
-  Electronic stabilization program

On vehicles equipped with a sound system, buttons ㉒ and ㉓ are located on the shift gate.

㉒ Climate control system

㉓ Selector lever with automatic transmission or shift lever

㉔ Electromechanical parking brake

㉕ START ENGINE STOP button

㉖ MMI terminal

㉗ Steering wheel position adjuster

⚠ WARNING

The column should only be adjusted when the vehicle is at a complete standstill.

Opening and closing the vehicle

With convenience key, you can lock and unlock your vehicle without using the remote control key. You only need to carry the remote control key with you.

Unlocking the vehicle:

Grasp one of the door handles or the handle recess on the luggage compartment lid.

Locking the vehicle:

Place the selector lever in the **P** position. Press the lock button **1** on one of the door handles.

Opening the rear lid:

Press the  button on the remote control key or pull the  release button inside of the driver's door.



⚠ WARNING

When you lock your vehicle from the outside, do not leave anyone - especially children - inside the vehicle. Remember, when you lock the vehicle from the outside the windows cannot be opened from the inside.

⚠ WARNING

Always ensure that no one is within range of the rear lid when it is moving, in particular close to the hinges - fingers or hands can be pinched.

⚠ WARNING

When you leave the vehicle, always remove the ignition key and take it with you. This will prevent passengers (children, for example) from accidentally being locked in the vehicle should they accidentally press the power locking switch in the front doors.

Starting the engine

Convenience key:

You can switch on the ignition and start/stop the engine using the START ENGINE STOP button without having the key inserted in the ignition lock.

Switching the ignition on and off:

Insert the key into the ignition lock.

Manual transmission: Do **not** depress the clutch. Press on the key.

Automatic transmission: Do **not** depress the brake pedal. Press on the key.

The key can only be removed when the ignition is switched off.

Starting the engine:

Insert the key into the ignition lock.

Manual transmission: Depress the clutch and engage Neutral.

Automatic transmission: Depress the brake pedal and move the selector lever into **P** or **N**.

Briefly press on the key.

Stopping the engine when the vehicle is standing:

Automatic transmission: Move the selector lever into **P** or **N**. Briefly press on the key.



Adjusting the seats

① Upper thigh support

② Adjusting the lumbar support:

Press on the respective area of the switch.

③ Adjusting seat height and forward/back position

- Front of the seat cushion up/down
- Back of the seat cushion up/down
- Seat up/down
- Seat forward/back

④ Adjusting backrest/headrest:

- Backrest forward/back
- Head restraint up/down

⑤ Entry assistance:

Pull the lever up and tilt the backrest forward or back.



Adjusting the headrests:

The top edge of the headrest should be at eye level or higher.



⚠ WARNING

Thoroughly review your Owner's Manual for warnings and other important information about proper restraint use and what you can do to reduce the risk of injury in accidents. Failure to properly use restraint systems can cause serious personal injury.

⚠ WARNING

Never install rear facing child seats or infant carriers on the passenger seat. A child will be seriously injured or killed when the passenger airbag inflates.

⚠ WARNING

Always fasten safety belts before driving off. Always make sure passengers are properly restrained. Children 12 years old and younger must ride in the rear seat and be properly restrained as indicated in the Owner's Manual. The airbag is supplemental and does not replace safety belt use.

⚠ WARNING

Front seat passengers must never ride in a moving vehicle with the seatback reclined. The risk of personal injury increases with increasing rearward angle of the seatback. Safety belts only offer protection when the seatback is upright and belts are properly positioned on the body. Adjust your seats only when the vehicle is at a complete standstill.

⚠ WARNING

The airbag system cannot protect you properly if you are seated too close to any of the airbag locations. When adjusting their seat positions, it is important that both the driver and front passenger keep their upper bodies at a minimum safe distance of 10 inches (25 cm) between the chest and the steering wheel/instrument panel.



Climate control switch

Left switch – driver's side

Right switch – passenger's side


Rotary switch: Temperature selection

-  **Automatic mode**
Set the desired temperature and press the button.
-  **Recirculation mode**
Circulate and filter the air inside the passenger compartment
-  **Fan speed**
-  **Air distribution**
-  **Defrost the windshield/side windows**
-  **Rear window defroster**
-  **Heated seats**
-  **Switch the air conditioning system on/off**
-  **Switching on/off**

Panoramic tilting sunroof

Opening/closing

Press/pull the switch in the direction of the arrow. Press/pull the switch again when the desired position is reached.



WARNING

Be careful when closing the panoramic tilting sunroof. Check to see that no one is in the way, or serious personal injury could result.

Cruise control system

The **CRUISE/**  indicator light appears in the instrument cluster when the system is switched on.

Switching on/off: Pull/press the lever **2**.

Storing the speed: Press the button **1**.

Changing the stored speed: Press the lever up (*faster*) or down (*slower*).



Electromechanical parking brake

Engaging the parking brake:
Stop the vehicle and pull the  button.

Releasing the parking brake:
Press the brake pedal while pressing the  button.

WARNING

Improper use of the cruise control system can cause collisions, other accidents and serious personal injury. Always read and heed the Warnings in the Owner's Manual.

Multi Media Interface

MMI components

① Driver information system

② Multifunction steering wheel

Roll the **left menu thumbwheel** to mark a menu item in the driver information system. Press the thumbwheel to confirm the menu item.

Press the **MODE button** to switch between the active radio source, navigation system, and telephone.

Press the  button briefly to switch voice commands on.

For example, after the *<Beep>*, say *<Help>* to call up the system announcement with the possible speech commands. Hold the Talk button down to switch voice commands off.

Roll the **right menu thumbwheel** to control the volume. Press the right thumbwheel to repeat the last navigation announcement.





3 Sound system/MMI display

4 On/Off knob

Switching on: Press briefly.

Adjusting the volume: Rotate.

Muting: Tap.

Switching off: Press and hold.

5 Function buttons

Press the desired button (such as MEDIA) to activate that mode.

6 Control knob

Marking a menu item in the display 3: Rotate the control knob.

Confirming the selection: Press the control knob.

7 Control buttons

To call up one of the functions shown in the four corners of the display, press the corresponding control button that is assigned to that corner of the display.

8 Joystick

To move the crosshairs in a map view (*navigation*) or to control the DVD menu.


⚠ WARNING

Distraction causes accidents:

- Never enter data while driving!
- Obey traffic laws & road signs!
- Refer to the Owner's Manual!

Operating concept

All functions are controlled using the same operating concept.



A Calling up menus in the display corners: Press the corresponding button.

B Marking: Rotate the knob.

C Confirming: Press the knob.

Storing a radio station



- 1** Press the RADIO function button.



- 2** Rotate the control knob and mark the desired station.



- 3** Press the control knob to confirm.



- 4** Press the "Presets" control button.
5 Rotate the control knob and mark "Store <station name>".



- 6** Press the control knob. The next free memory preset is marked.



- 7** Rotate the control knob and mark the desired preset.
8 Press the control knob to confirm.



- 1 Press the NAV function button.



- 2 Rotate the control knob and mark "City/ZIP".
- 3 Press the control knob to confirm.



- 4 Rotate the control knob to mark the first letter of the destination.
- 5 Press the control knob to confirm.



- 6 Continue entering the remaining letters of the destination name using the same procedure until the desired location name is displayed.




- 7 Press and hold the control knob longer when the city appears in the list.
- 8 Rotate and press to select the city and enter detailed destination information if necessary.



- 9 Mark the menu item "Start route guidance".
- 10 Press the control knob to confirm. The route is calculated.

Driver assistance systems



Use the CAR button to adjust or operate many driver assistance systems in your Audi.

For detailed information on this, please see your vehicle Owner's Manual.

Establishing a Bluetooth™ cell phone connection

You can quickly connect your Bluetooth-compatible cell phone with the MMI or radio system.

Connecting to the MMI:

- Switch the ignition, MMI and cell phone on.
- Activate "Bluetooth" and "Access to SIM card" on the cell phone.
- Press the TEL function button.
- Mark the menu item "Search for new cell phones".
- Press the SETUP function button.
- Press the "Bluetooth" control button.
- Highlight the menu item "Search for Bluetooth devices" and confirm.
- Mark and confirm your cell phone in the display.
- Mark "Handsfree" and confirm.
- Confirm the PIN number with "Yes".
- Enter the PIN number on the cell phone.
- Also confirm the system prompt on the cell phone if necessary.

Connecting with the radio system:

- Switch the ignition, radio system and cell phone on.
- Select the menu in the cell phone that searches for Bluetooth-compatible devices (such as the cell phone prep or handsfree system).
- Connect the cell phone with the cell phone prep.
- Enter the PIN number on the cell phone.



Indicator lights

	Dynamic steering
EPC	Electronic power control ¹⁾
	Electronic Stabilization Program (ESP)
AIR BAG	Airbag system (USA) ¹⁾
	Airbag system (CAN) ¹⁾
	Tire pressure low (check immediately)
	Turn signals/ Emergency flasher
	Safety belt

	Malfunction Indicator Lamp ¹⁾
	High beam
CRUISE	Cruise control activated (USA)
	Cruise control activated (CAN)
ABS	Anti-lock brake system (USA) ¹⁾
	Anti-lock brake system (CAN) ¹⁾
PARK BRAKE	Parking brake (USA)
	Parking brake (CAN)

¹⁾ If this illuminates while driving, contact your authorized Audi dealer immediately.

Warning symbols

	Alternator malfunction
BRAKE	Brake malfunction (USA)
	Brake malfunction (CAN)
	Cooling system malfunction
	Engine oil pressure too low
	Refill engine oil now
	Steering defective
	Ignition switch defective

If one of these red symbols appears in the display while driving, pull over immediately, stop the engine, and check the Owner's Manual.

2009 AUDI AG

Audi is constantly improving their products. Modifications in form, equipment, and technology are possible. No legal commitment is implied by the information, illustrations, and descriptions in this Quick Reference Guide. Reprinting, reproduction or translation, in whole or in part, is not permitted without written permission from Audi of America, Inc. Reprinting, reproduction or translation, in whole or in part, is not permitted without written permission from Audi of America, Inc. Subject to modification without notice. Concept and design: Pfriemer GmbH. Printed in Germany.

www.audi.com

**Audi A5 • S5
Kurzanleitung
Nordamerika
englisch 5.09
101.562.834.21**