

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

2014 ELECTRICAL

Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

MASTER ELECTRICAL COMPONENT LIST**Master Electrical Component List**

Code	Name	Option	Location	Locator View	Connector End View
A1	Mirror Dimming	DNP	Located inside the Outside Rearview Mirror Assembly - Driver	-	-
A3L	Sunshade - Left	-	In the passenger compartment, on the left sunshade	<u>Headliner Components</u>	<u>A3L Sunshade - Left</u>
A3R	Sunshade - Right	-	In the passenger compartment, on the right sunshade	<u>Headliner Components</u>	<u>A3R Sunshade - Right</u>
A7	Fuel Pump and Level Sensor Assembly	-	Under left center of vehicle, mounted on top of the fuel tank	<u>Fuel Tank Components</u>	<u>A7 Fuel Pump and Level Sensor Assembly</u>
A9A	Outside Rearview Mirror - Driver	-	On the outside of the driver door	<u>Driver Door</u>	• <u>A9A Outside Rearview Mirror - Driver (DL6 or DS3 or DM8)</u> • <u>A9A Outside Rearview Mirror - Driver X1 (DNP)</u> • <u>A9A Outside Rearview Mirror - Driver X2 (DNP)</u>
					• <u>A9B Outside Rearview Mirror - Passenger (DL6 or</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

A9B	Outside Rearview Mirror - Passenger	-	On the outside of the passenger door	<u>Passenger Door</u>	<u>DS3 or DM8)</u> • <u>A9B Outside Rearview Mirror - Passenger X1 (DNP)</u> • <u>A9B Outside Rearview Mirror - Passenger X2 (DNP)</u>
A10	Inside Rearview Mirror	-	In the passenger compartment, top center of the windshield	<u>Headliner Components</u>	<u>A10 Inside Rearview Mirror</u>
A11	Radio	-	In the passenger compartment, in the center of the instrument panel	<u>Instrument Panel Components</u>	• <u>A11 Radio X1</u> • <u>A11 Radio X2</u> • <u>A11 Radio X3 (U42)</u> • <u>A11 Radio X4</u>
A12	Digital Radio Receiver Control Module	(U2K or UBS)	In the passenger compartment, behind the left rear interior body panel	<u>Left Rear of the Passenger Compartment</u>	<u>A12 Digital Radio Receiver Control Module (U2K or UBS)</u>
A13	Rear Audio Control Module	-	In the passenger compartment, on the right rear interior body panel	<u>Right Rear Trim Panel</u>	<u>A13 Rear Audio Control Module (RCA)</u>
A21	Radio/HVAC Controls - Auxiliary	-	In the passenger compartment, at the rear of the floor console	<u>Console Components</u>	• <u>A21 Radio/HVAC Control - Auxiliary X2 (ULD)</u> • <u>A21 Radio/HVAC Control - Auxiliary X1 (ULD)</u>
A23C	Liftgate Latch Assembly	-	Inside bottom center of liftgate	<u>Liftgate Components</u>	• <u>A23C Liftgate Latch Assembly (TB4)</u> • <u>A23C Liftgate Latch Assembly (TB5)</u>
A23D	Door Latch Assembly - Driver	-	In the rear center of the	<u>Driver Door</u>	<u>A23D Door Latch Assembly - Driver</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			left front door		
A23LR	Door Latch Assembly - Left Rear	-	In the rear center of the left rear door	<u>Left Rear Door</u>	<u>A23LR Door Latch Assembly - Left Rear (A45 or AXE)</u>
A23P	Door Latch Assembly - Passenger	-	In the rear center of the right front door	<u>Passenger Door</u>	<u>A23P Door Latch Assembly - Passenger</u>
A23RR	Door Latch Assembly - Right Rear	-	In the rear center of the right rear door	<u>Right Rear Door</u>	<u>A23RR Door Latch Assembly - Right Rear (A45 or AXE)</u>
A91	Mirror Display	UVC	In the passenger compartment, located inside the Inside Rearview Mirror	-	-
B1	A/C Refrigerant Pressure Sensor	-	In the engine compartment, right front, on the high pressure refrigerant line	<u>Engine Components - Front Left</u>	<u>B1 A/C Refrigerant Pressure Sensor</u>
B5LF	Wheel Speed Sensor - Left Front	-	Under the vehicle, attached to the left front steering knuckle	<u>Front Suspension</u>	<u>B5LF Wheel Speed Sensor - Left Front</u>
B5LR	Wheel Speed Sensor - Left Rear	-	Under the vehicle, part of the left rear hub assembly	<u>Left Rear Suspension</u>	<u>B5LR Wheel Speed Sensor - Left Rear</u>
B5RF	Wheel Speed Sensor - Right Front	-	Under the vehicle, attached to the right front steering knuckle	<u>Front Suspension</u>	<u>B5RF Wheel Speed Sensor - Right Front</u>
B5RR	Wheel Speed Sensor - Right Rear	-	Under the vehicle, part of the right rear hub assembly	<u>Left Rear Suspension</u>	<u>B5RR Wheel Speed Sensor - Right Rear</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

B7A	Inside Air Temperature Sensor	(CJ2)	In the passenger compartment, on the HVAC duct, next to the left side of the instrument panel cluster	<u>Near the Steering Column</u>	<u>B7A Inside Air Temperature Sensor (CJ2)</u>
B7D	Air Temperature Sensor - Duct Left Lower	(CJ2)	In the passenger compartment, behind the center of the instrument panel, on the lower left side of the front HVAC module	<u>Interior HVAC Module - Front (CJ2)</u>	<u>B7D Air Temperature Sensor - Duct Left Lower (CJ2)</u>
B7E	Air Temperature Sensor - Duct Right Lower	(CJ2)	In the passenger compartment, behind the center of the instrument panel, on the lower right side of the front HVAC module	<u>Interior HVAC Module - Front (CJ2)</u>	<u>B7E Air Temperature Sensor - Duct Right Lower (CJ2)</u>
B7H	Air Temperature Sensor - Duct Left Upper	(CJ2)	In the passenger compartment, behind the center of the instrument panel, on the bottom of the left upper A/C duct, above the accelerator pedal	<u>Interior HVAC Module - Front (CJ2)</u>	<u>B7H Air Temperature Sensor - Duct Left Upper (CJ2)</u>
			In the passenger compartment, behind the		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

B7J	Air Temperature Sensor - Duct Right Upper	(CJ2)	center of the instrument panel, on the bottom of the right upper A/C duct, to right of the mode actuator	<u>Interior HVAC Module - Front (CJ2)</u>	<u>B7J Air Temperature Sensor - Duct Right Upper (CJ2)</u>
B9	Ambient Air Temperature Sensor	(CJ2)	Behind the front bumper fascia, at the left radiator support	• <u>Front of Vehicle - Buick</u> • <u>Front of Vehicle - Chevrolet</u> • <u>Front of Vehicle - GMC</u>	<u>B9 Ambient Air Temperature Sensor</u>
B10	Ambient Light Sensor	(C67)	In the passenger compartment, on the center of the instrument panel upper trim panel	<u>Instrument Panel Components</u>	<u>B10 Ambient Light Sensor (C67)</u>
B12A	Transmission Fluid Pressure Switch	-	In the engine compartment, in the automatic transmission	-	-
B13	Transmission Fluid Temperature Sensor	-	In the engine compartment, in the automatic transmission	-	-
B14A	Transmission Output Shaft Speed Sensor	-	In the engine compartment, in the automatic transmission	<u>Automatic Transmission Electronic Components</u>	-
B14C	Transmission Input Shaft Speed Sensor	-	In the engine compartment, in the automatic transmission	<u>Automatic Transmission Electronic Components</u>	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

B15	Transmission Internal Mode Switch	-	In the engine compartment, in the automatic transmission, at the shift select shaft	<u>Automatic Transmission Electronic Components</u>	-
B18	Battery Current Sensor	-	In the passenger compartment, right second seat floor, on the battery positive cable, near the battery	• <u>Second Row Seat Area Floor</u> • <u>Near the Passenger Seat</u>	<u>B18 Battery Current Sensor</u>
B19B	Brake Booster Vacuum Sensor	-	In left rear of engine compartment, on the bottom of vacuum brake booster	<u>Engine Components - Front Left</u>	<u>B19B Brake Booster Vacuum Sensor</u>
B20	Brake Fluid Level Switch	-	At the left rear of the engine compartment, in the master cylinder fluid reservoir	-	<u>B20 Brake Fluid Level Switch</u>
B22	Brake Pedal Position Sensor	-	In the passenger compartment, under left side of the instrument panel, above the brake pedal assembly	<u>Below the Driver Side of the Instrument Panel</u>	<u>B22 Brake Pedal Position Sensor</u>
B23A	Camshaft Position Sensor - Bank 1 Exhaust	-	In the engine compartment, on the right side of the rear cylinder head, lower rear position	<u>Engine Components - Right Rear</u>	<u>B23A Camshaft Position Sensor - Bank 1 Exhaust</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

B23B	Camshaft Position Sensor - Bank 1 Intake	-	In the engine compartment, on the right side of the rear cylinder head, upper front position	<u>Engine Components - Right Rear</u>	<u>B23B Camshaft Position Sensor - Bank 1 Intake</u>
B23C	Camshaft Position Sensor - Bank 2 Exhaust	-	In the engine compartment, on the right side of the front cylinder head, lower front position	-	<u>B23C Camshaft Position Sensor - Bank 2 Exhaust</u>
B23D	Camshaft Position Sensor - Bank 2 Intake	-	In the engine compartment, on the right side of the front cylinder head, upper rear position	-	<u>B23D Camshaft Position Sensor - Bank 2 Intake</u>
B24	Cellular Phone Microphone	(UE1)	In the passenger compartment, near the inside rearview mirror, in the front overhead console	<u>Headliner Components</u>	<u>B24 Cellular Phone Microphone (UE1)</u>
B26	Crankshaft Position Sensor	-	Left side of engine compartment, lower rear of engine block, above the transmission	<u>Engine Components - Right Rear</u>	<u>B26 Crankshaft Position Sensor</u>
B34	Engine Coolant Temperature Sensor	-	In the engine compartment, in the front cylinder head, between cylinders 2 and 4	• <u>Engine Components - Front</u> • <u>Engine Components - Front Left</u>	<u>B34 Engine Coolant Temperature Sensor</u>
	Engine Oil Level		In the engine		<u>B35 Engine Oil Level</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

B35	Switch	-	compartment, on the oil pan	-	<u>Switch</u>
B37	Engine Oil Pressure Switch	-	In the engine compartment, right front of the engine, on the oil filter adapter	<u>Engine Components - Front</u>	<u>B37 Engine Oil Pressure Switch</u>
B39	Evaporator Temperature Sensor	-	In the passenger compartment, in the HVAC module, mounted to the evaporator core, behind right center of the instrument panel, below the air temperature actuator	• <u>Interior HVAC Module - Front (CJ2)</u> • <u>Front HVAC Module (C67)</u>	<u>B39 A/C Evaporator Temperature Sensor</u>
B47	Fuel Pressure Sensor	-	Mounted under the left center of the vehicle, on the fuel line, forward of the fuel tank	-	<u>B47 Fuel Pressure Sensor</u>
B47B	Fuel Rail Pressure Sensor	-	Right side of the engine, under the intake plenum, on the fuel rail, near fuel injectors 1 and 2	<u>Engine Components - Top</u>	<u>B47B Fuel Rail Pressure Sensor</u>
B52C	Heated Oxygen Sensor - Bank 1 Sensor 1	-	In the engine compartment, on the rear exhaust manifold, above the catalytic converter	<u>Engine Components - Right Rear</u>	<u>B52C Heated Oxygen Sensor - Bank 1 Sensor 1</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

B52D	Heated Oxygen Sensor - Bank 1 Sensor 2	-	Under the vehicle, in the rear exhaust pipe, after the catalytic converter	-	<u>B52D Heated Oxygen Sensor - Bank 1 Sensor 2</u>
B52E	Heated Oxygen Sensor - Bank 2 Sensor 1	-	In engine compartment, on the front exhaust manifold, above the catalytic converter	<u>Engine Components - Front</u>	<u>B52E Heated Oxygen Sensor - Bank 2 Sensor 1</u>
B52F	Heated Oxygen Sensor - Bank 2 Sensor 2	-	Under the vehicle, in the front exhaust pipe, after the catalytic converter	-	<u>B52F Heated Oxygen Sensor - Bank 2 Sensor 2</u>
B55	Hood Ajar Switch	(BTV)	Behind the front fascia, upper center of the radiator support, on the hood latch	<u>Front of Engine Compartment - Components</u>	<u>B55 Hood Ajar Switch (BTV)</u>
B57	Ignition Cylinder Lock Control Switch	-	In the passenger compartment, part of the automatic transmission shift lever	<u>Automatic Transmission Floor Shifter</u>	-
B59L	Front Impact Sensor - Left	-	Behind the front fascia, at upper left front of radiator support	<u>Front of Engine Compartment - Components</u>	<u>B59L Front Impact Sensor - Left</u>
B59R	Front Impact Sensor - Right	-	Behind the front fascia, at upper right front of radiator support	<u>Front of Engine Compartment - Components</u>	<u>B59R Front Impact Sensor - Right</u>
B63LF	Side Impact Sensor -	-	In the driver	<u>Driver Door</u>	<u>B63LF Side Impact</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

	Left Front		door		Sensor - Left Front
B63LR	Side Impact Sensor - Left Rear	-	In the left rear door	<u>Left Rear Door</u>	<u>B63LR Side Impact Sensor - Left Rear</u>
B63RF	Side Impact Sensor - Right Front	-	In the passenger door	<u>Passenger Door</u>	<u>B63RF Side Impact Sensor - Right Front</u>
B63RR	Side Impact Sensor - Right Rear	-	In the right rear door	<u>Right Rear Door</u>	<u>B63RR Side Impact Sensor - Right Rear</u>
B68A	Knock Sensor 1	-	In the engine compartment, on the rear middle of the engine block	<u>Engine Components - Right Rear</u>	<u>B68A Knock Sensor 1</u>
B68B	Knock Sensor 2	-	In the engine compartment, on the front middle of the engine block	<u>Engine Components - Front</u>	<u>B68B Knock Sensor 2</u>
B70	Liftgate Close Switch	TB5	In the passenger compartment, behind the left rear interior body panel, inside the Liftgate Motor Assembly	-	-
B71L	Liftgate Object Sensor - Left	(TB5)	Left side of the liftgate opening	<u>Liftgate Components</u>	<u>B71L Liftgate Object Sensor - Left (TB5)</u>
B71R	Liftgate Object Sensor - Right	(TB5)	Right side of the liftgate opening	<u>Liftgate Components</u>	<u>B71R Liftgate Object Sensor - Right (TB5)</u>
B74	Manifold Absolute Pressure Sensor	-	In the engine compartment, on the intake manifold	-	<u>B74 Manifold Absolute Pressure Sensor</u>
B75C	Multifunction Intake Air Sensor	-	Left side of the engine compartment, between the engine and the air cleaner assembly	<u>Engine Components - Front Left</u>	<u>B75C Multifunction Intake Air Sensor</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

B78E	Rear Object Sensor - Left Middle	(UD7)	Outside center rear of the vehicle, left center area of rear bumper fascia	• <u>Rear of the Vehicle (X88)</u> • <u>Rear of the Vehicle (W49)</u> • <u>Rear of the Vehicle (Z88)</u>	<u>B78E Rear Object Sensor - Left Middle (UD7)</u>
B78F	Rear Object Sensor - Right Middle	(UD7)	Outside center rear of the vehicle, right center area of rear bumper fascia	• <u>Rear of the Vehicle (X88)</u> • <u>Rear of the Vehicle (W49)</u> • <u>Rear of the Vehicle (Z88)</u>	<u>B78F Rear Object Sensor - Right Middle (UD7)</u>
B78G	Rear Object Sensor - Left Outer	(UD7)	Outside left rear of the vehicle, left outer edge of rear bumper fascia	• <u>Rear of the Vehicle (X88)</u> • <u>Rear of the Vehicle (W49)</u> • <u>Rear of the Vehicle (Z88)</u>	<u>B78G Rear Object Sensor - Left Outer (UD7)</u>
B78H	Rear Object Sensor - Right Outer	(UD7)	Outside right rear of the vehicle, right outer edge of rear bumper fascia	• <u>Rear of the Vehicle (X88)</u> • <u>Rear of the Vehicle (W49)</u> • <u>Rear of the Vehicle (Z88)</u>	<u>B78H Rear Object Sensor - Right Outer (UD7)</u>
B80	Park Brake Switch	-	In the passenger compartment, lower left A-pillar, part of the park brake assembly	<u>Below the Driver Side of the Instrument Panel</u>	<u>B80 Park Brake Switch</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

B87	Rearview Camera	(UVC)	Outside of the vehicle, on the liftgate, right side of the rear license plate lamp bezel	<u>Rear of the Vehicle (W49)</u>	<u>B87 Rearview Camera (UVC)</u>
B88D	Seat Belt Switch - Driver	-	In the passenger compartment, part of the driver seat belt buckle, attached to the lower right side of the driver seat	-	-
B88P	Seat Belt Switch - Passenger	-	In the passenger compartment, part of the passenger seat belt buckle, attached to the lower left side of the passenger seat	-	-
B89D	Seat Front Vertical Position Sensor - Driver	(A45)	In the passenger compartment, under the driver seat, on rear of front vertical motor	<u>Driver Seat Components (A45)</u>	<u>B89D Seat Front Vertical Position Sensor - Driver (A45)</u>
B90D	Seat Horizontal Position Sensor - Driver	(A45)	In the passenger compartment, under the driver seat on back of horizontal motor	<u>Driver Seat Components (A45)</u>	<u>B90D Seat Horizontal Position Sensor - Driver (A45)</u>
B92D	Seat Rear Vertical Position Sensor -	(A45)	In the passenger compartment, under the	<u>Driver Seat Components</u>	<u>B92D Seat Rear Vertical Position Sensor - Driver</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

	Driver		driver seat on back of vertical motor	(A45)	(A45)
B93D	Seat Recline Position Sensor - Driver	(A45)	In the passenger compartment, in the driver seat back, right side, across from motor	<u>Driver Seat Components (A45)</u>	<u>B93D Seat Recline Position Sensor - Driver (A45)</u>
B94L	Side Object Sensor - Left	(UFT)	At the left corner of the vehicle, under the left rear bumper fascia	-	<u>B92L Side Object Sensor - Left (UFT)</u>
B94R	Side Object Sensor - Right	(UFT)	At the right corner of the vehicle, under the right rear bumper fascia	-	<u>B92R Side Object Sensor - Right (UFT)</u>
B99	Steering Wheel Angle Sensor	-	In the passenger compartment, near the top of the steering column, below the SIR coil	<u>Steering Column Components</u>	<u>B99 Steering Wheel Angle Sensor</u>
B102	Steering Column Tilt Position Sensor	(N38)	In the passenger compartment, near the lower center of the steering column	<u>Steering Column Components</u>	<u>B102 Steering Column Tilt Position Sensor (N38)</u>
B104	Sunload Sensor	(CJ2)	In the passenger compartment, center of the upper instrument panel cover	<u>Instrument Panel Components</u>	<u>B104 Sunload Sensor (CJ2)</u>
			In the passenger compartment,		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

B107	Accelerator Pedal Position Sensor	-	below left side of instrument panel, above the accelerator pedal	<u>Below the Driver Side of the Instrument Panel</u>	<u>B107 Accelerator Pedal Position Sensor</u>
B118B	Windshield Washer Fluid Level Switch	-	In the engine compartment, mounted to the washer solvent reservoir, below the left headlamp assembly	<u>Front of Engine Compartment - Components</u>	<u>B118B Windshield Washer Fluid Level Switch</u>
B119	Multi-axis Acceleration Sensor	-	In the passenger compartment, on the floor below the front floor console	<u>Near the Passenger Seat</u>	<u>B119 Multi-axis Acceleration Sensor</u>
B150	Fuel Tank Pressure Sensor	-	Under the vehicle, mounted on top of the fuel tank	<u>Fuel Tank Components</u>	<u>B150 Fuel Tank Pressure Sensor</u>
B153D	Seat Belt Buckle - Driver	-	In the passenger compartment, attached to the lower right side of the driver seat	<u>Driver Seat Components (A45)</u>	<u>B153D Seat Belt Buckle - Driver</u>
B153P	Seat Belt Buckle - Passenger	-	In the passenger compartment, attached to the lower left side of the passenger seat	<u>Passenger Seat Components</u>	<u>B153P Seat Belt Buckle - Passenger</u>
B268	Liftgate Full Open	(TB5)	Behind the left rear interior body panel,	-	<u>B268 Liftgate Full Open</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

	Switch		mounted to the liftgate actuator assembly		<u>Switch (TB5)</u>
C1	Battery	-	In the passenger compartment, in the floor pan, at right second seat	• <u>Second Row Seat Area Floor</u> • <u>Near the Passenger Seat</u>	-
E1D	Accent Lamp - Driver Door	(W49)	In the passenger compartment, on the left front door, on the trim panel	-	<u>E1D Accent Lamp - Driver Door (W49)</u>
E1G	Accent Lamp - Left Instrument Panel	(Z88 or X88)	In the passenger compartment, behind left side of the instrument panel	-	<u>E1G Accent Lamp - Left Instrument Panel (W49 or X88)</u>
E1H	Accent Lamp - Right Instrument Panel	(W49)	In the passenger compartment, behind right side of the instrument panel	-	<u>E1H Accent Lamp - Right Instrument Panel (W49)</u>
E1LR	Accent Lamp - Left Rear Door	(W49)	In the passenger compartment, on the left rear door, on the trim panel	-	<u>E1LR Accent Lamp - Left Rear Door (W49)</u>
E1P	Accent Lamp - Passenger Door	(W49)	In the passenger compartment, on the right front door, on the trim panel	-	<u>E1P Accent Lamp - Passenger Door (W49)</u>
E1RR	Accent Lamp - Right Rear Door	(W49)	In the passenger compartment, on the left	-	<u>E1RR Accent Lamp - Right Rear Door (W49)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			rear door, on the trim panel		
E1Z	Accent Lamp - Middle Instrument Panel	(Z88 or X88)	In the passenger compartment, behind right side of the instrument panel, left of the instrument panel compartment	-	<u>E1Z Accent Lamp - Middle Instrument Panel (Z88 or X88)</u>
E2LF	Side Marker Lamp - Left Front	(X88 or Z88)	Outside front left side of the vehicle	• <u>Front of Vehicle - Buick</u> • <u>Front of Vehicle - Chevrolet</u> • <u>Front of Vehicle - GMC</u>	<u>E2LF Side Marker Lamp - Left Front (X88 or Z88)</u>
E2LR	Side Marker Lamp - Left Rear	-	Outside left rear of the vehicle	• <u>Rear of the Vehicle (X88)</u> • <u>Rear of the Vehicle (W49)</u> • <u>Rear of the Vehicle (Z88)</u>	• <u>E2LR Side Marker Lamp - Left Rear (W49)</u> • <u>E2LR Side Marker Lamp - Left Rear (X88)</u>
E2RF	Side Marker Lamp - Right Front	(X88 or Z88)	Outside front right side of the vehicle	• <u>Front of Vehicle - Buick</u> • <u>Front of Vehicle - Chevrolet</u> • <u>Front of Vehicle - GMC</u>	<u>E2RF Side Marker Lamp - Right Front (X88 or Z88)</u>
E2RR	Side Marker Lamp -	-	Outside right rear of the	• <u>Rear of the Vehicle (X88)</u> • <u>Rear of the</u>	• <u>E2RR Side Marker Lamp - Right Rear (W49)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

	Right Rear		vehicle	<u>Vehicle (W49)</u> <u>Rear of the Vehicle (Z88)</u>	<u>E2RR Side Marker Lamp - Right Rear (X88)</u>
E4C	Daytime Running Lamp - Left	(T61)	Outside left front of the vehicle	<u>Front of Vehicle - GMC</u>	<u>E4C Daytime Running Lamp - Left (W49 or Z88 with T61)</u>
E4D	Daytime Running Lamp - Right	(T61)	Outside right front of the vehicle	<u>Front of Vehicle - GMC</u>	<u>E4D Daytime Running Lamp - Right (W49 or Z88 with T61)</u>
E4E	Headlamp - Left High Beam	-	Front left side of the vehicle, part of the headlamp assembly	<u>Front of Vehicle - Chevrolet</u>	<u>E4E Headlamp - Left High Beam (X88)</u> <u>E4E Headlamp - Left High Beam (Z88 without TVD)</u>
E4F	Headlamp - Right High Beam	-	Front right side of the vehicle, part of the headlamp assembly	<u>Front of Vehicle - Chevrolet</u>	<u>E4F Headlamp - Right High Beam (X88)</u> <u>E4F Headlamp - Right High Beam (Z88 without TVD)</u>
E4G	Headlamp - Left Low Beam	-	Front left side of the vehicle, part of the headlamp assembly	<u>Front of Vehicle - Buick</u> <u>Front of Vehicle - Chevrolet</u> <u>Front of Vehicle - GMC</u>	<u>E4G Headlamp - Left Low Beam (X88)</u> <u>E4G Headlamp - Left Low Beam (Z88 without TVD)</u>
E4H	Headlamp - Right Low Beam	-	Front right side of the vehicle, part of the headlamp assembly	<u>Front of Vehicle - Buick</u> <u>Front of Vehicle - Chevrolet</u> <u>Front of Vehicle - GMC</u>	<u>E4H Headlamp - Right Low Beam (X88)</u> <u>E4H Headlamp - Right Low Beam (Z88 without TVD)</u>
	Park Lamp - Left		Outside left front of the	<u>Front of Vehicle -</u>	<u>E4J Park Lamp - Left</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

E4J	Front	(W49)	vehicle, part of headlamp assembly	<u>Buick</u>	<u>Front (W49)</u>
E4K	Park Lamp - Right Front	(W49)	Outside right front of the vehicle, part of headlamp assembly	<u>Front of Vehicle - Buick</u>	<u>E4K Park Lamp - Right Front (W49)</u>
E4LF	Turn Signal Lamp - Left Front	(Z88)	Outside front left side of the vehicle	<u>Front of Vehicle - GMC</u>	<u>E4LF Turn Signal Lamp - Left Front (W49 or Z88)</u>
E4RF	Turn Signal Lamp - Left Front	(Z88)	Outside front right side of the vehicle	<u>Front of Vehicle - GMC</u>	<u>E4RF Turn Signal Lamp - Right Front (W49 or Z88)</u>
E4LR	Turn Signal Lamp - Left Rear	X88	Outside left rear of the vehicle, inside Tail Lamp Assembly - Left	-	-
E4N	Park/Turn Signal Lamp - Left	(X88)	Outside left front of the vehicle, on the fascia, below the headlamp assembly	<u>Front of Vehicle - Chevrolet</u>	<u>E4N Park/Turn Signal Lamp - Left (X88)</u>
E4P	Park/Turn Signal Lamp - Right	(X88)	Outside right front of the vehicle, on the fascia, below the headlamp assembly	<u>Front of Vehicle - Chevrolet</u>	<u>E4P Park/Turn Signal Lamp - Right (X88)</u>
E4RF	Turn Signal Lamp - Right Front	-	Outside front right side of the vehicle, inside headlamp assembly	-	-
E4RR	Turn Signal Lamp - Right Rear	X88	Outside right rear of the vehicle, inside Tail Lamp Assembly - Right	-	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

E5A	Backup Lamp - Left	-	Outside left rear of the vehicle, left center of the liftgate	• <u>Rear of the Vehicle (X88)</u> • <u>Rear of the Vehicle (W49)</u>	• <u>E5A Backup Lamp - Left (W49)</u> • <u>E5A Backup Lamp - Left (X88)</u> • <u>E5A Backup Lamp - Left (Z88)</u>
E5AA	Tail/Stop Lamp - Left	-	Outside left rear of the vehicle, in the left tail lamp assembly	-	-
E5AB	Tail/Stop Lamp - Right	-	Outside left rear of the vehicle, in the left tail lamp assembly	-	-
E5B	Backup Lamp - Right	-	Outside right rear of the vehicle, right center of the liftgate	• <u>Rear of the Vehicle (X88)</u> • <u>Rear of the Vehicle (W49)</u>	• <u>E5B Backup Lamp - Right (W49)</u> • <u>E5B Backup Lamp - Right (X88)</u> • <u>E5B Backup Lamp - Right (Z88)</u>
E5E	Tail Lamp - Left	(W49)	Outside left rear of the vehicle, on the liftgate	<u>Rear of the Vehicle (W49)</u>	<u>E5E Tail Lamp - Left (W49)</u>
E5E	Tail Lamp - Left	(Z88)	Outside left rear of the vehicle, on the quarter panel	<u>Rear of the Vehicle (Z88)</u>	-
E5F	Tail Lamp - Right	(W49)	Outside right rear of the vehicle, on the liftgate	<u>Rear of the Vehicle (W49)</u>	<u>E5F Tail Lamp - Right (W49)</u>
E5F	Tail Lamp - Right	(Z88)	Outside right rear of the vehicle, on the quarter panel	<u>Rear of the Vehicle (Z88)</u>	-
E5G	Tail Lamp - Left Inner	(Z88)	Outside left rear of the vehicle, on the liftgate	<u>Rear of the Vehicle (Z88)</u>	<u>E5G Tail Lamp - Left Inner (Z88)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

E5H	Tail Lamp - Right Inner	(Z88)	Outside right rear of the vehicle, on the liftgate	<u>Rear of the Vehicle (Z88)</u>	<u>E5H Tail Lamp - Right Inner (Z88)</u>
E5S	Tail/Stop and Turn Signal Lamp - Left	(W49 or X88)	Outside rear of the vehicle, left side	• <u>Rear of the Vehicle (W49)</u> • <u>Rear of the Vehicle (X88)</u>	<u>E5S Tail/Stop and Turn Signal Lamp - Left (W49 or X88)</u>
E5T	Tail/Stop and Turn Signal Lamp - Right	(W49 or X88)	Outside rear of the vehicle, right side	• <u>Rear of the Vehicle (W49)</u> • <u>Rear of the Vehicle (X88)</u>	<u>E5T Tail/Stop and Turn Signal Lamp - Right (W49 or X88)</u>
E6	Center High Mounted Stop Lamp	-	Outside center rear of the vehicle, top center of the liftgate	• <u>Rear of the Vehicle (X88)</u> • <u>Rear of the Vehicle (W49)</u> • <u>Rear of the Vehicle (Z88)</u>	• <u>E6 Center High Mounted Stop Lamp (W49)</u> • <u>E6 Center High Mounted Stop Lamp (without W49)</u>
E7L	License Plate Lamp - Left	-	Outside center rear of the vehicle, above the license plate	• <u>Rear of the Vehicle (X88)</u> • <u>Rear of the Vehicle (W49)</u> • <u>Rear of the Vehicle (Z88)</u>	<u>E7L License Plate Lamp - Left</u>
E7R	License Plate Lamp - Right	-	Outside center rear of the vehicle, above the license plate	<u>Rear of the Vehicle (X88)</u>	<u>E7R License Plate Lamp - Right</u>
E8A	Door Sill Plate Lamp - Driver	(B8K)	In the left side of the passenger compartment, near the	<u>Driver Side Footwell and Door Sill (B8K)</u>	<u>E8A Door Sill Plate Lamp - Driver (B8K)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			bottom of the left A-pillar		
E8B	Door Sill Plate Lamp - Passenger	(B8K)	In the right side of the passenger compartment, near the bottom of the right A-pillar	<u>Passenger Side Footwell and Door Sill (B8K)</u>	<u>E8B Door Sill Plate Lamp - Passenger (B8K)</u>
E8J	Instrument Panel Courtesy Lamp - Left	(B8K)	In the left side of the passenger compartment, in the driver side foot well, near the accelerator pedal	<u>Driver Side Footwell and Door Sill (B8K)</u>	<u>E8J Instrument Panel Courtesy Lamp - Left (B8K)</u>
E8K	Instrument Panel Courtesy Lamp - Right	(B8K)	In the right side of the passenger compartment, in the passenger side foot well, near the upper right air temperature sensor	<u>Passenger Side Footwell and Door Sill (B8K)</u>	<u>E8K Instrument Panel Courtesy Lamp - Right (B8K)</u>
E8M	Liftgate Courtesy Lamp - Left	-	In the passenger compartment, inside left of liftgate	<u>Liftgate Components</u>	<u>E8M Liftgate Courtesy Lamp - Left</u>
E8N	Liftgate Courtesy Lamp - Right	-	In the passenger compartment, inside right of liftgate	<u>Liftgate Components</u>	<u>E8N Liftgate Courtesy Lamp - Right</u>
E13LA	Headlamp Assembly - Left	-	Front left side of the vehicle	-	-
E13RA	Headlamp Assembly - Right	-	Front right side of the vehicle, part of the headlamp	-	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			assembly		
E14A	Seat Heating Element - Driver Back	(KA1 or KB6 or SPO Accessory)	In the passenger compartment, under the driver seat back cover	<u>Driver Seat (Except A45)</u>	• <u>E14A Seat Heating Element - Driver Back (KA1)</u> • <u>E14A Seat Heating Element - Driver Back (KB6)</u> • <u>E14A Seat Heating Element - Driver Back (SPO Accessory)</u>
E14B	Seat Heating Element - Driver Cushion	(KA1 or KB6 or SPO Accessory)	In the passenger compartment, under the driver seat cushion cover	<u>Driver Seat (Except A45)</u>	• <u>E14B Seat Heating Element - Driver Cushion (KA1)</u> • <u>E14B Seat Heating Element - Driver Cushion (KB6)</u> • <u>E14B Seat Heating Element - Driver Cushion (SPO Accessory)</u>
E14C	Seat Heating Element - Passenger Back	(KA1 or KB6 or SPO Accessory)	In the passenger compartment, under the passenger seat back cover	<u>Passenger Seat Components</u>	• <u>E14C Seat Heating Element - Passenger Back (KA1)</u> • <u>E14C Seat Heating Element - Passenger Back (KB6)</u> • <u>E14C Seat Heating Element - Passenger Back (SPO Accessory)</u>
E14D	Seat Heating Element - Passenger Cushion	(KA1 or KB6 or SPO Accessory)	In the passenger compartment, under the passenger seat cushion cover	<u>Passenger Seat Components</u>	• <u>E14D Seat Heating Element - Passenger Cushion (KA1)</u> • <u>E14D Seat Heating Element - Passenger Cushion (KB6)</u> • <u>E14D Seat Heating Element - Passenger Cushion (SPO Accessory)</u>
			In the passenger		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

E15	Steering Wheel Heater	UVD	compartment, inside the steering wheel	-	-
E17D	Outside Rearview Mirror Glass - Driver	-	On the outside of driver door, internal to the driver's outside rearview mirror	-	-
E17P	Outside Rearview Mirror Glass - Passenger	-	On the outside of passenger door, internal to the passenger's outside rearview mirror	-	-
E18	Rear Defogger Grid	-	In the passenger compartment, on the inside of the liftgate window	<u>Liftgate Components</u>	• <u>E18 Rear Defogger Grid X1</u> • <u>E18 Rear Defogger Grid X2</u>
E29LF	Fog Lamp - Left Front	(T96)	On the outside left front of the vehicle	• <u>Front of Vehicle - Chevrolet</u> • <u>Front of Vehicle - GMC</u>	• <u>E29LF Fog Lamp - Left Front (Z88 with T96)</u> • <u>E29LF Fog Lamp - Left Front (W49 with T96)</u>
E29R	Fog Lamp - Rear	(W49 with T79)	In the rear bumper, near the left rear corner object alarm sensor	-	<u>E29R Fog Lamp - Rear (W49 with T79)</u>
E29RF	Fog Lamp - Right Front	(T96)	On the outside right front of the vehicle	• <u>Front of Vehicle - Chevrolet</u> • <u>Front of Vehicle - GMC</u>	• <u>E29RF Fog Lamp - Right Front (Z88 with T96)</u> • <u>E29RF Fog Lamp - Right Front (W49 with T96)</u>
			In the		• <u>E37B</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

E37B	Dome/Reading Lamps - 2nd Row	-	passenger compartment, in the headliner, above the second row seats	<u>Headliner Components</u>	<u>Dome/Reading Lamps - 2nd Row (without U42)</u> • <u>E37B Dome/Reading Lamps - 2nd Row (C3U with U42)</u>
E37C	Dome/Reading Lamps - 3rd Row	-	In the passenger compartment, in the headliner, above the third row seats	<u>Headliner Components</u>	<u>E37C Dome/Reading Lamps - 3rd Row</u>
E37E	Dome/Reading Lamps - Front Overhead Console	-	In the passenger compartment, in the headliner above the front seats	<u>Headliner Components</u>	<u>E37E Dome/Reading Lamps - Front Overhead Console</u>
E38	Flood Lamp - Center Console	-	In the passenger compartment, in the front overhead console	<u>Headliner Components</u>	<u>E38 Flood Lamp - Center Console</u>
E42L	Tail Lamp Assembly - Left	-	On the rear of the vehicle, on the left side	-	-
E42R	Tail Lamp Assembly - Right	-	On the rear of the vehicle, on the right side	-	-
E43L	Liftgate Tail Lamp Assembly - Left	-	On the rear of the vehicle, on the left side of the liftgate	-	-
E43R	Liftgate Tail Lamp Assembly - Right	-	On the rear of the vehicle, on the right side of the liftgate	-	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

F101	Passenger Instrument Panel Air Bag	-	In the passenger compartment, in the instrument panel, above the instrument panel compartment	<u>Instrument Panel and Steering Wheel</u>	<u>F101 Passenger Instrument Panel Air Bag</u>
F105L	Roof Rail Air Bag - Left	-	In passenger compartment, all along the left inside of the roof	<u>Roof Rail Air Bags</u>	<u>F105L Roof Rail Air Bag - Left</u>
F105R	Roof Rail Air Bag - Right	-	In passenger compartment, all along the right inside of the roof	<u>Roof Rail Air Bags</u>	<u>F105R Roof Rail Air Bag - Right</u>
F106D	Seat Side Air Bag - Driver	-	Left front of passenger compartment, in the left front seat back	• <u>Driver Seat Components (A45)</u> • <u>Driver Seat (Except A45)</u>	<u>F106D Seat Side Air Bag - Driver</u>
F106DA	Seat Side Air Bag - Driver Inboard	AYQ	Left front of passenger compartment, in the right front seat back	<u>Driver Seat Components (A45)</u>	<u>F106DA Seat Side Air Bag - Driver Inboard (AYQ)</u>
F106P	Seat Side Air Bag - Passenger	-	Right front of passenger compartment, in the right front seat back	<u>Passenger Seat Components</u>	<u>F106P Seat Side Air Bag - Passenger</u>
F107	Steering Wheel Air Bag	-	In the passenger compartment, in the center hub of the steering wheel	<u>Instrument Panel and Steering Wheel</u>	• <u>F107 Steering Wheel Air Bag X1</u> • <u>F107 Steering Wheel Air Bag X2</u>
	Seat Belt Retractor		In the passenger		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

F112D	Pretensioner - Driver	-	compartment, in the left B-pillar	<u>Behind the Driver Seat</u>	<u>F112D Seat Belt Retractor Pretensioner - Driver</u>
F112P	Seat Belt Retractor Pretensioner - Passenger	-	In the passenger compartment, in the right B-pillar	<u>Behind the Passenger Seat</u>	<u>F112P Seat Belt Retractor Pretensioner - Passenger</u>
F113D	Seat Belt Anchor Pretensioner - Driver	-	In the passenger compartment, in the driver seat, attached to the lower right side of the seat	<u>Driver Seat Components (A45)</u>	<u>F113D Seat Belt Anchor Pretensioner - Driver</u>
F113P	Seat Belt Anchor Pretensioner - Passenger	-	In the passenger compartment, in the passenger seat, attached to the lower left side of the seat	<u>Passenger Seat Components</u>	<u>F113P Seat Belt Anchor Pretensioner - Passenger</u>
G1	A/C Compressor	-	In the engine compartment, front right lower of engine	-	-
G6	Brake Booster Pump - Auxiliary	-	In the engine compartment, mounted to the top center rear of the radiator support	<u>Engine Components - Right Rear</u>	<u>G6 Brake Booster Pump - Auxiliary</u>
G10L	Cooling Fan Motor - Left	-	In the engine compartment, behind the left side of the radiator	<u>Front of Engine Compartment - Components</u>	<u>G10L Cooling Fan Motor - Left</u>
G10R	Cooling Fan Motor - Right	-	In the engine compartment, behind the right side of	<u>Front of Engine Compartment - Components</u>	<u>G10R Cooling Fan Motor - Right</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			the radiator		
G13	Generator	-	In the engine compartment, right front lower area of engine	<u>Engine Components - Front</u>	<u>G13 Generator X1</u>
G16	Headlamp Washer Pump	CZ2	In the engine compartment, mounted to the washer solvent reservoir, below the left headlamp assembly	-	-
G18	High Pressure Fuel Pump	-	In the engine compartment, left end of the front cylinder head	<u>Engine Components - Front</u>	<u>G18 High Pressure Fuel Pump</u>
G19	Rear Window Washer Pump	-	Attached to the washer fluid reservoir in the engine compartment, below the left headlamp assembly	<u>Front of Engine Compartment - Components</u>	<u>G19 Rear Window Washer Pump</u>
G24	Windshield Washer Pump	-	In the engine compartment, mounted to the washer solvent reservoir, below the left headlamp assembly	<u>Front of Engine Compartment - Components</u>	<u>G24 Windshield Washer Pump</u>
K8	Blower Motor Control Module	-	In the passenger compartment, on the HVAC case, behind the right side of the instrument panel	• <u>Interior HVAC Module - Front (CJ2)</u> • <u>Front HVAC Module</u>	• <u>K8 Blower Motor Control Module X1</u> • <u>K8 Blower Motor Control Module X2</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			compartment, in front of the blower motor	(C67)	
K8A	Blower Motor Control Module - Auxiliary	-	In the passenger compartment, on the rear HVAC case, behind the right rear interior body panel	<u>Interior HVAC Module - Rear</u>	• <u>K8A Blower Motor Control Module - Auxiliary X1</u> • <u>K8A Blower Motor Control Module - Auxiliary X2</u>
K9	Body Control Module	-	In the passenger compartment, below the left side of the instrument panel, to the left of the steering column	<u>Below the Driver Side of the Instrument Panel</u>	• <u>K9 Body Control Module X1</u> • <u>K9 Body Control Module X2</u> • <u>K9 Body Control Module X3</u> • <u>K9 Body Control Module X4</u> • <u>K9 Body Control Module X5</u> • <u>K9 Body Control Module X6</u> • <u>K9 Body Control Module X7</u>
K13	DVD Control Module	(SPO Accessory)	In the passenger compartment, on driver side of center console, below the instrument panel, behind the trim panel	-	• <u>K13 DVD Control Module X1 (SPO Accessory)</u> • <u>K13 DVD Control Module X2 (SPO Accessory)</u> • <u>K13 DVD Control Module X3 (SPO Accessory)</u> • <u>K13 DVD Control Module X4 (SPO Accessory)</u> • <u>K13 DVD Control Module X5 (SPO Accessory)</u> • <u>K13 DVD Control Module X6 (SPO</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

					<u>Accessory)</u>
K17	Electronic Brake Control Module	-	Lower left side of the engine compartment	<u>Engine Components - Front Left</u>	<u>K17 Electronic Brake Control Module</u>
K18	Compass Module	(U80)	In the passenger compartment, above the rear center of headliner, near the remote control door lock receiver	<u>Headliner Components</u>	<u>K18 Compass Module (U80)</u>
K20	Engine Control Module	-	In the front center of the engine compartment, mounted on the upper core support, behind the hood latch	<u>Engine Components - Front Left</u>	• <u>K20 Engine Control Module X1</u> • <u>K20 Engine Control Module X2</u> • <u>K20 Engine Control Module X3</u>
K26	Headlamp Control Module	(TSH or T26)	Front right side of the vehicle, part of the right headlamp assembly	-	<u>K26 Headlamp Control Module (TSH or T26)</u>
K26A	Headlamp High Beam Control Module - Left	(W49)	Front left side of the vehicle, part of the headlamp assembly	-	<u>K26A Headlamp High Beam Control Module - Left (W49)</u>
K26B	Headlamp High Beam Control Module - Right	(W49)	Front right side of the vehicle, part of the headlamp assembly	-	<u>K26B Headlamp High Beam Control Module - Right (W49)</u>
					• <u>K29D Seat Heating Control Module - Driver X1 (KA1 without A45)</u> • <u>K29D Seat Heating</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

K29D	Seat Heating Control Module - Driver	(KA1 without A45 or SPO Accessory)	In the passenger compartment, under the driver seat	<u>Driver Seat (Except A45)</u>	<u>Control Module - Driver X2 (KA1 without A45)</u> • <u>K29D Seat Heating Control Module - Driver X3 (KA1 without A45)</u> • <u>K29D Seat Heating Control Module - Driver X4 (KA1 without A45)</u>
K32	Steering Wheel Heating Control Module	UVD	In the passenger compartment, in the steering wheel, behind the air bag	-	-
K33	HVAC Control Module	-	In the passenger compartment, in the instrument panel center trim panel, beneath the radio	• <u>Instrument Panel Components</u> • <u>Front Center of the Instrument Panel (W49)</u>	• <u>K33 HVAC Control Module X1</u> • <u>K33 HVAC Control Module X2 (C67)</u> • <u>K33 HVAC Control Module X2 (CJ2)</u> • <u>K33 HVAC Control Module X3</u> • <u>K33 HVAC Control Module X4</u>
K33A	HVAC Control Module - Auxiliary	-	In the passenger compartment, rear of center console	-	-
K36	Inflatable Restraint Sensing and Diagnostic Module	-	In passenger compartment, on the floor, below the front floor console	<u>Near the Passenger Seat</u>	• <u>K36 Inflatable Restraint Sensing and Diagnostic Module (SDM) X1</u> • <u>K36 Inflatable Restraint Sensing and Diagnostic Module (SDM) X2</u>
K38	Chassis Control Module	-	Mounted under the rear of the vehicle, rear of the	-	<u>K38 Chassis Control Module</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			fuel tank		
K39	Liftgate Control Module	(TB5)	In the passenger compartment, behind the left rear interior body panel	<u>Left Rear of the Passenger Compartment</u>	• <u>K39 Liftgate Control Module X1 (TB5)</u> • <u>K39 Liftgate Control Module X2 (TB5)</u> • <u>K39 Liftgate Control Module X3 (TB5)</u>
K40	Seat Memory Control Module	(A45)	In the passenger compartment, under the driver seat	<u>Driver Seat Components (A45)</u>	• <u>K40 Seat Memory Control Module X1 (A45)</u> • <u>K40 Seat Memory Control Module X2 (A45)</u> • <u>K40 Seat Memory Control Module X3 (A45)</u> • <u>K40 Seat Memory Control Module X4 (A45)</u> • <u>K40 Seat Memory Control Module X5 (A45)</u> • <u>K40 Seat Memory Control Module X6 (A45)</u> • <u>K40 Seat Memory Control Module X7 (A45)</u>
K41	Front and Rear Parking Assist Control Module	(UD7)	In the passenger compartment, behind the left rear interior body panel	<u>Left Rear of the Passenger Compartment</u>	• <u>K41 Front and Rear Parking Assist Control Module X1 (UD7)</u> • <u>K41 Front and Rear Parking Assist Control Module X2 (UD7)</u>
	Rear Differential		Under rear of vehicle,	<u>Near the Rear</u>	• <u>K47 Rear Differential Clutch Control Module X1 (M7X)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

K47	Clutch Control Module	(MH6)	mounted above the rear differential	<u>Differential (MH6)</u>	• <u>K47 Rear Differential Clutch Control Module X2 (M7X)</u>
K53D	Seat Blower Assembly - Driver Back	(KB6)	In the left front passenger compartment, under the driver seat back rear trim panel	<u>Driver Seat Components (A45)</u>	<u>K53D Seat Blower Assembly - Driver Back (KB6)</u>
K53P	Seat Blower Assembly - Passenger Back	(KB6)	In the right front passenger compartment, under the passenger seat back rear trim panel	<u>Passenger Seat Components</u>	<u>K53P Seat Blower Assembly - Passenger Back (KB6)</u>
K55D	Seat Blower Assembly - Driver Cushion	(KB6)	In the passenger compartment, below the driver seat	<u>Driver Seat Components (A45)</u>	<u>K55D Seat Blower Assembly - Driver Cushion (KB6)</u>
K55P	Seat Blower Assembly - Passenger Cushion	(KB6)	In the passenger compartment, below the passenger seat	<u>Passenger Seat Components</u>	<u>K55P Seat Blower Assembly - Passenger Cushion (KB6)</u>
K61	Sunroof Control Module	(C3U)	In the passenger compartment, in the roof, above the headliner, between the sunshades	<u>Roof Panel</u>	<u>K61 Sunroof Control Module (C3U)</u>
K64	Content Theft Deterrent Control Module	-	In the passenger compartment, in the steering column, at the ignition switch	<u>Steering Column Components</u>	<u>K64 Content Theft Deterrent Control Module</u>
			In the engine		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

K71	Transmission Control Module	-	compartment, in the automatic transmission, part of control solenoid valve assembly	-	-
K73	Telematics Communication Interface Control Module	(UE1)	In the passenger compartment, behind the left rear interior body panel	<u>Left Rear of the Passenger Compartment</u>	• <u>K73 Telematics Communication Interface Control Module X1 (UE1)</u> • <u>K73 Telematics Communication Interface Control Module (VCIM) X2 (UE1)</u>
K77	Remote Control Door Lock Receiver	-	In the passenger compartment, rear center of roof, above the cargo lamp and headliner	<u>Headliner Components</u>	<u>K77 Remote Control Door Lock Receiver</u>
K85	Passenger Presence Module	-	In the passenger compartment, under the upholstery in the passenger seat cushion, right rear corner, sensor part of module and under cushion	<u>Passenger Seat Components</u>	<u>K85 Passenger Presence Module</u>
KR103	DVD Relay	(SPO Accessory)	In the passenger compartment	-	<u>KR103 DVD Relay (SPO Accessory)</u>
M3L	Headlamp Horizontal Motor - Left	(TSH or T26)	Front left side of the vehicle, part of the headlamp assembly	-	<u>M3L Headlamp Horizontal Motor - Left (TSH or T26)</u>
			Front right		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

M3R	Headlamp Horizontal Motor - Right	(TSH or T26)	side of the vehicle, part of the headlamp assembly	-	<u>M3R Headlamp Horizontal Motor - Right (TSH or T26)</u>
M6	Air Temperature Door Actuator	(C67)	In the passenger compartment, behind the center of the instrument panel, on the right side of the front HVAC module	<u>Front HVAC Module (C67)</u>	<u>M6 Air Temperature Door Actuator (C67)</u>
M6B	Air Temperature Door Actuator - Auxiliary	-	In the passenger compartment, in the rear HVAC module, behind the right rear interior body panel	<u>Interior HVAC Module - Rear</u>	<u>M6B Air Temperature Door Actuator - Auxiliary</u>
M6L	Air Temperature Door Actuator - Left	(CJ2)	In the passenger compartment, behind the center of the instrument panel, on the left side of the front HVAC module	<u>Interior HVAC Module - Front (CJ2)</u>	<u>M6L Air Temperature Door Actuator - Left (CJ2)</u>
M6R	Air Temperature Door Actuator - Right	(CJ2)	In the passenger compartment, behind the center of the instrument panel, on the right side of the front HVAC module	<u>Interior HVAC Module - Front (CJ2)</u>	<u>M6R Air Temperature Door Actuator - Right (CJ2)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

M7	Transmission Shift Lock Control Solenoid Actuator	-	In the passenger compartment, part of the automatic transmission shifter, at the base of the shift lever	<u>Automatic Transmission Floor Shifter</u>	<u>M7 Transmission Shift Lock Control Solenoid Actuator</u>
M8	Blower Motor	-	In the passenger compartment, in the HVAC case, behind the right side of the instrument panel compartment	• <u>Interior HVAC Module - Front (CJ2)</u> • <u>Front HVAC Module (C67)</u> • <u>Interior HVAC Module - Rear</u>	<u>M8 Blower Motor</u>
M8B	Blower Motor - Auxiliary	-	In the passenger compartment, on the rear HVAC case, behind the right rear interior body panel	<u>Interior HVAC Module - Rear</u>	<u>M8B Blower Motor - Auxiliary</u>
M17	Liftgate Motor Assembly	(TB5)	In the passenger compartment, behind the left rear interior body panel	<u>Left Rear of the Passenger Compartment</u>	-
M28L	High Beam Solenoid Actuator - Left	-	Front left side of the vehicle, part of the headlamp assembly	-	• <u>M28L High Beam Solenoid Actuator - Left (W49)</u> • <u>M28L High Beam Solenoid Actuator - Left (Z88 with TVD)</u>
			Front right side of the		• <u>M28R High Beam Solenoid Actuator - Right (W49)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

M28R	High Beam Solenoid Actuator - Right	-	vehicle, part of the headlamp assembly	-	• <u>M28R High Beam Solenoid Actuator - Right (Z88 with TVD)</u>
M31	Liftgate Motor	(TB5)	Behind the left rear interior body panel, mounted to the liftgate actuator assembly	-	-
M37	Mode Door Actuator	-	In the passenger compartment, right side of the HVAC module, forward of the right air temperature actuator	• <u>Interior HVAC Module - Front (CJ2)</u> • <u>Front HVAC Module (C67)</u>	<u>M37 Mode Door Actuator</u>
M37B	Mode Door Actuator - Auxiliary	-	In the passenger compartment, in the rear HVAC module, behind the right rear interior body panel	<u>Interior HVAC Module - Rear</u>	<u>M37B Mode Door Actuator - Auxiliary</u>
M45	Rear Wiper Motor	-	Rear of the vehicle, inside the liftgate	<u>Liftgate Components</u>	• <u>M45 Rear Wiper Motor (without X88)</u> • <u>M45 Rear Wiper Motor (X88)</u>
M46	Air Recirculation Door Actuator	-	In the passenger compartment, above the blower motor, on the right side of the front HVAC module	<u>Front HVAC Module (C67)</u>	<u>M46 Air Recirculation Door Actuator (CJ2)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

M50D	Seat Front Vertical Motor - Driver	(AG1 or AG3 or AH5)	In the passenger compartment, under the driver seat	• <u>Driver Seat Components (A45)</u> • <u>Driver Seat (Except A45)</u>	<u>M50D Seat Front Vertical Motor - Driver (AG1 or AH5 or AG3)</u>
M50P	Seat Front Vertical Motor - Passenger	AH8	In the passenger compartment, under the passenger seat	-	-
M51D	Seat Horizontal Motor - Driver	(AG1 or AG3 or AH5)	In the passenger compartment, under the driver seat	• <u>Driver Seat Components (A45)</u> • <u>Driver Seat (Except A45)</u>	<u>M51D Seat Horizontal Motor - Driver (AG1 or AH5 or AG3)</u>
M51P	Seat Horizontal Motor - Passenger	(AAQ or AG2)	In the passenger compartment, under the passenger seat	<u>Passenger Seat Components</u>	<u>M51P Seat Horizontal Motor - Passenger (AG2 or AH8)</u>
M52D	Seat Lumbar Support Horizontal Motor - Driver	(AG3 or AH5)	In the passenger compartment, in the driver seat back	• <u>Driver Seat (Except A45)</u> • <u>Driver Seat Components (A45)</u>	<u>M52D Seat Lumbar Support Horizontal Motor - Driver (AG3 or AH5)</u>
M52P	Seat Lumbar Support Horizontal Motor - Passenger	(AAQ)	In the passenger compartment, in the passenger seat back	<u>Passenger Seat Components</u>	<u>M52P Seat Lumbar Support Horizontal Motor - Passenger (AH8)</u>
M55D	Seat Rear Vertical Motor - Driver	(AG1 or AG3 or AH5)	In the passenger compartment, under the driver seat	• <u>Driver Seat (Except A45)</u> • <u>Driver Seat Components (A45)</u>	<u>M55D Seat Rear Vertical Motor - Driver (AG1 or AH5 or AG3)</u>
M55P	Seat Rear Vertical Motor - Passenger	AH8	In the passenger compartment, under the	-	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			passenger seat		
M56D	Seat Recline Motor - Driver	(AG3 or AH5)	In the passenger compartment, in the driver seat back	• <u>Driver Seat (Except A45)</u> • <u>Driver Seat Components (A45)</u>	<u>M56D Seat Recline Motor - Driver (AG3 or AH5)</u>
M56P	Seat Recline Motor - Passenger	(AAQ)	In the passenger compartment, in the passenger seat back	<u>Passenger Seat Components</u>	<u>M56P Seat Recline Motor - Passenger (AH8)</u>
M64	Starter Motor	-	In the engine compartment, lower left front of the engine	<u>Engine Components - Front</u>	<u>M64 Starter Motor X2</u>
M65	Steering Column Telescope Motor	(N38)	In the passenger compartment, on the lower center of the steering column	<u>Steering Column Components</u>	<u>M65 Steering Column Telescope Motor (N38)</u>
M66	Steering Column Tilt and Telescope Motor	(N38)	In the passenger compartment, on the lower center of the steering column	-	-
M68	Steering Column Tilt Motor	(N38)	In the passenger compartment, near the lower center of the steering column	<u>Steering Column Components</u>	<u>M68 Steering Column Tilt Motor (N38)</u>
M72	Variable Power Steering Solenoid Valve	(NV7)	Left rear of engine compartment, part of the power steering rack assembly, at	<u>Engine Components - Front Left</u>	<u>M72 Variable Power Steering Solenoid Valve (NV7)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			the steering shaft connection		
M74D	Window Motor - Driver	-	Inside the driver door	<u>Driver Door</u>	• <u>M74D Window Motor - Driver (AXE)</u> • <u>M74D Window Motor - Driver (without AXE)</u>
M74LR	Window Motor - Left Rear	-	Inside the left rear door	<u>Left Rear Door</u>	<u>M74LR Window Motor - Left Rear</u>
M74P	Window Motor - Passenger	-	Inside the passenger door	<u>Passenger Door</u>	• <u>M74P Window Motor - Passenger (AXE)</u> • <u>M74P Window Motor - Passenger (without AXE)</u>
M74RR	Window Motor - Right Rear	-	Inside the right rear door	<u>Right Rear Door</u>	<u>M74RR Window Motor - Right Rear</u>
M75	Windshield Wiper Motor	-	Top left rear of the engine compartment	-	<u>M75 Windshield Wiper Motor</u>
M93	Key Capture Solenoid Actuator	-	Left front of passenger compartment, on the steering column	<u>Steering Column Components</u>	<u>M93 Key Capture Solenoid Actuator</u>
P2	Transmission Shift Lever Position Indicator	-	In the passenger compartment, in the floor console, on the automatic transmission floor shifter	<u>Automatic Transmission Floor Shifter</u>	<u>P2 Transmission Shift Lever Position Indicator</u>
P6	Clock	(W49)	In the passenger compartment, center of the instrument panel, above the radio	<u>Front Center of the Instrument Panel (W49)</u>	<u>P6 Clock (W49)</u>
			In the passenger		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

P9	Driver Information Center Display	-	compartment, on the left side of the instrument panel, above the steering column, inside the Instrument Cluster	-	-
P12A	Horn - High Note	-	Right front of the vehicle, below the right headlamp housing	<u>Front of Engine Compartment - Components</u>	<u>P12A Horn - High Note</u>
P12B	Horn - Low Note	-	Left front of the vehicle, below the left headlamp housing	<u>Front of Engine Compartment - Components</u>	<u>P12B Horn - Low Note</u>
P14	Passenger Air Bag Disable Indicator	-	In the passenger compartment, in the center of the instrument panel, above the radio	• <u>Front Center of the Instrument Panel (W49)</u> • <u>Instrument Panel Components</u>	<u>P14 Passenger Air Bag Disable Indicator</u>
P16	Instrument Cluster	-	In the passenger compartment, on the left side of the instrument panel, above the steering column	• <u>Left Side of Upper Instrument Panel</u> • <u>Instrument Panel Components</u>	<u>P16 Instrument Cluster</u>
P19AC	Speaker - Subwoofer	(UQA or UQS)	In the passenger compartment, below the center of the instrument panel	<u>Below the Center Instrument Panel Trim</u>	<u>P19AC Speaker - Subwoofer (UQA or UQS)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

P19AG	Speaker - Left Front Door	-	In the passenger compartment, inside the left front door	• <u>Upper Instrument Panel Area</u> • <u>Driver Door</u>	• <u>P19AG Speaker - Left Front Door (UQA or UQS)</u> • <u>P19AG Speaker - Left Front Door (UQF)</u>
P19AH	Speaker - Right Front Door	-	Inside the right front door	• <u>Upper Instrument Panel Area</u> • <u>Passenger Door</u>	• <u>P19AH Speaker - Right Front Door (UQA or UQS)</u> • <u>P19AH Speaker - Right Front Door (UQF)</u>
P19AL	Speaker - Left Rear Door	-	Inside the left rear door	<u>Left Rear Door</u>	• <u>P19AL Speaker - Left Rear Door (UQA or UQS with W49)</u> • <u>P19AL Speaker - Left Rear Door (UQA or UQS without W49)</u> • <u>P19AL Speaker - Left Rear Door (UQF)</u>
P19AM	Speaker - Right Rear Door	-	Inside the right rear door	<u>Right Rear Door</u>	• <u>P19AM Speaker - Right Rear Door (UQA or UQS with W49)</u> • <u>P19AM Speaker - Right Rear Door (UQA or UQS without W49)</u> • <u>P19AM Speaker - Right Rear Door (UQF)</u>
P19B	Speaker - Center Instrument Panel	(UQA or UQS)	In the passenger compartment, top center of the instrument panel	<u>Upper Instrument Panel Area</u>	<u>P19B Speaker - Center Instrument Panel (UQA or UQS)</u>
P19H	Speaker - Left Front Tweeter	-	In the passenger compartment, on the left A-	<u>Upper Instrument Panel Area</u>	<u>P19H Speaker - Left Front Tweeter</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			pillar		
P19L	Speaker - Left Rear Compartment	(UQA or UQS)	In the passenger compartment, left rear of the vehicle, at third row seating, in quarter trim panel	<u>Left Rear of the Passenger Compartment</u>	<u>P19L Speaker - Left Rear Compartment (UQA or UQS)</u>
P19V	Speaker - Right Front Tweeter	-	In the passenger compartment, on the right A-pillar	<u>Upper Instrument Panel Area</u>	<u>P19V Speaker - Right Front Tweeter</u>
P19Y	Speaker - Right Rear Compartment	(UQA or UQS)	In the passenger compartment, right rear of the vehicle, at third row seating, in quarter trim panel	<u>Right Rear Trim Panel</u>	<u>P19Y Speaker - Right Rear Compartment (UQA or UQS)</u>
P22D	Video Display - Driver Seat Headrest	(SPO Accessory)	In the passenger compartment, mounted to the driver seat headrest	-	• <u>P22D Video Display - Driver Seat Headrest X1 (SPO Accessory)</u> • <u>P22D Video Display - Driver Seat Headrest X2 (SPO Accessory)</u>
P22P	Video Display - Passenger Seat Headrest	(SPO Accessory)	In the passenger compartment, mounted to the passenger seat headrest	-	• <u>P22P Video Display - Passenger Seat Headrest X1 (SPO Accessory)</u> • <u>P22P Video Display - Passenger Seat Headrest X2 (SPO Accessory)</u>
P23	Video Display	(U42)	In the passenger compartment, in the center headliner	<u>Headliner Components</u>	<u>P23 Video Display (U42)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			console		
P29	Head-Up Display	(UV6)	In the passenger compartment, left top of the instrument panel, in front of the instrument panel cluster	<u>Left Side of Upper Instrument Panel</u>	<u>P29 Head-Up Display (UV6)</u>
Q2	A/C Compressor Clutch	-	In the engine compartment, mounted to the front of the A/C compressor, front right lower of engine	<u>Engine Components - Front Left</u>	<u>Q2 A/C Compressor Clutch</u>
Q6A	Camshaft Position Actuator Solenoid Valve - Bank 1 Exhaust	(CMP) Actuator Solen	In the engine compartment, on the right side of the rear cylinder head, lower center position	<u>Engine Components - Right Rear</u>	<u>Q6A Camshaft Position Actuator Solenoid Valve - Bank 1 Exhaust</u>
Q6B	Camshaft Position Actuator Solenoid Valve - Bank 1 Intake	(CMP) Actuator Solen	In the engine compartment, on the right side of the rear cylinder head, upper center position	<u>Engine Components - Right Rear</u>	<u>Q6B Camshaft Position Actuator Solenoid Valve - Bank 1 Intake</u>
Q6C	Camshaft Position Actuator Solenoid Valve - Bank 2 Exhaust	(CMP) Actuator Solen	In the engine compartment, on the right side of the front cylinder head, lower center position	<u>Engine Components - Right Rear</u>	<u>Q6C Camshaft Position Actuator Solenoid Valve - Bank 2 Exhaust</u>
	Camshaft Position	(CMP)	In the engine compartment, on the right	<u>Engine</u>	<u>Q6D Camshaft Position</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

Q6D	Actuator Solenoid Valve - Bank 2 Intake	Actuator Solenoid	side of the front cylinder head, upper center position	<u>Components - Right Rear</u>	<u>Actuator Solenoid Valve - Bank 1 Intake</u>
Q8	Control Solenoid Valve Assembly	-	In the engine compartment, inside the automatic transmission, at front	<u>Automatic Transmission Electronic Components</u>	• <u>Q8 Control Solenoid Valve Assembly X1</u> • <u>Q8 Control Solenoid Valve Assembly X2</u> • <u>Q8 Control Solenoid Valve Assembly X3</u> • <u>Q8 Control Solenoid Valve Assembly X4</u>
Q12	Evaporative Emission Purge Solenoid Valve	-	In the engine compartment, left top front of the engine, on the intake manifold, next to the throttle body	<u>Engine Components - Front</u>	<u>Q12 Evaporative Emission Purge Solenoid Valve</u>
Q13	Evaporative Emission Vent Solenoid Valve	-	Under left center of vehicle, on EVAP canister	<u>Fuel Tank Components</u>	<u>Q13 Evaporative Emission Vent Solenoid Valve</u>
Q17A	Fuel Injector 1	-	In the engine compartment, top of the engine, at the cylinder 1 intake port, under the upper plenum	<u>Engine Components - Top</u>	<u>Q17A Fuel Injector 1</u>
Q17B	Fuel Injector 2	-	In the engine compartment, top of the engine, at the cylinder 2 intake port, under the upper plenum	<u>Engine Components - Top</u>	<u>Q17B Fuel Injector 2</u>
			In the engine compartment, top of the	<u>Engine</u>	

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

Q17C	Fuel Injector 3	-	engine, at the cylinder 3 intake port, under the upper plenum	<u>Components - Top</u>	<u>Q17C Fuel Injector 3</u>
Q17D	Fuel Injector 4	-	In the engine compartment, top of the engine, at the cylinder 4 intake port, under the upper plenum	<u>Engine Components - Top</u>	<u>Q17D Fuel Injector 4</u>
Q17E	Fuel Injector 5	-	In the engine compartment, top of the engine, at the cylinder 5 intake port, under the upper plenum	<u>Engine Components - Top</u>	<u>Q17E Fuel Injector 5</u>
Q17F	Fuel Injector 6	-	In the engine compartment, top of the engine, at the cylinder 6 intake port, under the upper plenum	<u>Engine Components - Top</u>	<u>Q17F Fuel Injector 6</u>
Q27A	Pressure Control Solenoid Valve 1	-	In the engine compartment, inside the automatic transmission	-	-
Q27B	Pressure Control Solenoid Valve 2	-	In the engine compartment, inside the automatic transmission	-	-
Q27C	Pressure Control Solenoid Valve 3	-	In the engine compartment, inside the automatic transmission	-	-
	Pressure Control		In the engine compartment,		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

Q27D	Solenoid Valve 4	-	inside the automatic transmission	-	-
Q27E	Pressure Control Solenoid Valve 5	-	In the engine compartment, inside the automatic transmission	-	-
Q32A	Shift Solenoid Valve 1	-	In the engine compartment, inside the automatic transmission	-	-
Q32B	Shift Solenoid Valve 2	-	In the engine compartment, inside the automatic transmission	-	-
Q38	Throttle Body	-	In the engine compartment, top of the engine	<u>Engine Components - Right Rear</u>	<u>Q38 Throttle Body</u>
Q39A	Torque Converter Clutch Pressure Control Solenoid Valve	-	In the engine compartment, inside the automatic transmission	-	-
Q46	A/C Compressor Solenoid Valve	-	In the right front of the engine compartment, at the right front corner of the engine, attached to the A/C compressor	-	<u>Q46 A/C Compressor Solenoid Valve</u>
Q49	Rear Differential Clutch Solenoid Valve	M7X	Under the rear of the vehicle, mounted near the top of the rear differential	-	-
			Behind the left rear interior body		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

Q75	Liftgate Actuator Clutch	(TB5)	panel, mounted to the liftgate actuator assembly	-	<u>Q75 Liftgate Motor Clutch (TB5)</u>
R6A	Terminating Resistor - High Speed Bus	(without MH6)	Under the vehicle, taped to the rear chassis harness, near X405, above the spare tire	<u>Near the Rear Differential (without MH6)</u>	<u>R6A Terminating Resistor - High Speed Bus (M7V)</u>
S2	Transmission Manual Shift Switch	-	In the passenger compartment, part of the automatic transmission shift lever knob	<u>Automatic Transmission Floor Shifter</u>	<u>S2 Transmission Manual Shift Switch</u>
S3	Transmission Shift Lever	-	In the passenger compartment, in the center of the front floor console, part of floor shifter assembly	<u>Automatic Transmission Floor Shifter</u>	-
S13D	Door Lock Switch - Driver	(without AXE)	In the passenger compartment, mounted on the left front door trim	<u>Driver Door Switches (without AXE)</u>	<u>S13D Door Lock Switch - Driver (without AXE)</u>
S13P	Door Lock Switch - Passenger	(without AXE)	In the passenger compartment, mounted on the right front door trim	<u>Passenger Door</u>	<u>S13P Door Lock Switch - Passenger (without AXE)</u>
S16	Driver Information Center Switch	(UH9)	In the passenger compartment, center of the instrument	<u>Front Center of the Instrument Panel (W49)</u>	<u>S16 Driver Information Center Switch (UH9)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			panel, below the radio		
S25	Garage Door Opener	(UG1)	In the passenger compartment, in the headliner console	<u>Headliner Components</u>	<u>S25 Garage Door Opener (UG1)</u>
S26	Hazard Warning Switch	-	In the passenger compartment, center of the instrument panel, above the HVAC control	<u>Instrument Panel Components</u>	<u>S26 Hazard Warning Switch</u>
S27	Head-Up Display Switch	(UV6)	In the passenger compartment, below the right side of the instrument panel cluster	<u>Instrument Panel Components</u>	<u>S27 Head-Up Display Switch (UV6)</u>
S30	Headlamp Switch	-	In the passenger compartment, left side of the instrument panel, below the instrument panel cluster	<u>Instrument Panel Components</u>	<u>S30 Headlamp Switch</u>
S31D	Seat Heating and Cooling Switch - Driver	(KB6)	In the passenger compartment, left center of the instrument panel, below the HVAC control	<u>Console Components</u>	<u>S31D Seat Heating and Cooling Switch - Driver (KB6)</u>
S31P	Seat Heating and Cooling Switch - Passenger	(KB6)	In the passenger compartment, right center of the instrument panel, below the HVAC control	<u>Console Components</u>	<u>S31P Seat Heating and Cooling Switch - Passenger (KB6)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			control		
S32D	Seat Heating Switch - Driver	(KA1 or KB6 or SPO Accessory)	In the passenger compartment, left center of the instrument panel below the HVAC control	<u>Console Components</u>	<u>S32D Seat Heating Switch - Driver (KA1)</u>
S32P	Seat Heating Switch - Passenger	(KA1 or SPO Accessory)	In the passenger compartment, right center of the instrument panel, below the HVAC control	<u>Console Components</u>	<u>S32P Seat Heating Switch - Passenger (KA1)</u>
S33	Horn Switch	-	In the passenger compartment, in the steering wheel	<u>Steering Wheel Components</u>	• <u>S33 Horn Switch X1</u> • <u>S3 Horn Switch X2</u>
S34B	HVAC Controls Switch Assembly - Auxiliary	ULD	In the passenger compartment, rear of center console	-	-
S39	Ignition Switch	-	In the passenger compartment, in the steering column, below ignition key cylinder	<u>Steering Column Components</u>	<u>S39 Ignition Switch</u>
S45A	Liftgate Control Switch - Exterior	-	Outside rear center of the vehicle, on the liftgate	<u>Liftgate Components</u>	<u>S45A Liftgate Control Switch - Exterior</u>
S45B	Liftgate Control Switch - Interior	(TB5)	Inside rear of the vehicle, on the bottom left liftgate trim panel	<u>Liftgate Components</u>	<u>S45B Liftgate Control Switch - Interior (TB5)</u>
			In the passenger		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

S47D	Seat Memory Switch - Driver	(A45)	compartment, on the left front door trim panel	<u>Driver Door</u>	<u>S47D Seat Memory Switch - Driver (A45)</u>
S48A	Multifunction Switch - Instrument Panel	-	In the passenger compartment, in the instrument panel center trim panel, beneath the HVAC control	<u>Instrument Panel Components</u>	<u>S48A Multifunction Switch - Instrument Panel</u>
S51	Telematics Button Assembly	UE1	In the passenger compartment, on the overhead console	-	-
S52	Outside Rearview Mirror Switch	(without AXE)	In the passenger compartment, mounted on the left front door trim	<u>Driver Door Switches (without AXE)</u>	<u>S52 Outside Rearview Mirror Switch (without AXE)</u>
S64D	Seat Adjuster Switch - Driver	(AG1 or AG3 or AH5)	In left front passenger compartment, on the lower left outside of the driver seat	<u>Driver Seat Components (A45)</u> <u>Driver Seat (Except A45)</u>	<u>S64D Seat Adjuster Switch - Driver (AG1)</u> <u>S64D Seat Adjuster Switch - Driver (AG3)</u> <u>S64D Seat Adjuster Switch - Driver (AH5)</u>
S64P	Seat Adjuster Switch - Passenger	(AAQ or AG2)	In the right front passenger compartment, on the lower right outside of the passenger seat	<u>Passenger Seat Components</u>	<u>S64P Seat Adjuster Switch - Passenger (AH8)</u> <u>S64P Seat Adjuster Switch - Passenger (AG2)</u>
	Seat Lumbar		In the passenger	<u>Driver Seat (Except</u>	<u>S65D Seat Lumbar</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

S65D	Support Switch - Driver	(AG3 or AH5)	compartment, on the lower left outside of the driver seat	<u>A45)</u> • <u>Driver Seat Components</u> <u>(A45)</u>	<u>Support Switch - Driver</u> <u>(AG3 or AH5)</u>
S65P	Seat Lumbar Support Switch - Passenger	(AAQ)	In the passenger compartment, on the lower right outside of the passenger seat	<u>Passenger Seat Components</u>	<u>S65P Seat Lumbar Support Switch - Passenger (AH8)</u>
S70L	Steering Wheel Controls Switch - Left	-	In the passenger compartment, on the left steering wheel spoke	<u>Steering Wheel Components</u>	<u>S70L Steering Wheel Controls Switch - Left</u>
S70R	Steering Wheel Controls Switch - Right	(UK3)	In the passenger compartment, on the right steering wheel spoke	<u>Steering Wheel Components</u>	<u>S70R Steering Wheel Controls Switch - Right (UK3)</u>
S71	Steering Column Tilt and Telescope Switch	(N38)	In the passenger compartment, left side of the steering column, below the multifunction switch	<u>Steering Column Components</u>	<u>S71 Steering Column Tilt and Telescope Switch (N38)</u>
S72	Sunroof Switch	(C3U)	In the passenger compartment, at the roof, in the overhead console	<u>Headliner Components</u>	<u>S72 Sunroof Switch (C3U)</u>
S78	Turn Signal/Multifunction Switch	-	In the passenger compartment, on the left side of the upper steering column	<u>Steering Column Components</u>	• <u>S78 Turn Signal/Multifunction Switch X1</u> • <u>S78 Turn Signal/Multifunction Switch X2</u>
			In the		• <u>S79D Window</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

S79D	Window Switch - Driver	(without AXE)	passenger compartment, in the left front door armrest	<u>Driver Door Switches (without AXE)</u>	<u>Switch - Driver X1 (without AXE)</u> • <u>S79D Window Switch - Driver X2 (without AXE)</u>
S79LR	Window Switch - Left Rear	-	In the passenger compartment, in the left rear door armrest	<u>Left Rear Door</u>	<u>S79LR Window Switch - Left Rear</u>
S79P	Window Switch - Passenger	(without AXE)	In the passenger compartment, in the right front door armrest	<u>Passenger Door</u>	<u>S79P Window Switch - Passenger (without AXE)</u>
S79RR	Window Switch - Right Rear	-	In the passenger compartment, in the right rear door armrest	<u>Right Rear Door</u>	<u>S79RR Window Switch - Right Rear</u>
S84D	Door Switch Panel Control Module - Driver	(AXE)	In the passenger compartment, on the left front door, on the trim panel armrest	<u>Driver Door</u>	• <u>S84D Door Switch Panel Control Module - Driver X1 (AXE)</u> • <u>S84D Door Switch Panel Control Module - Driver X2 (AXE)</u> • <u>S84D Door Switch Panel Control Module - Driver X3 (AXE)</u> • <u>S84D Door Switch Panel Control Module - Driver X4 (AXE)</u> • <u>S84D Door Switch Panel Control Module - Driver X7 (AXE)</u>
					• <u>S84P Door Switch Panel Control Module - Passenger</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

S84P	Door Switch Panel Control Module - Passenger	(AXE)	In the passenger compartment, on the passenger door, on the trim panel armrest	<u>Passenger Door</u>	<u>X1 (AXE)</u> • <u>S84P Door Switch Panel Control Module - Passenger X2 (AXE)</u> • <u>S84P Door Switch Panel Control Module - Passenger X3 (AXE)</u> • <u>S84P Door Switch Panel Control Module - Passenger X4 (AXE)</u> • <u>S84P Door Switch Panel Control Module - Passenger X7 (AXE)</u>
T1	Accessory DC/AC Power Inverter Module	(KV1)	In the passenger compartment, in the left rear wheelhouse, behind the trim panel	<u>Left Rear of the Passenger Compartment</u>	<u>T1 Accessory DC/AC Power Inverter Module (KV1)</u>
T2	Antenna	(SPO Accessory)	In the passenger compartment, connected to the DVD control module	-	-
T3	Audio Amplifier	(UQA or UQS)	In the passenger compartment, behind the left side of the instrument panel	<u>Below the Driver Side of the Instrument Panel</u>	• <u>T3 Audio Amplifier X1 (UQA or UQS)</u> • <u>T3 Audio Amplifier X2 (UQA or UQS)</u> • <u>T3 Audio Amplifier X3 (UQA or UQS)</u>
T4M	Radio Antenna	-	Rear center of the outside of the roof	• <u>Rear of the Vehicle (X88)</u> • <u>Rear of the Vehicle (W49)</u> • <u>Rear of the</u>	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

				<u>Vehicle (Z88)</u>	
T4P	Navigation Antenna	(U4H or UUM or UUK)	In the passenger compartment, below the instrument panel defrost deflector, right side	<u>Right Side of the Upper Instrument Panel</u>	-
T4S	Wireless Communication Antenna - Bluetooth	(UPF)	In the passenger compartment, mounted to the VCIM, behind the left rear interior trim panel	<u>Left Rear of the Passenger Compartment</u>	-
T7L	Headlamp Ballast - Left	(Z88 with W49 or TVD)	Front left side of the vehicle, part of the headlamp assembly	-	<u>T7L Headlamp Ballast - Left (Z88 with TVD or W49)</u>
T7R	Headlamp Ballast - Right	(Z88 with W49 or TVD)	Front right side of the vehicle, part of the headlamp assembly	-	<u>T7R Headlamp Ballast - Right (Z88 with TVD or W49)</u>
T8A	Ignition Coil 1	-	In the engine compartment, on the top right of the rear valve cover	<u>Engine Components - Right Rear</u>	<u>T8A Ignition Coil 1</u>
T8B	Ignition Coil 2	-	In the engine compartment, on the top right of the front valve cover	<u>Engine Components - Front</u>	<u>T8B Ignition Coil 2</u>
T8C	Ignition Coil 3	-	In the engine compartment, on the top middle of the rear valve	<u>Engine Components - Right Rear</u>	<u>T8C Ignition Coil 3</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			cover		
T8D	Ignition Coil 4	-	In the engine compartment, on the top middle of the front valve cover	<u>Engine Components - Front</u>	<u>T8D Ignition Coil 4</u>
T8E	Ignition Coil 5	-	In the engine compartment, on the top left of the rear valve cover	<u>Engine Components - Right Rear</u>	<u>T8E Ignition Coil 5</u>
T8F	Ignition Coil 6	-	In the engine compartment, on the top left of the front valve cover	<u>Engine Components - Front</u>	<u>T8F Ignition Coil 6</u>
T9	Infrared Transmitter	(U42)	In the passenger compartment, in the center headliner console	<u>Headliner Components</u>	<u>T9 Infrared Transmitter (U42)</u>
T12	Automatic Transmission Assembly	-	In the engine compartment, left of the engine	-	-
X50A	Fuse Block - Underhood	-	In the engine compartment, above the right front wheel well	<u>Engine Components - Right Rear</u>	<u>Electrical Center Identification Views</u>
X51A	Fuse Block - Instrument Panel	-	In the passenger compartment, under the lower right side of the instrument panel	<u>Behind the Right Side of the Instrument Panel</u>	<u>Electrical Center Identification Views</u>
X55AF	Fuse Holder - Engine Control	-	In the passenger compartment, at right second seat, in the floor,	<u>Second Row Seat Area Floor</u>	<u>Electrical Center Identification Views</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

	Module		near the battery, on the positive battery cable		
X55B	Fuse Holder - Telematics	(UE1)	In the passenger compartment, at right second seat, in the floor, near the battery, on the positive battery cable	<u>Second Row Seat Area Floor</u>	<u>Electrical Center Identification Views</u>
X55J	Fuse Holder - Generator	-	Right front of engine compartment, near the generator, part of the generator positive battery cable	<u>Engine Components - Front</u>	<u>Electrical Center Identification Views</u>
X55K	Fuse Holder - Steering Column	N38	In the passenger compartment, on the steering column, part of the steering wheel air bag coil harness	-	<u>Electrical Center Identification Views</u>
X55X	Fuse Holder - Video Display	(SPO Accessory)	In the passenger compartment, approximately 30 cm (12 in) from the instrument panel fuse block	-	<u>Electrical Center Identification Views</u>
X80G	Accessory Power Receptacle - Instrument Panel	-	In the passenger compartment, on the front right of the	<u>Instrument Panel Components</u>	<u>X80G Accessory Power Receptacle - Instrument Panel</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			front floor console		
X80H	Accessory Power Receptacle - Center Console	-	In the passenger compartment, on the rear of the front floor console	<u>Console Components</u>	<u>X80H Accessory Power Receptacle - Center Console</u>
X80L	Accessory Power Receptacle - Rear Console	(DK1)	In the passenger compartment, on the second row seat rear floor console	-	<u>X80L Accessory Power Receptacle - Rear Console (DK1)</u>
X80R	Accessory Power Receptacle - Rear Compartment	-	In the passenger compartment, in the left rear interior body panel	<u>Trim Panel Components - Left Rear</u>	<u>X80R Accessory Power Receptacle - Rear Compartment (without DK1)</u>
X81	Accessory Power Receptacle - 110V AC	(KV1)	In the passenger compartment, at the rear of the front floor console	<u>Console Components</u>	• <u>X81 Accessory Power Receptacle - 110V AC X2 (KV1)</u> • <u>X81 Accessory Power Receptacle - 110V AC X1 (KV1)</u>
X82	Audio/Video Input Adapter	(U42)	In the passenger compartment, on the rear of the front floor console	<u>Below the Driver Side of the Instrument Panel</u>	• <u>T3 Audio Amplifier X1 (UQA or UQS)</u> • <u>T3 Audio Amplifier X2 (UQA or UQS)</u> • <u>T3 Audio Amplifier X3 (UQA or UQS)</u>
X83	Auxiliary Audio Input	(USR)	In the passenger compartment, inside the instrument panel center storage compartment	<u>Upper Instrument Panel Area</u>	-
X84	Data Link Connector	-	In the passenger compartment, below the steering	<u>Below the Left Knee Bolster</u>	<u>X84 Data Link Connector</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			column, bottom of the knee bolster		
X85	Steering Wheel Air Bag Coil	-	In the passenger compartment, top of the steering column, below the steering wheel	<u>Steering Column Components</u>	• <u>X85 Steering Wheel Air Bag Coil X1</u> • <u>X85 Steering Wheel Air Bag Coil X2</u> • <u>X85 Steering Wheel Air Bag Coil X3</u>
X88	Trailer Connector	-	Under the right rear corner of the body, at the bumper fascia	<u>Rear of the Vehicle (W49)</u>	<u>X88 Trailer Connector (V92)</u>
X100	Engine harness to body harness	-	In the engine compartment near the rear left corner of the underhood fuse block	<u>Engine Compartment Harness Routing</u>	<u>X100 Body Harness to Engine Harness</u>
X104	Cooling fan harness to the forward lamp harness	-	In the left front of the engine compartment behind the upper left corner of the radiator	-	<u>X104 Cooling Fan Harness to Forward Lamp Harness</u>
X110	Forward lamp harness to the left headlamp harness	(W49 without TSH or T26)	Outside left front of the vehicle behind the left headlamp	<u>Front Fascia Harness Routing (X88)</u>	<u>X110 Forward Lamp Harness to Left Headlamp Harness (W49 without TSH or T26)</u>
X110	Forward lamp harness to the left headlamp harness	(W49 with TSH or T26)	Outside left front of the vehicle behind the left headlamp	<u>Front Fascia Harness Routing (X88)</u>	<u>X110 Forward Lamp Harness to Left Headlamp Harness (W49 with TSH or T26)</u>
X110	Left headlamp harness to the forward lamp harness	(Z88 with TVD)	Outside left front of the vehicle behind the left headlamp	<u>Front Fascia Harness Routing (X88)</u>	<u>X110 Left Headlamp Harness to Forward Lamp Harness (Z88 with TVD)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

X110	Forward lamp harness to the left headlamp harness	(Z88 without TVD)	Outside left front of the vehicle behind the left headlamp	<u>Front Fascia Harness Routing (X88)</u>	<u>X110 Forward Lamp Harness to Left Headlamp Harness (Z88 without TVD)</u>
X110	Forward lamp harness to the left headlamp harness	(X88)	Outside left front of the vehicle behind the left headlamp	<u>Front Fascia Harness Routing (X88)</u>	<u>X110 Forward Lamp Harness to Left Headlamp Harness (X88)</u>
X111	Engine harness to the instrument panel harness	-	In the engine compartment inboard of the left front strut tower	<u>Engine Compartment Harness Routing</u>	<u>X111 Engine Harness to Instrument Panel Harness</u>
X112	Engine harness to the instrument panel harness	-	In the engine compartment inboard of the left front strut tower	-	<u>X112 Engine Harness to Instrument Panel Harness</u>
X113	Body harness to the forward lamp harness	-	In the engine compartment forward of the right front strut tower next to underhood fuse block	<u>Forward Lamp Harness Routing</u>	<u>X113 Body Harness to Forward Lamp Harness</u>
X115	Engine harness to the forward lamp harness	(TSH or T26)	In the engine compartment above the left cooling fan taped to the harness	<u>Engine Compartment Harness Routing</u>	<u>X115 Engine Harness to Forward Lamp Harness (TSH or T26)</u>
X120	Forward lamp harness to the right headlamp harness	(W49 without TSH or T26)	Outside right front of the vehicle behind the right headlamp	<u>Front Fascia Harness Routing (X88)</u>	<u>X120 Forward Lamp Harness to Right Headlamp Harness (W49 without TSH or T26)</u>
X120	Forward lamp harness to the right headlamp harness	(W49 with TSH or T26)	Outside right front of the vehicle behind the right headlamp	<u>Front Fascia Harness Routing (X88)</u>	<u>X120 Forward Lamp Harness to Right Headlamp Harness (W49 with TSH or T26)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

X120	Right headlamp harness to the forward lamp harness	(Z88 with TVD)	Outside right front of the vehicle behind the right headlamp	<u>Front Fascia Harness Routing (X88)</u>	<u>X120 Right Headlamp Harness to Forward Lamp Harness (Z88 with TVD)</u>
X120	Forward lamp harness to the right headlamp harness	(Z88 without TVD)	Outside right front of the vehicle behind the right headlamp	<u>Front Fascia Harness Routing (X88)</u>	<u>X120 Forward Lamp Harness to Right Headlamp Harness (Z88 without TVD)</u>
X120	Forward lamp harness to the right headlamp harness	(X88)	Outside right front of the vehicle behind the right headlamp	<u>Front Fascia Harness Routing (X88)</u>	<u>X120 Forward Lamp Harness to Right Headlamp Harness (X88)</u>
X122	Forward lamp harness to the right front park lamp harness	(X88)	Behind the front bumper fascia	<u>Front Fascia Harness Routing (X88)</u>	<u>X122 Right Park Lamp Harness to Forward Lamp Harness (X88 with T96)</u>
X123	Forward lamp harness to the left front park lamp harness	(X88)	Behind the front bumper fascia	<u>Front Fascia Harness Routing (X88)</u>	<u>X123 Left Park Lamp Harness to Forward Lamp Harness (X88 with T96)</u>
X160	Engine harness to the fuel injector harness	-	In the engine compartment rear left top of the engine	<u>Engine Compartment Harness Routing</u>	<u>X160 Engine Harness to Fuel Injector Bank 2 Harness</u>
X161	Engine harness to the fuel injector harness	-	In the engine compartment rear left top of the engine	<u>Engine Compartment Harness Routing</u>	<u>X161 Engine Harness to Fuel Injector Bank 1 Harness</u>
X200	Body harness to the instrument panel harness	-	In the passenger compartment behind the right front kick panel near X252	<u>Body Harness Routing - Front Passenger Compartment</u>	<u>X200 Body Harness to Instrument Panel Harness</u>
X201	Instrument panel harness to the steering column harness	-	In the passenger compartment below and left of the steering	<u>Body Harness Routing - Front Passenger Compartment</u>	<u>X201 Instrument Panel Harness to Steering Column Harness</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			column		
X202	Body harness to the instrument panel harness	-	In the passenger compartment near the floor at the front right of the floor console next to X340	<u>Body Harness Routing - Front Passenger Compartment</u>	<u>X202 Body Harness to Instrument Panel Harness</u>
X203	Body harness to the instrument panel harness	-	In the passenger compartment behind the far left side of the instrument panel behind the access panel	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	<u>X203 Body Harness to Instrument Panel Harness</u>
X205	Body harness to the instrument panel harness	-	In the passenger compartment under left side of the instrument panel	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	<u>X205 Body Harness to Instrument Panel Harness (N38)</u>
X209	Body harness to the trailer brake harness	-	In the passenger compartment under left side of the instrument panel taped to harness below the body control module	<u>Body Harness Routing - Front Passenger Compartment</u>	<u>X209 Trailer Brake Harness to Body Harness (V92)</u>
X211	Body harness to the steering column harness	-	In the passenger compartment below and left of the steering column right of the body control module	<u>Steering Column Harness Routing</u>	<u>X211 Body Harness to Steering Column Harness</u>
			In the		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

X212	Body harness to the passenger inflatable restraint module	-	passenger compartment under passenger kick panel	-	<u>X212 Body Harness to Passenger Inflatable Restraint Module Jumper</u>
X214	Instrument panel harness to the HVAC harness	-	In the passenger compartment behind right side of the instrument panel left of the instrument panel compartment	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	<u>X214 Instrument Panel Harness to HVAC Harness</u>
X216	Instrument panel harness to the headliner harness	-	In the passenger compartment under the left A-pillar trim	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	<u>X216 Instrument Panel Harness to Headliner Harness (U42)</u>
X240	Instrument panel harness to the floor console harness	-	In the passenger compartment front of the right center of the floor console next to X340	<u>Body Harness Routing - Front Passenger Compartment</u>	<u>X240 Instrument Panel Harness to Floor Console Harness</u>
X252	Body harness to the instrument panel harness	-	In the passenger compartment below the far right side of the instrument panel behind the right front kick panel next to X200	<u>Body Harness Routing - Front Passenger Compartment</u>	<u>X252 Instrument Panel Harness to Body Harness</u>
X295	Steering column harness to tilt/telescope motors harness	-	In the passenger compartment near the top of the steering column	<u>Steering Column Components</u>	<u>X295 Steering Column Harness to Tilt and Telescope Motors Harness (N38)</u>
			Left side of the passenger	<u>Body Harness</u>	

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

X305	Fuel tank harness to body harness	-	compartment on the floor under driver seat and carpet	<u>Routing - Front Passenger Compartment</u>	<u>X305 Fuel Tank Harness to Body Harness</u>
X308	Rear chassis harness to the fuel tank harness	-	Under the left rear of the vehicle rear of fuel tank	-	<u>X308 Rear Chassis Harness to Fuel Tank Harness</u>
X313	Body harness to the passenger seat harness	-	In the passenger compartment below the passenger seat	-	<u>X313 Body Harness to Passenger Seat Harness</u>
X314	Body harness to the passenger seat harness	-	In the passenger compartment below the passenger seat	<u>Passenger Seat Harness Routing</u>	<u>X314 Body Harness to Passenger Seat Harness</u>
X315	Body harness to the driver seat harness	-	In the passenger compartment below the driver seat	<u>Driver Seat Harness Routing (AG3)</u>	<u>X315 Body Harness to Driver Seat Harness</u>
X316	Body harness to the driver seat harness	-	In the passenger compartment below the driver seat	-	<u>X316 Body Harness to Driver Seat Harness</u>
X324	Battery negative cable harness to the body harness	-	In the passenger compartment below the right second seat floor near the battery	<u>Body Harness Routing - Front Passenger Compartment</u>	<u>X324 Battery Negative Cable Harness to Body Harness</u>
X325	Battery positive cable harness to the body harness	-	In the passenger compartment below the floor near the battery	<u>Body Harness Routing - Front Passenger Compartment</u>	<u>X325 Body Harness to Battery Positive Cable Harness (UE1)</u>
X332	Body harness to the passenger seat SIR	-	In the passenger compartment below the	<u>Passenger Seat Harness Routing</u>	<u>X332 Body Harness to Passenger Seat SIR</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

	jumper harness		passenger seat next to X314		<u>Jumper Harness</u>
X333	Body harness to the driver seat SIR jumper harness	-	In the passenger compartment below the driver seat next to X315	<u>Driver Seat Harness Routing (AG3)</u>	<u>X333 Body Harness to Driver Seat SIR Jumper Harness</u>
X340	Body harness to the floor console harness	-	In the passenger compartment forward of the floor console below the center of the instrument panel	<u>Front Floor Console Harness Routing</u>	<u>X340 Floor Console Harness to Body Harness</u>
X341	Floor console harness to the automatic transmission shifter harness	-	In the passenger compartment in the floor console at the right rear of the shifter	<u>Automatic Transmission Floor Shifter</u>	<u>X341 Floor Console Harness to Automatic Transmission Shifter Harness</u>
X343	Front overhead console harness to the headliner harness	-	In the passenger compartment above the front overhead console above front center of headliner	<u>Overhead Console Harness Routing</u>	<u>X343 Headliner Harness to Front Overhead Console Harness</u>
X370	Body harness to DVD power jumper harness	(SPO Accessory)	In the passenger compartment	-	<u>X370 Body Harness to DVD Power Jumper Harness (SPO Accessory)</u>
X371	Signal cable 3A to cable 1A	(SPO Accessory)	In the passenger compartment at the rear of the driver seat track	-	<u>X371 DVD Signal Cable 3A to DVD Signal Cable 1A (SPO Accessory)</u>
X372	Signal cable 3A to cable 2A	(SPO Accessory)	In the passenger compartment at the rear of	-	<u>X372 DVD Signal Cable 3B to DVD Signal Cable 1B (SPO Accessory)</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			the driver seat track		
X373	Signal cable 3B to cable 1B	(SPO Accessory)	In the passenger compartment at the rear of the passenger seat track	-	<u>X373 DVD Signal Cable 3A to DVD Signal Cable 2A (SPO Accessory)</u>
X374	Signal cable 3B to cable 2B	(SPO Accessory)	In the passenger compartment at the rear of the passenger seat track	-	<u>X374 DVD Signal Cable 3B to DVD Signal Cable 2B (SPO Accessory)</u>
X380	Accessory power outlet - rear console harness to the body harness	-	In the passenger compartment in the rear floor console	-	<u>X380 Rear Console Accessory Power Outlet Harness to Body Harness (DK1)</u>
X390	SPO heated seat body harness to floor console extension harness	(SPO Accessory)	In the front floor console	-	<u>X390 SPO Heated Seat Body Harness to Body Harness (SPO Accessory)</u>
X391	SPO heated seat body harness to SPO heated driver seat harness	(SPO Accessory)	Under the driver seat	-	<u>X391 SPO Heated Seat Body Harness to SPO Heated Driver Seat Harness (SPO Accessory)</u>
X392	SPO heated seat body harness to SPO heated passenger seat harness	(SPO Accessory)	Under the passenger seat	-	<u>X392 SPO Heated Seat Body Harness to SPO Heated Passenger Seat Harness (SPO Accessory)</u>
X393	SPO heated seat body harness to SPO heated driver seat harness	(SPO Accessory)	Under the driver seat	-	<u>X393 SPO Heated Seat Body Harness to SPO Heated Driver Seat Harness (SPO Accessory)</u>
X398	Headliner harness to the sunroof harness	-	Above the headliner at the passenger door opening	<u>Headlining Harness Routing</u>	<u>X398 Headliner Harness to Sunroof Harness (C3U)</u>
X405	Body harness to the rear chassis harness	-	At the rear left center of the floor forward of the liftgate opening	<u>Left Rear Passenger Compartment</u>	<u>X405 Rear Chassis Harness to Body Harness</u>
			Outside the		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

X410	Body harness to the left tail lamp harness	-	body behind the left tail lamp	<u>Tail Lamp Harness Routing (X88)</u>	<u>X410 Body Harness to Left Tail Lamp Harness (T89)</u>
X410	Body harness to the left tail lamp harness	(without T89)	Outside the body behind the left tail lamp	<u>Tail Lamp Harness Routing (X88)</u>	<u>X410 Body Harness to Left Tail Lamp Harness (without T89)</u>
X420	Body harness to the right tail lamp harness	-	Outside the body behind the right tail lamp	<u>Tail Lamp Harness Routing (X88)</u>	<u>X420 Body Harness to Right Tail Lamp Harness (T89)</u>
X420	Body harness to the right tail lamp harness	(without T89)	Outside the body behind the right tail lamp	<u>Tail Lamp Harness Routing (X88)</u>	<u>X420 Body Harness to Right Tail Lamp Harness (without T89)</u>
X421	Body harness to the headliner harness	-	In the passenger compartment on the lower left side of the right D-pillar below X422	<u>Body Harness Routing - Right Rear Passenger Compartment</u>	<u>X421 Body Harness to Headliner Harness</u>
X422	Body harness to the headliner harness	-	In the passenger compartment on the lower left side of the right D-pillar above X420	<u>Body Harness Routing - Right Rear Passenger Compartment</u>	<u>X422 Headliner Harness to Body Harness</u>
X440	Body harness to the rear bumper harness	(W49 with T79 or UD7)	Outside left rear of the vehicle below the left tail lamp behind the bumper fascia	<u>Rear Bumper Harness Routing</u>	<u>X440 Body Harness to Rear Bumper Harness</u>
X442	Body harness to the trailer harness	-	Outside the body behind the right side of the rear bumper fascia	<u>Body Harness Routing - Near Liftgate</u>	<u>X442 Body Harness to Trailer Harness (V92)</u>
X452	Rear HVAC harness	-	In the passenger compartment near the front middle of the	<u>Body Harness Routing - Right</u>	<u>X452 Rear HVAC</u>

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

	to the body harness		right D-pillar on the auxiliary blower motor	<u>Rear Passenger Compartment</u>	<u>Harness to Body Harness</u>
X500	Driver door harness to the body harness	-	At the left lower A-pillar between the door hinges	<u>Driver Door Harness Routing</u>	<u>X500 Driver Door Harness to Body Harness</u>
X553	Driver door trim panel harness to the driver door harness	-	Upper front of the door behind the trim panel above X555	<u>Driver Door Harness Routing</u>	<u>X553 Driver Door Trim Panel Harness to Driver Door Harness</u>
X555	Driver door trim panel harness to the driver door harness	-	Upper front of the door behind the trim panel below X553	<u>Driver Door Harness Routing</u>	<u>X555 Driver Door Trim Panel Harness to Driver Door Harness</u>
X600	Passenger door harness to the body harness	-	At the right lower A-pillar between the door hinges	<u>Passenger Door Harness Routing</u>	<u>X600 Passenger Door Harness to Body Harness</u>
X664	Passenger door trim panel harness to the passenger door harness	-	Upper front of the door behind the trim panel below X666	<u>Passenger Door Harness Routing</u>	<u>X664 Passenger Door Trim Panel Harness to Passenger Door Harness</u>
X666	Passenger door trim panel harness to the passenger door harness	-	Upper front of the door behind the trim panel above X664	<u>Passenger Door Harness Routing</u>	<u>X666 Passenger Door Trim Panel Harness to Passenger Door Harness</u>
X700	Left rear door harness to the body harness	-	At the left lower B-pillar between the door hinges	<u>Left Rear Door Harness Routing</u>	<u>X700 Left Rear Door Harness to Body Harness</u>
X800	Right rear door harness to the body harness	-	At the right lower B-pillar between the door hinges	<u>Right Rear Door Harness Routing</u>	<u>X800 Right Rear Door Harness to Body Harness</u>
X901	Body harness to the liftgate harness	-	Top right center of the liftgate opening next to X903	<u>Body Harness Routing - Near Liftgate</u>	<u>X901 Body Harness to Liftgate Harness</u>
			Top right		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

X902	Body harness to the liftgate harness	-	center of the liftgate opening next to X903	<u>Liftgate Harness Routing</u>	<u>X902 Body Harness to Liftgate Harness (UVC)</u>
X903	Body harness to the liftgate harness	-	Top right center of the liftgate opening next to X901	<u>Body Harness Routing - Near Liftgate</u>	<u>X903 Body Harness to Liftgate Harness</u>
X910	Liftgate harness to the liftgate applique harness	(W49 or Z88)	Behind the liftgate applique in center of liftgate	<u>Liftgate Harness Routing</u>	<u>X910 Liftgate Harness to Left Liftgate Tail Lamp Assembly Harness</u>
X911	Liftgate harness to the center high mounted stop lamp harness	-	Top left center of the liftgate opening	<u>Liftgate Harness Routing</u>	<u>X911 Center High Mounted Stop Lamp (CHMSL) Harness to Liftgate Harness</u>
X920	Liftgate harness to the liftgate applique harness	(W49 or Z88)	Behind the liftgate applique	<u>Liftgate Harness Routing</u>	<u>X920 Liftgate Harness to Right Liftgate Tail Lamp Assembly Harness</u>
X933	Liftgate harness to the license lamp harness	(W49 or Z88)	In the liftgate	<u>Liftgate Harness Routing</u>	<u>X933 License Lamp Harness to Liftgate Harness (Z88)</u>
X940	Liftgate harness to the liftgate trim panel harness	-	In the liftgate to courtesy lamps	<u>Liftgate Harness Routing</u>	<u>X940 Liftgate Harness to Liftgate Trim Panel Harness</u>
G101	(CKT 50) In the engine compartment	-	On the left frame rail near the left rear of the air cleaner above G115 below G103	<u>G101, G103, G105 and G115</u>	-
G102	(CKTs 250 and 1250) In the engine compartment	-	On the right inner fender panel near the right rear corner of the underhood fuse block	<u>G102 and G103</u>	-
G103	(CKT 1350) In the engine compartment	-	On the left inner fender panel above G101	<u>G102 and G103</u>	-
			And 1750		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

G105	(CKTs 1650	-	with XA7) In the engine compartment left of the brake booster rear of the fuel line bracket	<u>G101, G103, G105 and G115</u>	-
G110	(CKTs 451 and 1050) In the engine compartment	-	Right rear of engine mounted to the rear cylinder head	<u>G110, G112 and G115</u>	-
G112	(CKT 2550) In the engine compartment	-	Left rear of engine mounted to the rear cylinder head	<u>G110, G112 and G115</u>	-
G113	(CKT 50) In the engine compartment	-	At the front left edge of the front cylinder head	<u>G113 and G114</u>	-
G114	(CKT 2650) In the engine compartment	-	Front of the engine mounted to the front cylinder head between cylinders 4 and 6	<u>G113 and G114</u>	-
G115	(CKT 251) In the engine compartment	-	At the left inner fender panel forward of the strut tower below G101	<u>G110, G112 and G115</u>	-
G300	(CKT 351) In the passenger compartment	-	Near the base of the right A-pillar	<u>G300, G301, G302, G303, G304 and G305</u>	-
G301	(CKTs 1450 and 1551) In the passenger compartment	-	Near the base of the left A-pillar	<u>G300, G301, G302, G303, G304 and G305</u>	-
G302	(CKTs 450 and 750) In the passenger compartment	-	Near the base of the right B-pillar	<u>G300, G301, G302, G303, G304 and G305</u>	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

G303	(CKTs 550 and 1850) In the passenger compartment	-	Near the base of the left B-pillar	<u>G300, G301, G302, G303, G304 and G305</u>	-
G304	(CKT 1751) In the passenger compartment	-	Below the floor console	<u>G300, G301, G302, G303, G304 and G305</u>	-
G305	(CKT 50) In the passenger compartment	-	Right second seat floor near the battery on the side wall of the battery tray	<u>G300, G301, G302, G303, G304 and G305</u>	-
G401	(CKT 650) In the passenger compartment	-	Near the base of the left D-pillar	<u>G401</u>	-
G402	(CKT 850) In the passenger compartment	-	Above the right rear wheel house	<u>G402</u>	-
J104	Front Turn Signal Harness	(W49)	(CKT 1250) In the right front turn signal harness, near X108	<u>Fog Lamp Extension Harness Routing</u>	-
J104	Headlamp Assembly - Right Harness	(Z88)	In the right headlamp harness	<u>Fog Lamp Extension Harness Routing</u>	-
J106	Headlamp Assembly - Right Harness	(W49)	(CKT 1250) In the right headlamp harness	-	-
J112	Engine Harness	-	(CKT 2550) In the engine harness, near G112	<u>Engine Harness Splice Routing - Rear</u>	-
J113	Headlamp Assembly - Left Harness	(Z88)	In the left headlamp harness	<u>Fog Lamp Extension Harness Routing</u>	-
J115	Headlamp Assembly - Left Harness	(W49)	(CKT 1350) In the left headlamp harness	-	-
J117	Engine Harness	(TSH or T26)	(CKT 5986) In the engine	<u>Engine Harness Splice Routing -</u>	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			harness	<u>Rear</u>	
J120	Forward Lamp Harness	-	(CKT 1329) In the forward lamp harness, forward of the underhood fuse block	<u>Front Fascia Harness Routing (X88)</u>	-
J121	Forward Lamp Harness	-	(CKT 2501) In the forward lamp harness, near X150	<u>Forward Lamp Harness Routing</u>	-
J122	Forward Lamp Harness	(without W49 or TVD)	(CKT 712) In the forward lamp harness, forward and left of the underhood fuse block	<u>Front Fascia Harness Routing (X88)</u>	-
J122	Forward Lamp Harness	(W49 or Z88 without TVD)	(CKT 359) In the forward lamp harness, forward and left of the underhood fuse block	<u>Front Fascia Harness Routing (X88)</u>	-
J123	Forward Lamp Harness	-	(CKT 2500) In the forward lamp harness, near X150	<u>Forward Lamp Harness Routing</u>	-
J124	Forward Lamp Harness	-	(CKT 712) In the forward lamp harness, near X110	<u>Forward Lamp Harness Routing</u>	-
J125	Forward Lamp Harness	-	(CKT 309) In the forward lamp harness, near X120	<u>Forward Lamp Harness Routing</u>	-
J126	Forward Lamp Harness	(Z88)	(CKT 34) In the forward lamp harness, near underhood fuse block X1	<u>Forward Lamp Harness Routing</u>	-
J127	Automatic Transmission Harness	-	Inside the automatic transmission	-	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

J128	Forward Lamp Harness	-	(CKT 312) In the forward lamp harness, near X113	<u>Forward Lamp Harness Routing</u>	-
J131	Engine Harness	-	(CKT 5291) In the engine harness	<u>Engine Harness Splice Routing - Rear</u>	-
J132	Engine Harness	-	(CKT 439) In the engine harness, near the underhood fuse block	<u>Engine Harness Splice Routing - Rear</u>	-
J133	Engine Harness	-	(CKT 5292) In the engine harness	<u>Engine Harness Splice Routing - Rear</u>	-
J134	Engine Harness	-	(CKT 5290) In the engine harness, near the engine control module	<u>Engine Harness Splice Routing - Front</u>	-
J140	Engine Harness	-	(CKT 5293) In the engine harness, right top of the engine, near the bank 2 intake camshaft position sensor	<u>Engine Harness Splice Routing - Rear</u>	-
J141	Engine Harness	-	(CKT 705) In the engine harness	<u>Engine Harness Splice Routing - Rear</u>	-
J143	Engine Harness	-	(CKT 552) In the engine harness	<u>Engine Harness Splice Routing - Rear</u>	-
J144	Engine Harness	-	(CKT 2129) In the engine harness	<u>Engine Harness Splice Routing - Rear</u>	-
J145	Engine Harness	-	(CKT 2130) In the engine harness	-	-
			(CKT 1840) In the instrument		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

J202	Instrument Panel Harness	-	panel harness, right top of the instrument panel, behind the instrument panel air bag	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	-
J206	Instrument Panel Harness	(CJ2)	(CKT 61) In the instrument panel harness, right center top of the instrument panel, left of the instrument panel air bag	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	-
J208	Instrument Panel Harness	-	(CKT 4540) In the instrument panel harness, right center of the instrument panel, forward of the floor console	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	-
J211	Instrument Panel Harness	-	(CKT 1450) In the instrument panel harness, left center of the instrument panel, forward of the floor console	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	-
J213	Instrument Panel Harness	-	(CKT 1382) In the instrument panel harness, behind the instrument panel cluster	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	-
J214	Instrument Panel Harness	-	(CKT 1382) In the instrument panel harness	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	-
			(CKT 1551) In the	<u>Instrument Panel</u>	

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

J215	Instrument Panel Harness	-	instrument panel harness, left of the instrument panel cluster	<u>Harness Routing - Passenger Compartment</u>	-
J216	Instrument Panel Harness	-	(CKT 5986) In the instrument panel harness, near body control module X3	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	-
J219	Instrument Panel Harness	(U42 or UQS)	(CKT 7066) In the instrument panel harness, left top of the instrument panel near the outer left HVAC vent	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	-
J220	Instrument Panel Harness	-	(CKT 750) In the instrument panel harness, right top of the instrument panel, behind the instrument panel air bag	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	-
J221	Instrument Panel Harness	(B8K)	(CKT 690) In the instrument panel harness, in the left of the instrument panel, approximately 16.5 cm (6.5 in) from the body control module	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	-
J251	Instrument Panel Harness	-	(CKT 1551) In the instrument panel harness, between the data link	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			connector and the instrument panel cluster		
J253	Steering Column Harness	-	(CKT 1551) In the steering column harness, near X211	<u>Steering Column Harness Routing</u>	-
J260	HVAC Harness	-	(CKT 598) In the HVAC harness, near HVAC control module X3	-	-
J262	HVAC Harness	-	(CKT 1791) In the HVAC harness, near HVAC control module X3	-	-
J264	HVAC Harness	(CJ2)	(CKT 552) In the HVAC harness, near HVAC control module X3	-	-
J271	Steering Column Harness	-	(CKT 4) In the steering column harness, near X211	<u>Steering Column Harness Routing</u>	-
J273	Instrument Panel Harness	-	(CKT 1375) In the instrument panel harness, near X211	<u>Instrument Panel Harness Routing - Passenger Compartment</u>	-
J291	Steering Wheel Harness	(UK3)	(CKT 28) In the steering wheel harness	<u>Steering Wheel Harness Routing</u>	-
J293	Steering Column Harness	-	(CKT 1375) In the steering column harness, near the base of the steering column, over	<u>Steering Column Harness Routing</u>	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			the top		
J295	Steering Wheel Harness	(UK3)	(CKT 7005) In the steering wheel harness, near the left upper corner of the hub	<u>Steering Wheel Harness Routing</u>	-
J297	Steering Wheel Harness	-	(CKT 1551) In the steering wheel harness, near the right upper corner of the hub	<u>Steering Wheel Harness Routing</u>	-
J302	Body Harness	-	(CKT 1382) In the body harness, approximately 5.0 cm (2.0 in) from the Speaker - Left Front Tweeter towards X205	<u>Body Harness Routing - Front Passenger Compartment</u>	-
J304	Body Harness	-	(CKT 294) In the body harness, right side of the vehicle, near the front of the passenger door opening	<u>Body Harness Routing - Front Passenger Compartment</u>	-
J308	Body Harness	-	(CKT 295) In the body harness, right side of the vehicle, at the front of the passenger door opening	<u>Body Harness Routing - Front Passenger Compartment</u>	-
J311	Body Harness	-	(CKT 8) In the body harness, in the left A-pillar, approximately 5.0 cm (2.0	<u>Body Harness Routing - Front Passenger Compartment</u>	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			in) from the takeout to X500		
J313	Body Harness	-	(CKT 43) In the body harness, left side of the vehicle, near the front of the driver door opening	<u>Body Harness Routing - Front Passenger Compartment</u>	-
J315	Body Harness	(without X88)	(CKT 2283) In the body harness, left side of the vehicle, at the front of the driver door opening	<u>Body Harness Routing - Front Passenger Compartment</u>	-
J319	Body Harness	-	(CKT 690) In the body harness, right side of the vehicle, at the rear of the passenger door opening	<u>Body Harness Routing - Front Passenger Compartment</u>	-
J320	Body Harness	-	(CKT 24) In the body harness, near X322	<u>Body Harness Routing - Front Passenger Compartment</u>	-
J321	Body Harness	(DD8 or UVC)	(CKT 38) In the body harness, left side of the vehicle, at approximately the center of the driver door opening	<u>Body Harness Routing - Front Passenger Compartment</u>	-
J322	Body Harness	-	(CKT 1340) In the body harness, right side of the vehicle, at approximately	-	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			the center of the passenger door opening		
J323	Body Harness	-	(CKT 1314) In the body harness, left side of the vehicle, at approximately the center of the driver door opening	<u>Body Harness Routing - Front Passenger Compartment</u>	-
J324	Body Harness	-	(CKT 1315) In the body harness, right side of the vehicle, at approximately the center of the passenger door opening	-	-
J325	Body Harness	(KB6)	(CKT 640) In the body harness, right side of the vehicle, at approximately the center of the passenger door opening	<u>Body Harness Routing - Front Passenger Compartment</u>	-
J326	Headliner Harness	-	(CKT 850) In the headliner harness, over the center of the rear right door opening	<u>Headlining Harness Routing</u>	-
J328	Overhead Console Harness	-	(CKT 850) In the overhead console harness, near the front left corner of the overhead console	<u>Overhead Console Harness Routing</u>	-
			(CKT 709) In the body		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

J333	Body Harness	-	harness, at the floor, near the lower rear corner of the driver door opening	<u>Body Harness Routing - Front Passenger Compartment</u>	-
J337	Body Harness	(DK1)	(CKT 140) In the body harness, below the floor console	-	-
J339	Headliner Harness	-	(CKT 690) In the headliner harness, over the rear of the rear right door opening	<u>Headlining Harness Routing</u>	-
J342	Passenger Seat Harness	(KA1)	(CKT 2479) In the passenger seat harness, near the front left corner of the seat adjuster	<u>Passenger Seat Harness Routing</u>	-
J344	Passenger Seat Harness	(AAQ or KB6)	(CKT 750) In the passenger seat harness, near the rear center of the seat adjuster	<u>Passenger Seat Harness Routing</u>	-
J346	Passenger Seat Harness	(AAQ)	(CKT 3040) In the passenger seat harness, near the right side center of the seat adjuster	<u>Passenger Seat Harness Routing</u>	-
J347	Passenger Seat Harness	(KB6)	(CKT 640) In the passenger seat harness	<u>Passenger Seat Harness Routing</u>	-
J348	Headliner Harness	-	(CKT 1732) In the headliner harness, over the center of the front left	<u>Headlining Harness Routing</u>	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			door opening		
J349	Passenger Seat Harness	(KB6)	(CKT 5961) In the passenger seat harness	<u>Passenger Seat Harness Routing</u>	-
J350	Driver Seat Harness	(AG3)	(CKT 6207) In the driver seat harness, near the rear left corner of the seat adjuster	<u>Driver Seat Harness Routing (AG3)</u>	-
J353	Driver Seat Harness	(KA1)	(CKT 2432) In the driver seat harness, near the front left of the seat adjuster	<u>Driver Seat Harness Routing (AG3)</u>	-
J354	Driver Seat Harness	(AG3)	(CKT 6202) In the driver seat harness, near the rear center right of the seat adjuster	<u>Driver Seat Harness Routing (AG3)</u>	-
J355	Driver Seat Harness	(AG3 or AH5)	(CKT 1140) In the driver seat harness, near the rear left corner of the seat adjuster	<u>Driver Seat Harness Routing (AG3)</u>	-
J357	Driver Seat Harness	(KA1 without KB6)	(CKT 550) In the driver seat harness, near the rear left corner of the seat adjuster	<u>Driver Seat Harness Routing (AG3)</u>	-
J357	Driver Seat Harness	(KA1 or KB6)	(CKT 550) In the driver seat harness, near the front right corner of the seat adjuster	<u>Driver Seat Harness Routing (AG3)</u>	-
J358	Driver Seat Harness	(KB6)	(CKT 640) In the driver seat	<u>Driver Seat Harness Routing</u>	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			harness	<u>(AG3)</u>	
J359	Driver Seat Harness	(KB6)	(CKT 181) In the driver seat harness	<u>Driver Seat Harness Routing (AG3)</u>	-
J360	Sunroof Harness	(C3U)	(CKT 3440) In the sunroof harness	-	-
J364	Overhead Console Harness	(C3U)	(CKT 8) In the overhead console harness, near the front right corner of the overhead console	<u>Overhead Console Harness Routing</u>	-
J368	Sunroof Harness	(C3U)	(CKT 850) In the sunroof harness	-	-
J371	Floor Console Harness	(without KA1 or ULD)	(CKT 1382) In the floor console harness, forward and right of the A/T shifter	<u>Front Floor Console Harness Routing</u>	-
J375	Floor Console Harness	-	(CKT 750) In the floor console harness, right of the A/T shifter	<u>Front Floor Console Harness Routing</u>	-
J377	Floor Console Harness	-	(CKT 750) In the floor console harness, near the right middle rear of the floor console	<u>Front Floor Console Harness Routing</u>	-
J379	Floor Console Harness	(without ULD)	(CKT 8) In the floor console harness, near the right upper rear corner of the	<u>Front Floor Console Harness Routing</u>	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

			floor console		
J380	Floor Console Harness	(SPO Accessory)	(CKT 739) In the floor console harness, approximately 8 cm (3 in) from the digital video disc relay	-	-
J381	Body Harness	(W49 with T89)	(CKT 1320) In the body harness	-	-
J382	Floor Console Harness	(SPO Accessory)	(CKT 150) In the floor console harness, approximately 10 cm (4 in) from the digital video disc relay	-	-
J383	Body Harness	(W49 with T89)	(CKT 122) In the body harness	-	-
J385	SPO Heated Driver Seat Harness	(SPO Accessory)	(CKT 2432) In the SPO heated driver seat harness	-	-
J386	SPO Heated Passenger Seat Harness	(SPO Accessory)	(CKT 2479) In the SPO heated passenger seat harness	-	-
J387	SPO Body Harness	(SPO Accessory)	(CKT 550) In the SPO body harness	-	-
J388	SPO Body Harness	(SPO Accessory)	(CKT 1382) In the SPO body harness	-	-
J389	SPO Body Harness	(SPO Accessory)	(CKT 6816) In the SPO body harness	-	-
J390	Body Harness	-	(CKT 300) In the body harness	-	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

J395	Fuel Tank Harness	-	(CKT 2759) In the fuel tank harness, near X305	-	-
J404	Rear Bumper Harness	(UD7)	(CKT 1340) In the rear bumper harness, near X440	<u>Rear Bumper Harness Routing</u>	-
J405	Rear Chassis Harness	(MH6)	(CKT 5986) In the rear chassis harness	-	-
J409	Rear Bumper Harness	(UD7)	(CKT 650) In the rear bumper harness, near X440	<u>Rear Bumper Harness Routing</u>	-
J440	Rear Bumper Harness	(UD7)	(CKT 2374) In the rear bumper harness, below the left center of the liftgate opening	<u>Rear Bumper Harness Routing</u>	-
J444	Rear Bumper Harness	(UD7)	(CKT 2379) In the rear bumper harness, below the center of the liftgate opening	<u>Rear Bumper Harness Routing</u>	-
J455	Rear Chassis Harness	-	(CKT 7444) In the rear chassis harness, near the fuel pump flow control module	-	-
J457	Rear Chassis Harness	-	(CKT 7444) In the rear chassis harness, near X308	-	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

J459	Fuel Tank Harness	-	(CKT 7444) In the fuel tank harness, near X308	-	-
J488	Rear Bumper Harness	(W49 or X88)	(CKT 850) In the rear bumper harness	<u>Tail Lamp Harness Routing (X88)</u>	-
J490	Rear Bumper Harness	(W49 or X88)	(CKT 309) In the rear bumper harness	<u>Tail Lamp Harness Routing (X88)</u>	-
J493	Rear Bumper Harness	(W49 or X88)	(CKT 650) In the rear bumper harness	<u>Tail Lamp Harness Routing (X88)</u>	-
J495	Rear Bumper Harness	(W49 or X88)	(CKT 709) In the rear bumper harness	<u>Tail Lamp Harness Routing (X88)</u>	-
J497	Rear Bumper Harness	(X88)	(CKT 650) In the rear bumper harness	-	-
J499	Rear Bumper Harness	(X88)	(CKT 709) In the rear bumper harness	-	-
J555	Driver Door Harness	-	(CKT 550) In the driver door harness, near X500	<u>Driver Door Harness Routing</u>	-
J575	Driver Door Trim Harness	-	(CKT 550) In the driver door trim harness, near X555	<u>Driver Door Harness Routing</u>	-
J577	Driver Door Trim Harness	(without AXE)	(CKT 8) In the driver door trim harness, near X555	<u>Driver Door Harness Routing</u>	-
J595	Driver Mirror Harness	(DNP)	(CKT 672) In the driver mirror harness	-	-

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

J597	Driver Mirror Harness	(DNP)	(CKT 673) In the driver mirror harness	-	-
J600	Passenger Door Harness	(without AXE)	(CKT 750) In the passenger door harness, near X600	<u>Passenger Door Harness Routing</u>	-
J602	Passenger Door Harness	-	(CKT 750) In the passenger door harness, near X666	<u>Passenger Door Harness Routing</u>	-
J662	Passenger Mirror Harness	(DNP)	(CKT 674) In the passenger mirror harness	-	-
J664	Passenger Mirror Harness	(DNP)	(CKT 675) In the passenger mirror harness	-	-
J666	Passenger Door Trim Harness	(without AXE)	(CKT 8) In the passenger door trim harness, near the switches	<u>Passenger Door Harness Routing</u>	-
J711	Left Rear Door Harness	-	(CKT 550) In the left rear door harness, near X700	<u>Left Rear Door Harness Routing</u>	-
J800	Right Rear Door Harness	-	(CKT 750) In the right rear door harness, near X800	<u>Right Rear Door Harness Routing</u>	-
J903	Liftgate Harness	(Z88)	(CKT 24) In the liftgate harness, middle right of the liftgate	<u>Liftgate Harness Routing</u>	-
J905	Liftgate Harness	(TB5)	(CKT 6113) In the liftgate harness, right of the liftgate latch assembly	<u>Liftgate Harness Routing</u>	-
			(CKT 5801) In the liftgate		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

J907	Liftgate Harness	(TB5)	harness, right of the liftgate latch assembly	<u>Liftgate Harness Routing</u>	-
J911	Liftgate Harness	(W49 or Z88)	(CKT 709) In the liftgate harness, between the breakouts for the interior and exterior liftgate switches	<u>Liftgate Harness Routing</u>	-
J913	Liftgate Harness	-	(CKT 650) In the liftgate harness, middle right center of the liftgate	<u>Liftgate Harness Routing</u>	-
J915	Liftgate Harness	-	(CKT 650) In the liftgate harness, between the breakouts for the interior and exterior liftgate switches	<u>Liftgate Harness Routing</u>	-
J917	Liftgate Tail Lamp Assembly - Right	(Z88)	(CKT 650) In the liftgate applique harness	-	-
J919	Liftgate Tail Lamp Assembly - Left	(Z88)	(CKT 650) In the liftgate applique harness	-	-
J933	License Lamp Harness	(Z88)	In the license lamp harness	-	-
J935	License Lamp Harness	(Z88)	In the license lamp harness, between X933 and the pass-through	-	-
			In the passenger compartment,		

2014 GMC Acadia Denali

2014 ELECTRICAL Wiring Systems and Power Management - Component Locator - Master Electrical Component List - Acadia, Enclave And Traverse

JX205	Body Harness	-	behind the left side instrument panel, behind the headlamp switch, taped to harness	<u>Body Harness Routing - Front Passenger Compartment</u>	<u>JX205</u>
JX405	Body Harness	-	In the passenger compartment, taped to the body harness, forward of the left D-pillar, midway between the floor and window, behind the trim panel	<u>Left Rear Passenger Compartment</u>	<u>JX405</u>