

List of components

2/30	X feed overload relay	16/36	TV receiver
2/52	Relay, 15l feed, rear	16/81A	TV display, LH head restraint
2/84	Relay, electrically heated left-hand rear seat	16/81B	TV display, RH head restraint
2/85	Relay, electrically heated right-hand rear seat	16/82	DVD player rear
		16/83	Voice Guide Amplifier module VGA
3/64	Electrically heated rear seat switch	16/122	Rear Audio Separation module (RAS)
3/104	Sun blind switch	16/123	External equipment outlet AUX
		16/124	Rear Seat Entertainment module (RSE)
		16/125	IR transmitter
4/55	Sun blind control module		
6/74	Window antenna amplifier 2	17/21	12V outlet, rear seat
8/80	Control module M2D	31/10	Ground connection
		31/48	Ground connection
9/8	Seat heating element left-hand rear seat	31/53	Ground connection
9/9	Back support heating element left-hand rear seat	31/72	Ground connection
		31/93	Ground connection
9/10	Seat heating element right-hand rear seat	54/33	Connector
9/11	Back support heating element right-hand rear seat	54/36	Connector
		54/272A	Connector
9/14	Electrically heated right-hand rear seat	54/272B	Connector
9/15	Electrically heated left-hand rear seat	54/274	Connector
9/24	Coolbox rear seat	54/275	Connector
9/25	12V outlet, rear seat		