

Table of Contents

Vehicles with SRS (Airbag)/SIPS bag/IC (Inflatable curtain)	2
Abbreviations	4
How to use the wiring diagram 1:2	5
Electrical distribution 1:2	7

Fuses

Fuses by the battery	9
Fuses in auxiliary fuse box	10

Relays

Relays in the cargo compartment	11
---------------------------------------	----

Ground connections

31/10 - 31/93	12
---------------------	----

Group 36 Additional electrical equipment

12 V outlet	13
-------------------	----

Group 39 Other, Accessories

Rear Seat Entertainment (RSE)	14
Electrically heated rear seat	15

Group 87 Climate control system

Coolbox rear seat	16
-------------------------	----

Group 88 Internal equipment

Switch, sun blind	17
-------------------------	----

Connectors

54/33 - 54/64	18
54/73 - 54/272B	19
54/274	20
54/275 - 54/276	21
54/277 - 54/305	22

Junction points

53/550 - 53/726	23
53/737 - 53/738	24

Cable harness routing in vehicle

Rear Seat Entertainment (RSE) harness	25
Rear seat harness	26

Component illustrations

2/30 - 9/8	27
9/9 - 16/83	28
16/122 - 31/93	29
54/33 - 54/275B	30

Index

List of components