


## 2017 ELECTRICAL

### Wiring Systems and Power Management - Component Locator - Luggage Compartment/Rear of Vehicle Component Views - Impala

## LUGGAGE COMPARTMENT/REAR OF VEHICLE COMPONENT VIEWS

### LEFT SIDE OF LUGGAGE COMPARTMENT COMPONENTS




**Fig. 1: Left Side of Luggage Compartment Components**

Courtesy of GENERAL MOTORS COMPANY

#### Items

- 1: K182 Parking Assist Control Module **K182 Parking Assist Control Module X1 K182 Parking Assist Control Module X2**
- 2: T10E Keyless Entry Antenna - Rear Compartment (BTM) **T10E Keyless Entry Antenna - Rear Compartment**
- 3: T10G Keyless Entry Antenna - Rear Fascia (ATH) **T10G Keyless Entry Antenna - Rear Fascia**

### RIGHT SIDE OF LUGGAGE COMPARTMENT COMPONENTS



**Fig. 2: Right Side of Luggage Compartment Components**  
 Courtesy of GENERAL MOTORS COMPANY

#### Items


- 1: P19AJ Speaker - Left Rear Window Shelf (UQS) **P19AJ Speaker - Left Rear Window Shelf**
- 2: T4G Cellular Phone, Navigation, and Digital Radio Antenna (IO6, U2K, U2M or UE1) **T4G Cellular Phone, Navigation, and Digital Radio Antenna X1 T4G Cellular Phone, Navigation, and Digital Radio Antenna X2 T4G Cellular Phone, Navigation, and Digital Radio Antenna X3 (IO6 without MAM or UE1) T4G Cellular Phone, Navigation, and Digital Radio Antenna X3 (UE1 with MAM) T4G Cellular Phone, Navigation, and Digital Radio Antenna X4**
- 3: K77 Remote Control Door Lock Receiver **K77 Remote Control Door Lock Receiver X1 K77 Remote Control Door Lock Receiver X2**
- 4: K73 Telematics Communication Interface Control Module (UE1) **K73 Telematics Communication Interface Control Module X1 K73 Telematics Communication Interface Control Module X2 K73 Telematics Communication Interface Control Module X5 K73 Telematics Communication Interface Control Module X6 K73 Telematics Communication Interface Control Module X7 K73 Telematics Communication Interface Control Module X8 K73 Telematics Communication Interface Control Module X9**
- 5: T23 Radio Antenna Amplifier **T23 Radio Antenna Amplifier X1 T23 Radio Antenna Amplifier X4**
- 6: P19AK Speaker - Right Rear Window Shelf (UQS) **P19AK Speaker - Right Rear Window Shelf**
- 7: T15 Navigation Antenna Signal Splitter (IO6 with UE1) **T15 Navigation Antenna Signal Splitter X1 T15 Navigation Antenna Signal Splitter X2 T15 Navigation Antenna Signal Splitter X3**
- 8: K38 Chassis Control Module **K38 Chassis Control Module**

#### Items

9: T3 Audio Amplifier [T3 Audio Amplifier X1 \(UQG\)](#) [T3 Audio Amplifier X1 \(UQS\)](#) [T3 Audio Amplifier X2](#) [T3 Audio Amplifier X3](#) [T3 Audio Amplifier X4](#)

10: K18 Compass Module (U80 without UE1) [K18 Compass Module](#)

### CNG FUEL TANK COMPONENTS (FHV)



**Fig. 3: CNG Fuel Tank Components (FHV)**


Courtesy of GENERAL MOTORS COMPANY

#### Items

1: B263 Alternative Fuel Tank Temperature Sensor (FHV) [B263 Alternative Fuel Tank Temperature Sensor](#) [B263 Alternative Fuel Tank Temperature Sensor \(LFR\)](#)

2: Q68A CNG Cut-Off Solenoid Valve 1 (FHV) [Q68A CNG Cut-Off Solenoid Valve 1 \(LFR\)](#)

### REAR OF VEHICLE COMPONENTS




**Fig. 4: Rear of Vehicle Components**

Courtesy of GENERAL MOTORS COMPANY

#### Items

- 1: E5E Tail Lamp - Left **E5E Tail Lamp - Left**
- 2: T4G Cellular Phone, Navigation, and Digital Radio Antenna (IO6, U2K, U2M or UE1) **T4G Cellular Phone, Navigation, and Digital Radio Antenna X1 T4G Cellular Phone, Navigation, and Digital Radio Antenna X2 T4G Cellular Phone, Navigation, and Digital Radio Antenna X3 (IO6 without MAM or UE1) T4G Cellular Phone, Navigation, and Digital Radio Antenna X3 (UE1 with MAM) T4G Cellular Phone, Navigation, and Digital Radio Antenna X4**
- 3: E6 Center High Mounted Stop Lamp **E6 Center High Mounted Stop Lamp**
- 4: E5F Tail Lamp - Right **E5F Tail Lamp - Right**
- 5: E42R Tail Lamp Assembly - Right
- 6: E5T Tail/Stop and Turn Signal Lamp - Right **E5T Tail/Stop and Turn Signal Lamp - Right**
- 7: E5B Backup Lamp - Right **E5B Backup Lamp - Right**
- 8: B306H Parking Assist Sensor - Rear Right Outer (UD7) **B306H Parking Assist Sensor - Rear Right Outer**
- 9: B306G Parking Assist Sensor - Rear Right Middle (UD7) **B306G Parking Assist Sensor - Rear Right Middle**
- 10: E7R License Plate Lamp - Right **E7R License Plate Lamp - Right**
- 11: B87 Rearview Camera (UVC) **B87 Rearview Camera**
- 12: E7L License Plate Lamp - Left **E7L License Plate Lamp - Left**
- 13: B306F Parking Assist Sensor - Rear Left Middle (UD7) **B306F Parking Assist Sensor - Rear Left Middle**
- 14: B306E Parking Assist Sensor - Rear Left Outer (UD7) **B306E Parking Assist Sensor - Rear Left Outer**
- 15: E42L Tail Lamp Assembly - Left
- 16: E5A Backup Lamp - Left **E5A Backup Lamp - Left**
- 17: E5S Tail/Stop and Turn Signal Lamp - Left **E5S Tail/Stop and Turn Signal Lamp - Left**

## INSIDE OF REAR COMPARTMENT LID COMPONENTS




**Fig. 5: Inside of Rear Compartment Lid Components**

Courtesy of GENERAL MOTORS COMPANY

| Items                                                                            |
|----------------------------------------------------------------------------------|
| 1: E5F Tail Lamp - Right <a href="#">E5F Tail Lamp - Right</a>                   |
| 2: E5E Tail Lamp - Left <a href="#">E5E Tail Lamp - Left</a>                     |
| 3: M40 Rear Compartment Lid Latch <a href="#">M40 Rear Compartment Lid Latch</a> |

## SIDE OBJECT SENSOR MODULES (UFG OR UFT)



**Fig. 6: Side Object Sensor Modules (UFG or UFT)**

Courtesy of GENERAL MOTORS COMPANY

| Items                                                                                                           |
|-----------------------------------------------------------------------------------------------------------------|
| 1: B218R Side Object Sensor Module - Right (UFG or UFT) <a href="#">B218R Side Object Sensor Module - Right</a> |
| 2: B218L Side Object Sensor Module - Left (UFG or UFT) <a href="#">B218L Side Object Sensor Module - Left</a>   |

