

SECTION 3


WIRING DIAGRAM FOR POWER SUPPLIES

CONTENTS

1.	IGNITION SWITCH CIRCUIT	3-2
2.	30 TER "BAT+" POWER SUPPLY CIRCUIT(I.P FUSE BLOCK)	3-2
3.	15 TER "IGN 1" POWER SUPPLY CIRCUIT(I.P FUSE BLOCK)	3-3
4.	15A TER "IGN2", 15C TER "ACC" POWER SUPPLY CIRCUIT(I.P FUSE BLOCK)	3-4
5.	ENGINE FUSE BLOCK & RELAY CIRCUIT	3-5




J3B13002




J3B13003

3. 15 TER "IGN1" POWER SUPPLY CIRCUIT (I.P FUSE BLOCK)




J3D13001




J3D13002

4. 15A TER "IGN2", 15C TER "ACC" POWER SUPPLY CIRCUIT (I.P FUSE BLOCK)





J3D13003

5. ENGINE FUSE BLOCK & RELAY CIRCUIT





3-6 WIRING DIAGRAM FOR POWER SUPPLIES





3-8 WIRING DIAGRAM FOR POWER SUPPLIES





3-10 WIRING DIAGRAM FOR POWER SUPPLIES

(Sirius D4)

