



SECTION 1D**ENGINE (ENGINE COOLING)**


141. RADIATOR	1D – 3
143. COOLING FAN	1D – 5
145. RADIATOR HOSE & PIPE	1D – 7
148. THERMOSTAT	1D – 9



ENGINE COOLING – RADIATOR (141)					
NO.	OPERATION DESCRIPTION	OPERATION CODE	MODEL		
			S	N	L
1	COCK OR PLUG, RADIATOR DRAIN – REPLACE	1410300	0.4	0.6	0.6
2	RADIATOR ASSEMBLY – REPLACE	1410500	0.8	1.1	1.1
	A – With automatic transaxle	141050A	0.1	0.1	0.1
	COOLING SYSTEM – FLUSH	1411700	0.8	0.8	0.8




ENGINE COOLING – COOLING FAN (143)					
NO.	OPERATION DESCRIPTION	OPERATION CODE	MODEL		
			S	N	L
1	SUPPORT, RADIATOR (UPPER) – REPLACE	1430300	0.2	0.2	0.2
2	DEFLECTOR AND/OR SEAL, RADIATOR (LOWER) – REPLACE	1430500	0.3	0.4	0.3
3	SHROUD, RADIATOR FAN (ONE PIECE) – REPLACE	1430700	0.4	0.4	0.4
	A – Shroud, radiator fan (All)	143070A	0.1	0.1	—
4	MOTOR AND/OR BLADE, ELECTRIC COOLING FAN – REPLACE				
		Right 1431100	0.4	0.4	0.4
		Left 1431200	0.4	0.4	—
		Both 1431300	0.5	0.5	—



ENGINE COOLING – RADIATOR HOSE & PIPE (145)

NO.	OPERATION DESCRIPTION	OPERATION CODE	MODEL		
			S	N	L
1	TUBE, OVERFLOW – REPLACE	1450300	0.2	0.2	0.2
2	RESERVOIR, RADIATOR COOLANT – REPLACE	1450400	0.4	0.4	0.4
3	CLAMP, RADIATOR HOSE – REPLACE A – Replace each additional	1450500	0.4	0.8	0.8
		145050A	0.1	0.1	0.1
4	HOSE, UPPER ENGINE COOLANT – REPLACE	1450700	0.4	0.6	0.6
	HOSE, LOWER ENGINE COOLANT – REPLACE	1450800	0.4	0.8	0.8
	HOSE, BOTH ENGINE COOLANT – REPLACE	1450900	0.5	1.0	1.0
	HOSE, COOLANT (PIPE TO PUMP) – REPLACE	1451100	0.7	0.7	0.6
	HOSE, COOLANT (PIPE TO RESERVOIR) – REPLACE	1451200	0.4	0.4	0.4
	PIPE, COOLANT – REPLACE	1452100	0.9	0.9	0.9
5	HOSES, INLET HEATER – REPLACE	1453100	0.5	0.5	0.5
	HOSES, OUTLET HEATER – REPLACE	1453200	0.5	0.5	0.5
	HOSES, ALL HEATER – REPLACE	1453300	0.6	0.6	0.6
6	CAP, RADIATOR – REPLACE	1454100	0.2	0.2	0.2
7	PIPE, RADIATOR PUMP – REPLACE	1454300	0.9	0.9	0.9
8	DISTRIBUTOR, WATER – REPLACE	1454500	0.5	0.5	—
9	HOSE, THROTTLE BODY – REPLACE	1454700	0.4	0.4	0.4



ENGINE COOLING – THERMOSTAT (148)

NO.	OPERATION DESCRIPTION	OPERATION CODE	MODEL		
			S	N	L
1	THERMOSTAT, OUTLET AND/OR GASKET – REPLACE				
		SOHC 1480300	2.4	—	—
		DOHC 1480500	0.3	0.3	0.5
2	HOUSING, THERMOSTAT – REPLACE				
		SOHC 1480700	2.4	—	—
		DOHC 1480900	0.3	0.3	0.4