


SECTION 9A

BODY & ACCESSORIES (BODY WIRING SYSTEM)

911. WIRING HARNESS	9A - 3
---------------------------	--------



BODY WIRING SYSTEM – WIRING HARNESS (911)					
NO.	OPERATION DESCRIPTION	OPERATION CODE	MODEL		
			S	N	L
1	CABLES, BATTERY – REPLACE Battery to Alternator Negative	9110100	0.8	0.6	0.6
		9110300	0.5	0.5	—
2	WIRING, FLOOR – REPLACE	9110500	2.6	4.2	4.7
3	WIRING, INST PANEL – REPLACE	9110700	2.2	3.2	3.2
4	WIRING, ROOF – REPLACE	9110900	1.3	1.7	1.3
5	WIRING, ABS – REPLACE	9111100	4.0	0.6	0.6
6	WIRING, FRONT – REPLACE	9111300	2.6	1.7	1.2
7	WIRING, FRONT BUMPER – REPLACE	9111500	1.3	—	1.2
8	WIRING, REAR – REPLACE	9111700	0.4	0.6	0.4
9	WIRING, TRUNK LID – REPLACE	9112100	0.5	0.5	0.7
10	WIRING, FRONT DOOR – REPLACE	9112300	0.5	0.9	1.1
11	WIRING, REAR DOOR – REPLACE	9112500	0.5	0.9	0.8
12	WIRING, ECM & ABS – REPLACE	9112700	2.6	—	—
13	WIRING, ENGINE CONTROL – REPLACE	9112900	1.2	1.4	2.5
14	WIRING, FUEL PUMP – REPLACE	9113100	0.5	0.5	0.5
15	WIRING, REAR ABS – REPLACE	9113300	0.3	0.3	0.3
16	WIRING, AIRBAG – REPLACE	9113400	1.3	1.4	—