

SECTION 9

BODY & ACCESSORIES

BODY WIRING SYSTEM	9A – 1
LIGHTING SYSTEM	9B – 1
WIPER / WASHER SYSTEM	9D – 1
INST. DRIVER SYSTEM	9E – 1
AUDIO SYSTEM	9F – 1
INTERIOR TRIM	9G – 1
SEATS	9H – 1
GLASS & MIRRORS	9L – 1
EXTERIOR PARTS	9M – 1
BUMPERS & FASCIAS	9O – 1
DOORS	9P – 1
ROOF	9Q – 1
BODY FRONT END	9R – 1
BODY REAR END	9S – 1

DEFECT CODE

NATURE CODE

N02	Poor idle	N66	Blown fuse
N03	Surge, hesitate, stumble	N67	Warning light on
N08	Excessive oil consumption	N68	Intermittent operation
N12	Flooded, overflowing	N70	Poor AM reception / interference
N16	Percolation	N71	Oil leak, oil entering
N19	Vapor lock	N72	Water leak, water entering
N20	Blocked	N73	Leaks—other (air, fuel, refrigerant, vacuum)
N21	Shuddering, pulsation, vibration, chattering	N74	Poor FM reception / interference
N22	Slippage (= slipping)	N75	Radio / CD does not operate properly
N25	Abnormal shifts	N76	Tape deck does not operate properly
N26	Impossible shifts	N77	Improper memory
N27	Squeaking, squealing, abnormal(wind) noise	N78	Improper volume control
N28	Dragging	N80	Headlamp improperly aimed
N29	Pulls	N82	Loosening, falling—off, sagged
N43	Excessive shock	N83	Gas leak, gas entering
N44	Poor release	N84	Improper opening and/or closing
N46	Misaligned or mismatched	N85	Grabbed
N47	Weak	N86	Poor maneuverability
N51	Deteriorated	N91	Interference or hitting
N52	Distortion, rainbow, waving	N92	Inoperative
N53	Color mismatched	N93	High/low operating effort
N55	Rust, corrosion, perforation.	N94	Special policy
N56	Glazed	N95	Glass cracked
N57	Loose, poor fit	N96	Glass broken
N58	Bubbles	N97	Glass chipped
N62	Inaccurate (meter, gauge, etc.)	N98	Glass scratched
N63	Poor sound (horn, radio, etc.)	N99	Undefined
N65	Electrical failures		

CAUSE CODE

R01	Scored, scratched or chipped	R18	Grounded or shorted
R02	Frozen	R20	Faulty casting
R03	Peeling, come—off	R21	Improper clearance, back lash, free play
R04	Rusty, corroded	R23	Improper welding or soldering, welding or soldering omitted
R05	Split, cut or torn	R24	Improper tightening, fit or assembly
R06	Broken or cracked	R25	Sticks, binds, seized
R07	Porous, pin holes, cavity	R26	Foreign material, clogged
R08	Bent, kinky, twisted, distorted, warped or wrinkled	R27	Improper sealing, sealer omitted or skipped
R09	Stripped – bolts, holes, nuts	R28	Improper adjustment
R10	Soiled	R31	Incorrect part
R11	Weakened, loss of tension or resilience (spring, cushion, etc.)	R32	Improperly installed
R12	Abnormal wear	R33	Improperly routed
R13	Out of balance	R34	Missing part
R14	Out of round	R35	Flaw in material
R15	Loose or improper connection	R36	Contaminants
R16	Open circuit or short circuit	R99	Undefined