Audi
Vorsprung durch Technik

2011 Audi A5 Cabriolet
2011 Audi S5 Cabriolet
Quick Reference Guide

Fuel
(see label)

Fuel filler flap

Opening: Press the left side of the fuel filler flap.
Closing: Press the fuel filler flap in until it latches.



Engine oil

The engine oil specification is in the “Checking and filling” chapter and the engine oil capacity is in the “Data” chapter.

Tire pressures

(driver's side B-pillar)
Visible when the door is open.



Dear driver,

This Quick Reference Guide provides you with a brief overview of selected procedures and functions in your vehicle. It does not replace the Owner's Manual with its important explanations and warnings.

The Owner's Manual provides detailed information about your vehicle. You can find everything you need to know about the radio, CD player, navigation system and telephone in the Radio System Owner's Manual or MMI Owner's Manual.

We hope you enjoy driving your new Audi and we wish you safe and pleasant motoring.

Sincerely, AUDI AG

Cockpit

1 Steering wheel position adjuster

WARNING

The column should only be adjusted when the vehicle is at a complete standstill.

2 Hood release

3 Data Link Connector for On Board Diagnostics (OBD II)

4 Power windows

Setting the desired position:
Press/pull as far as the first level and hold.
Automatic up/down function:
Briefly press/pull as far as the second level.

WARNING

Be careful when closing the windows. Check to see that no one is in the way, or serious personal injury could result.

5 Adjusting the exterior mirrors

Adjust the knob:

- Left exterior mirror
- Heating the exterior mirror
- Right exterior mirror

The mirror glass moves in the direction that the knob is pressed.

6 Door handle and central locking switch

- locked
- unlocked

7 Memory seat buttons

8 Light switch and Instrument lighting

9 Cruise control or Audi adaptive cruise control

10 Multifunction steering wheel controls

11 Turn signal and high beam lever with lane assist button

12 Audi side assist

13 Instruments and indicator lights

14 Windshield wiper controls and trip computer buttons

15 Ignition lock

16 Sound system/MMI display

17 Emergency flashers

PASS AIR BAG OFF PASSENGER AIR BAG OFF indicator light

18 Sound system/ Audi multimedia

19 Audi drive select buttons:

You can select from the following settings:

COMFORT
Choose this setting when you want a more comfortable driving style (for example, when driving long distances on the expressway).

AUTO
Choose this setting for everyday driving.

DYNAMIC
Choose this setting when you want a more sporty driving style.

20 Parking system advanced

OFF Electronic Stabilization Program (ESP)

On vehicles equipped with a sound system, buttons **19** and **20** are located on the shift gate.

21 Climate control system

22 Shift lever for automatic transmission

23 Electromechanical parking brake

24 START ENGINE STOP button

25 MMI control console

26 Convertible top

27 Central power window switch

Opening and closing the vehicle

With convenience key, you can lock and unlock your vehicle without using the remote control key. You only need to carry the remote control key with you.

Unlocking the vehicle:

Grasp one of the door handles or the handle recess on the luggage compartment lid.

Locking the vehicle:

Place the selector lever in the **P** position. Touch the sensor 1 on one of the door handles.

Closing the luggage compartment lid:

Pull the rear lid down at the grip on the inside and allow it to drop gently to close it.

⚠WARNING

When you leave the vehicle, always remove the ignition key and take it with you. This will prevent passengers (children, for example) from accidentally being locked in the vehicle should they accidentally press the power locking switch in the front doors.

⚠WARNING

When you lock your vehicle from the outside, do not leave anyone - especially children - inside the vehicle. Remember, when you lock the vehicle from the outside the windows cannot be opened from the inside.

⚠WARNING

Always ensure that no one is within range of the rear lid when it is moving, in particular close to the hinges - fingers or hands can be pinched.

Starting the engine

Switching the ignition on and off:

Insert the key into the ignition lock.

Do **not** depress the brake pedal. Press on the key.

The key can only be removed when the ignition is switched off.

Starting the engine:

Insert the key into the ignition lock.

Depress the brake pedal and move the selector lever into **P** or **N**.

Briefly press on the key.

Stopping the engine when the vehicle is standing:

Move the selector lever into **P** or **N**.

Briefly press on the key.

Convenience key:

You can switch on the ignition and start/stop the engine using the START ENGINE STOP button without having the key inserted in the ignition lock.

Adjusting the seats

1 Adjusting the lumbar support:

Press on the respective area of the switch.

2 Adjusting seat height and forward/back position:

- Front of the seat cushion up/down
- Back of the seat cushion up/down
- Seat up/down
- Seat forward/back

3 Seatback adjustment and head restraint:

- Backrest forward/back
- Head restraint up/down

4 Entry assistance:

Pull the lever up and tilt the backrest forward or back.

Adjusting the headrests

Adjust the head restraint so the upper edge is as even as possible with the top of your head.

⚠WARNING

Thoroughly review your Owner's Manual for warnings and other important information about proper restraint use and what you can do to reduce the risk of injury in accidents. Failure to properly use restraint systems can cause serious personal injury.

⚠WARNING

Never install rear facing child seats or infant carriers on the passenger seat. A child will be seriously injured or killed when the passenger airbag inflates.

⚠WARNING

Always fasten safety belts before driving off. Always make sure passengers are properly restrained. Children 12 years old and younger must ride in the rear seat and be properly restrained as indicated in the Owner's Manual. The airbag is supplemental and does not replace safety belt use.

⚠WARNING

Front seat passengers must never ride in a moving vehicle with the seatback reclined. The risk of personal injury increases with increasing rearward angle of the seatback. Safety belts only offer protection when the seatback is upright and belts are properly positioned on the body. Adjust your seats only when the vehicle is at a complete standstill.

⚠WARNING

The airbag system cannot protect you properly if you are seated too close to any of the airbag locations. When adjusting their seat positions, it is important that both the driver and front passenger keep their upper bodies at a minimum safe distance of 10 inches (25 cm) between the chest and the steering wheel/instrument panel.

Automatic climate control



Climate control switch

Left switch – driver's side

Right switch – passenger's side

Rotary switch: Temperature selection

AUTO **Automatic mode**
Set the desired temperature and press the button.

Recirculation mode
Circulate and filter the air inside the passenger compartment

Fan speed

Air distribution

Defrost the windshield/side windows

Rear window defroster

Heated seats

AC **Switch the air conditioning system on/off**

OFF **Switching on/off**

Automatic transmission



Selector lever positions

P Park

R Reverse

N Neutral (Idle)

D Drive

S Sport

Releasing the selector lever lock and engaging a gear: Switch the ignition on, press the brake pedal and press the lock button on the selector lever. Place the selector lever in the **D** or **S** position to drive forward.

tiptronic: To shift manually, move the selector lever to the right out of the **D** position. The driver information system displays the gears.

Shifting up/down: Press the selector lever forward/back.

Convertible top

Opening the convertible top

Switch the ignition on:

Pull and hold the switch until the convertible top opens and the covers close completely.

Closing the convertible top

Switch the ignition on:

Press and hold the switch until the top has closed completely.

Variable convertible top compartment

Raise the convertible top compartment to increase the size of the luggage compartment.

The convertible top must be closed.

Raising: Press the tray in the direction of the arrow.



Wind deflector

Installing: Remove the wind deflector from the bag and fold it apart **once**.

Open the rear window on the passenger's side and insert both retaining pins 1 in the mounts in the side trim panel on the driver's side.

Pull the handle 2 in driving direction and lift the center of the wind deflector slightly.

Insert both retaining pins 3 in the mounts on the passenger's side.

Press the center of the wind deflector down slightly until the handle locks in place.

Straighten the wind deflector frame until it stops.

Removing: Perform the same steps used when installing, but in reverse order.

Multi Media Interface/ Sound system

Components

1 Driver information system

2 Multifunction steering wheel

Roll the **left menu thumbwheel** to mark a menu item in the driver information system. Press the thumbwheel to confirm the menu item.

Press the **MODE button** to switch between the active radio source, navigation system and telephone.

Roll the **right menu thumbwheel** to control the volume. Press the right thumbwheel to repeat the last navigation announcement.

3 Sound system/MMI display

4 On/Off knob

Switching on: Press briefly.

Adjusting the volume: Rotate.

Muting: Tap.

Switching off: Press and hold.

5 Function buttons

Press the desired button (such as MEDIA) to activate that mode.

6 Control knob

Marking a menu item in the display 3: Rotate the control knob.

Confirming the selection: Press the control knob.

7 Control buttons

To call up one of the functions shown in the four corners of the display, press the corresponding control button that is assigned to that corner of the display.

8 Joystick

To move the cross-hairs in a map view (navigation) or to control the DVD menu.

⚠WARNING

Distraction causes accidents:

- Never enter data while driving!

- Obey traffic laws & road signs!

- Refer to the Owner's Manual!

Operating concept

All functions are controlled using the same operating concept.



A Calling up menus in the display corners: Press the corresponding button.

B Marking: Rotate the knob.

C Confirming: Press the knob.

Storing a radio station

1 Press the RADIO function button.

2 Rotate the control knob and mark the desired station.

3 Press the control knob to confirm.

4 Press the “Presets” control button.
5 Rotate the control knob and mark “Store <station name>”.



6 Press the control knob. The next free memory preset is marked.



7 Rotate the control knob and mark the desired preset.
8 Press the control knob to confirm.



1 Press the NAV function button.

2 Rotate the control knob and mark “City/ZIP”.

3 Press the control knob to confirm.

4 Rotate the control knob to mark the first letter of the destination.

5 Press the control knob to confirm.

6 Continue entering the remaining letters of the destination name using the same procedure until the desired location name is displayed.

7 Press and hold the control knob longer when the city appears in the list.

8 Rotate and press to select the city and enter detailed destination information if necessary.

9 Mark the menu item “Start route guidance”.

10 Press the control knob to confirm. The route is calculated.

Driver assistance systems



Use the CAR button to adjust or operate many driver assistance systems in your Audi.

For detailed information on this, please see your vehicle Owner's Manual.

Establishing a Bluetooth™ cell phone connection

You can quickly connect your Bluetooth-compatible cell phone with the MMI or radio system.

Connecting to the MMI:

- Switch the ignition, MMI and cell phone on.
- Activate "Bluetooth" and "Access to SIM card" on the cell phone.
- Press the TEL function button.
- Mark the menu item "Search for new cell phones".
- Press the SETUP function button.
- Press the "Bluetooth" control button.
- Highlight the menu item "Search for Bluetooth devices" and confirm.
- Mark and confirm your cell phone in the display.
- Mark "Handsfree" and confirm.
- Confirm the PIN number with "Yes".
- Enter the PIN number on the cell phone.
- Also confirm the system prompt on the cell phone if necessary.

Connecting with the radio system:

- Switch the ignition, radio system and cell phone on.
- Select the menu in the cell phone that searches for Bluetooth-compatible devices (such as the cell phone prep or handsfree system).
- Connect the cell phone with the cell phone prep.
- Enter the PIN number on the cell phone.
- Also confirm the system prompt on the cell phone if necessary.

For additional information on indicator lights, refer to your vehicle Owner's Manual.

	Dynamic steering
	Electronic power control
	Electronic Stabilization Program (ESP)
	Airbag system (USA)
	Airbag system (CAN)
	Tire pressure too low
	Turn signals/Emergency flasher

	Safety belt
	Malfunction Indicator Lamp
	adaptive cruise control
	High beam
	Lane assist
	Lane assist
	Convertible top

	Cruise control activated (USA)
	Cruise control activated (CAN)
	Anti-lock brake system (USA)
	Anti-lock brake system (CAN)
	Parking brake (USA)
	Parking brake (CAN)
	Alternator malfunction

	Brake malfunction (USA)
	Brake malfunction (CAN)
	Cooling system malfunction
	Engine oil pressure too low
	Refill engine oil now
	Steering defective
	Ignition switch defective

© 2010 AUDI AG

Audi is constantly improving their products. Modifications in form, equipment, and technology are possible. No legal commitment is implied by the information, illustrations, and descriptions in this Quick Reference Guide. Reprinting, reproduction or translation, in whole or in part, is not permitted without written permission from Audi of America, Inc. Reprinting, reproduction or translation, in whole or in part, is not permitted without written permission from Audi of America, Inc. Subject to modification without notice. Concept and design: Pfriemer GmbH.

www.audi.com

Audi A5 Cabriolet
Audi S5 Cabriolet
Kurzanleitung
Nordamerika
englisch 05.2010
111.562.867.21