

Table of Contents 1:2

Vehicles with SRS (Airbag)/SIPS bag/IC (Inflatable Curtain)	2
Abbreviations	5
How to use the wiring diagrams 1:2.....	6
Electrical distribution 1:2.....	8

Fuses

Engine compartment distribution box F1-F8.....	10
Engine compartment distribution box F9-F18.....	11
Engine compartment distribution box F20-F32.....	12
Engine compartment distribution box F33-FH1	13
Central Electronic Module (CEM) F43-F52.....	14
Central Electronic Module (CEM) F53-F66.....	15
Central Electronic Module (CEM) F68-F86.....	16
Battery, PF1-PF2.....	17

Relays

Ignition switch and relays.....	18
Distribution box in engine compartment R1-R14.....	19
Central Electronic Module (CEM) R15-R18.....	20
Relays - soldered.....	21

Ground connections

Overview.....	22
31/3 - 31/10	23
31/11 - 31/66	24
31/67 - 31/84	25
31/88 - 31/114	26
31/115 - Ground connections in chassis.....	27

Control modules

Overview of locations.....	28
Overview of designations.....	29
Data communication Low speed CAN 1:2.....	30
Data communication LIN 1:2	32
Data communication High speed CAN	34
Data communication MOST	35

Group 23 Fuel system

Engine management system, 4-cyl 1.6l 1:2	36
Engine management system 4-cyl. 1.6l Diesel 1:2	38
Engine management system, 4-cyl 1.8l 1:2	40
Engine management system 5-cyl. Turbo 1.8l 1:2.....	42

Group 26 Cooling system

Cooling fan.....	44
Cooling fan Diesel.....	45

Group 27 Engine control

Cruise control 1.6l	46
Cruise control 1.8l.....	47
Cruise control 5-cyl.	48
Cruise control 4-cyl. Diesel	49

Group 32 Generator and voltage regulator

Power supply 4-cyl.....	50
Power supply 5-cyl.....	51

Group 33 Starting system

Starting system 4-cyl.....	52
Starting system 5-cyl.....	53

Group 35 Lighting

Reversing lights	54
------------------------	----

Group 36 Additional electrical equipment

Electronic immobilizer	55
Anti-theft alarm	56

Group 39 Other

Multimedia & Traffic Information	57
Audio Low Level 1:2	58
Cellular phone 1:2.....	60
Subwoofer.....	62

Table of Contents 2:2

Group 43 Transmission

Automatic transmission CFT 23.....	63
Automatic transmission AW 55-51, 5-cyl.	64
Differential Electronic Module (DEM).....	65

Group 87 Climate controls

Climate controls 4-cyl. 1:2	66
Climate controls 5-cyl. 1:2	67
Climate control system Diesel 1:2	68
Climate controls 4-cyl., 5-cyl. & Diesel 2:2	69

Connectors.....	70
-----------------	----

Branching points	87
------------------------	----

Component illustrations	94
-------------------------------	----

Index	117
-------------	-----

List of components 1:3	
------------------------	--