

2017 ELECTRICAL

Wiring Systems and Power Management - Component Locator - Instrument Panel/Center Console Component Views - Sierra, Silverado

INSTRUMENT PANEL/CENTER CONSOLE COMPONENT VIEWS

FRONT OF HVAC ASSEMBLY COMPONENTS




Fig. 1: Front of HVAC Assembly Components

Courtesy of GENERAL MOTORS COMPANY

Items

1. M4 Air Inlet Door Actuator
2. K33 HVAC Control Module
3. M6L Air Temperature Door Actuator - Left
4. E40 Electrical Auxiliary Heater (C32)
5. M37L Mode Door Actuator - Left
6. B7D Air Temperature Sensor - Duct Left Lower (CJ2)
7. B7E Air Temperature Sensor - Duct Right Lower (CJ2)

BACK OF HVAC ASSEMBLY COMPONENTS




Fig. 2: Back of HVAC Assembly Components
 Courtesy of GENERAL MOTORS COMPANY

Items

1. B7H Air Temperature Sensor - Duct Left Upper (CJ2)
2. B7J Air Temperature Sensor - Duct Right Upper (CJ2)
3. B39 A/C Evaporator Temperature Sensor (C67 or CJ2) **B39 A/C Evaporator Temperature Sensor ()**
4. M8 Blower Motor
5. M6R Air Temperature Door Actuator - Right (CJ2)

FRONT OF INSTRUMENT PANEL COMPONENTS




Fig. 3: Front of Instrument Panel Components
 Courtesy of GENERAL MOTORS COMPANY

Items

1. S76 Trailer Brake Control Switch (JL1) **S76 Trailer Brake Control Switch**
2. P19J Speaker - Left Instrument Panel (UQ3, UQA or UQG) **P19J Speaker - Left Instrument Panel (UQ3/UQG) P19J Speaker - Left Instrument Panel (UQA/UQS/UQH-UQG)**
3. P16 Instrument Cluster **P16 Instrument Cluster (-UHS) P16 Instrument Cluster (UHS)**
4. B10B Ambient Light/Sunload Sensor **B10B Ambient Light/Sunload Sensor**

Items

5. P17 Info Display Module P17 Info Display Module X1 (IO3) P17 Info Display Module X1 (IO5/IO6) P17 Info Display Module X1 (IOB) P17 Info Display Module X2 P17 Info Display Module X3 (IO3/IO5/IO6)
6. S31P Seat Heating and Cooling Switch - Passenger (KA1 or KB6) S31P Seat Heating and Cooling Switch - Passenger
7. P19W Speaker - Right Instrument Panel (UQ3, UQA or UQG) P19W Speaker - Right Instrument Panel (UQ3/UQG/UQ5) P19W Speaker - Right Instrument Panel (UQA)
8. S48A Multifunction Switch - Instrument Panel S48A Multifunction Switch - Instrument Panel X1 S48A Multifunction Switch - Instrument Panel X2
9. X81 Accessory Power Receptacle - 110V AC (KI4) X81 Accessory Power Receptacle - 110V AC X1 X81 Accessory Power Receptacle - 110V AC X2
10. X80K Accessory Power Receptacle - Instrument Panel 2 (D07) X80K Accessory Power Receptacle - Instrument Panel 2
11. X80J Accessory Power Receptacle - Instrument Panel 1 (D07) X80J Accessory Power Receptacle - Instrument Panel 1
12. X92 USB Receptacle X92 USB Receptacle
13. S31D Seat Heating and Cooling Switch - Driver (KA1 or KB6) S31D Seat Heating and Cooling Switch - Driver
14. X84 Data Link Connector X84 Data Link Connector
15. S30 Headlamp Switch S30 Headlamp Switch
16. S77 Transfer Case Shift Control Switch S77 Transfer Case Shift Control Switch (NQG) S77 Transfer Case Shift Control Switch (NQH/NQF)

REAR OF INSTRUMENT PANEL COMPONENTS




Fig. 4: Rear of Instrument Panel Components

Courtesy of GENERAL MOTORS COMPANY

Items

1. K74 Human Machine Interface Control Module (IO5 or IO6) K74 Human Machine Interface Control Module X1 K74 Human Machine Interface Control Module X2
2. F101 Passenger Instrument Panel Air Bag F101 Passenger Instrument Panel Air Bag
3. A33 Media Disc Player (TG5/U42/D07) A33 Media Disc Player X1 (D07/U42) A33 Media Disc Player X1 (TG5) A33 Media Disc Player X2 (D07/U42) A33 Media Disc Player X3 (U42) A33 Media Disc Player X4 (U42) A33 Media Disc Player X5 (U42)

Items

5. A11 Radio [A11 Radio X1](#) [A11 Radio X2 \(-IOB\)](#) [A11 Radio X2 \(IOB\)](#) [A11 Radio X3](#) [A11 Radio X4](#) [Q](#) [A11 Radio X5 \(IOB\)](#) [A11 Radio X6 \(IO5/IO6 +U2K\)](#) [A11 Radio X7 \(IO3/IOB\)](#)
6. K73 Telematics Communication Interface Control Module (UE1) [K73 Telematics Communication Interface Control Module X1](#) [K73 Telematics Communication Interface Control Module X2](#)
7. K56 Serial Data Gateway Module [K56 Serial Data Gateway Module X1](#) [Q](#) [K56 Serial Data Gateway Module X2](#)
8. K9 Body Control Module [K9 Body Control Module X1](#) [K9 Body Control Module X2](#) [K9 Body Control Module X4](#) [K9 Body Control Module X5](#) [K9 Body Control Module X6](#) [K9 Body Control Module X7](#)
9. T1 Accessory DC/AC Power Inverter Module (KI4 or KI5) [T1 Accessory DC/AC Power Inverter Module \(KI5\)](#)
10. X80J Accessory Power Receptacle - Instrument Panel 1 (D07) [X80J Accessory Power Receptacle - Instrument Panel 1](#)
11. X81 Accessory Power Receptacle - 110V AC (KI4) [X81 Accessory Power Receptacle - 110V AC X1](#) [X81 Accessory Power Receptacle - 110V AC X2](#)
12. S135 Rollover Protection Disable Switch (C9I) [S135 Rollover Protection Disable Switch](#)

Article GUID: A00854603