

1 Vehicle underbody

◆ ⇒ ["1.1 Rear underbody", page 1](#)

Component	Chapter	Comment
Rear left vehicle level sender -G76-	⇒ "1.1.1 Rear underbody, all engines", page 1	
Steering moment sender -G269-	⇒ "1.1.1 Rear underbody, all engines", page 1	
Delivery unit for reducing agent metering system -GX19-	⇒ "1.1.2 Rear underbody for vehicles with diesel engine, DFGA, DFHA, DBGC", page 3	For models with reducing agent metering system
Control unit 2 for NOx sender -GX46-	⇒ "1.1.2 Rear underbody for vehicles with diesel engine, DFGA, DFHA, DBGC", page 3	For models with reducing agent metering system
All-wheel drive control unit -J492-	⇒ "1.1.1 Rear underbody, all engines", page 1	For models with all-wheel drive
Power steering control unit -J500-	⇒ "1.1.1 Rear underbody, all engines", page 1	
Exhaust flap control unit -J883-	⇒ "1.1.1 Rear underbody, all engines", page 1	For models with 1.5l petrol engine, DADA, DPCA, DFYA
	⇒ "1.1.2 Rear underbody for vehicles with diesel engine, DFGA, DFHA, DBGC", page 3	For models with diesel engine
Control unit for reducing agent heater -J891-	⇒ "1.1.2 Rear underbody for vehicles with diesel engine, DFGA, DFHA, DBGC", page 3	For models with reducing agent metering system
Metering pump -V54-	⇒ "1.1.1 Rear underbody, all engines", page 1	for vehicles with auxiliary heater
All-wheel drive coupling pump -V181-	⇒ "1.1.1 Rear underbody, all engines", page 1	For models with all-wheel drive
Heater for reducing-agent line (heater circuit 2) -Z104-	⇒ "1.1.2 Rear underbody for vehicles with diesel engine, DFGA, DFHA, DBGC", page 3	For models with reducing agent metering system

1.1 Rear underbody

◆ ⇒ ["1.1.1 Rear underbody, all engines", page 1](#)

◆ ⇒ ["1.1.2 Rear underbody for vehicles with diesel engine, DFGA, DFHA, DBGC", page 3](#)


◆ ⇒ ["1.1.3 Rear underbody, for models with petrol engine, DAZA, DNWA", page 4](#)

1.1.1 Rear underbody, all engines

- 1 - Power steering control unit -J500-**
 - ☐ with steering moment sender -G269-
- 2 - Metering pump -V54-**
 - ☐ for vehicles with auxiliary heater
- 3 - All-wheel drive coupling pump -V181-**
 - ☐ For models with all-wheel drive
- 4 - All-wheel drive control unit -J492-**
 - ☐ For models with all-wheel drive
- 5 - Rear left vehicle level sender -G76-**
- 6 - Exhaust flap control unit -J883-**
 - ☐ For models with 1.5l petrol engine, DADA, DPCA, DFYA



Protected by copyright. Copying for private or commercial purposes, in part or permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept with respect to the correctness of information in this document. Copyright by Audi AG




[Back to overview ⇒ page 1](#)

1.1.2 Rear underbody for vehicles with diesel engine, DFGA, DFHA, DBGC

- 1 - Exhaust flap control unit -J883-
- 2 - Control unit 2 for NOx sender -GX46-
 - ☐ For models with reducing agent metering system
- 3 - Heater for reducing-agent line (heater circuit 2) -Z104-
 - ☐ For models with reducing agent metering system
- 4 - Delivery unit for reducing agent metering system -GX19-
 - ☐ For models with reducing agent metering system
- 5 - Control unit for reducing agent heater -J891-
 - ☐ For models with reducing agent metering system
 - ☐ in luggage compartment, rear right

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




[Back to overview ⇒ page 1](#)

1.1.3 Rear underbody, for models with petrol engine, DAZA, DNWA

- 1 - Duplicate exhaust gas temperature sensor 1 -GX41-
☐ According to equipment
- 2 - Duplicate exhaust gas temperature sensor 2 -GX42-
☐ According to equipment
- 3 - Exhaust flap control unit -J883-
- 4 - Exhaust flap control unit 2 -J945-



Protected by copyright. Copying is not permitted unless authorised by Audi AG with respect to the correctness of the information.



[Back to overview ⇒ page 1](#)