
LF7161A hatchback spare parts catalogue

1.Engine(LF481)


1.01 气缸盖罩　Cylinder head cover



1.01 气缸盖罩 Cylinder head cover

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-1003200A1	气缸盖罩总成	Cylinder head cover assy.	1		√
1-1	LF479Q1-1003210A1	气缸盖罩	Cylinder head cover	1		√
1-2	LF479Q1-1003202A	气缸盖罩通气嘴	Blowhole	1		
1-3	LF479Q1-1003212A	挡油板（Ⅰ）	Oil baffle I	1		√
1-4	LF479Q1-1003213A	挡油板（Ⅱ）	Oil baffle II	1		√
1-5	LF479Q1-1003214A	挡油板安装螺栓	Bolt	12		
2	LF479Q1-1003230A	加油口盖总成	Oil filler cap assy.	1		
2-1	LF479Q1-1003201A	加油口盖	Oil Filler Cap	1		√
2-2	LF479Q1-1003204A	加油口盖密封圈	Oil Filler Cap seal	1		
3	LF479Q1-3707000A	高压阻尼线总成	Ignition cable kit	1		√
4	LF479Q1-1014014A	PCV阀密封圈	PCV seal	1		√
5	LF479Q1-1003017A	气缸盖罩螺栓密封垫	Seal,cylinder head cover bolt	4		√
6	LF479Q1-1003018A	气缸盖罩螺母	Nut	4		√
7	LF479Q1-1014011A	PCV阀通气软管	PCV hose	1		√
7	LF479Q3-1014011A1	PCV阀通气软管	PCV hose	1	plastic in-manifold	√
8	LF479Q1-1014100A	PCV阀总成	PCV assy.	1		√
9	LF479Q1-1003015A	气缸盖罩密封垫	Gasket,cylinder head cover	1		√
	LF479Q1-1003203A	汽缸盖罩油封	Seal,cylinder head cover	4		√

1.02 气缸盖　Cylinder head




1.02 气缸盖　Cylinder head

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-1003100A	气缸盖总成	Cylinder head assy.	1		√
1-1	LF479Q1-1003101A	气缸盖体	Cylinder head	1		
1-2	LF479Q1-1003109A	排气凸轮轴轴承盖Ⅰ	Exhaust Camshaft Bearing Cap 1	1	cannot supply separately	
1-3	LF479Q1-1003110A	排气凸轮轴轴承盖Ⅱ	Exhaust Camshaft Bearing Cap 2	1	cannot supply separately	
1-4	LF479Q1-1003111A	排气凸轮轴轴承盖Ⅲ	Exhaust Camshaft Bearing Cap 3	1	cannot supply separately	
1-5	LF479Q1-1003112A	排气凸轮轴轴承盖Ⅳ	Exhaust Camshaft Bearing Cap 4	1	cannot supply separately	
1-6	LF479Q1-1003113A	排气凸轮轴轴承盖Ⅴ	Exhaust Camshaft Bearing Cap 5	1	cannot supply separately	
1-7	LF479Q1-1003104A	进气凸轮轴轴承盖Ⅰ	Intake Camshaft Bearing Cap 1	1	cannot supply separately	
1-8	LF479Q1-1003105A	进气凸轮轴轴承盖Ⅱ	Intake Camshaft Bearing Cap 2	1	cannot supply separately	
1-9	LF479Q1-1003106A	进气凸轮轴轴承盖Ⅲ	Intake Camshaft Bearing Cap 3	1	cannot supply separately	
1-10	LF479Q1-1003107A	进气凸轮轴轴承盖Ⅳ	Intake Camshaft Bearing Cap 4	1	cannot supply separately	
1-11	LF479Q1-1003108A	进气凸轮轴轴承盖Ⅴ	Intake Camshaft Bearing Cap 5	1	cannot supply separately	
1-12	LF479Q1-1003114A	凸轮轴主轴承盖紧固螺栓	Bolt	16	cannot supply separately	
2	LF479Q1-1003102A	气缸盖碗形堵塞Ⅰ	Bowl Plug 1	1		
3	LF479Q1-1003016A	半圆塞	Semi-Circle Plug	1		√
4	LF479Q1-1300017A	出水管	Outlet tube	1		√
5	Q1840820	六角法兰面螺栓	Hex flange bolt	2		√
6	LF481Q1-1003300A	气缸盖密封垫总成	Gasket,cylinder head	1		√
7	LF479Q1-1003013A	气缸盖连接组合螺栓（排气侧）	Cylinder head bolt(exhaust)	5		√
8	LF479Q1-1003014A	汽缸盖螺栓垫圈	Cylinder head bolt washer	10		√

1.02 气缸盖　Cylinder head

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
9	LF479Q1-1003012A	气缸盖连接组合螺栓（进气侧）	Cylinder head bolt(intake)	5		√
10	LF479Q1-3707011A	火花塞套筒	Spark pulg guild pipe	4		√
11	LF479Q1-3707800A	火花塞	Spark plug	4		√
12	LF479Q1-1003019A	气缸盖罩双头螺栓	Bolt	4		√


1.03 气缸体　Cylinder block



1.03 气缸体　Cylinder block

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-1307012A	水泵0型密封圈	Ring seal	1		√
2	LF481Q1-1002100A	曲轴箱总成	Crank case assy.	1		√
3	LF479Q1-1005019A	曲轴后端盖油封	Crankshaft rear seal	1		√
4	Q1841016	螺栓	Hex bolt	2		√
5	LF479Q1-1701012A	变速器隔板	Transimission Plate	1		√
6	Q1840616	六角法兰面螺栓	Hex flange bolt	6		√
7	LF479Q1-1005018A	曲轴后端盖	Crankshaft rear cover	1		√
8	Q5220614	曲轴后端盖定位销	Crankshaft rear cover pin	2		√
9	LF479Q1-1005017A	曲轴后端盖密封垫	Crankshaft rear gasket	1		√
10	LF479Q1-3818100A	机油压力报警器	Oil pressure warner	1		√
11	LF479Q1-1017100A	机油滤清器总成	Oil Filter Assy	1		√
12	LF479Q1-1002107A	曲轴箱轴承盖紧固螺栓	Crank case bearing cap bolt	10		
13	LF479Q1-1017011A	机油滤清器连接管	Oil Filter connecting pipe	1		√

1.04 配气机构　Valve timing mechanism



1.04 配气机构　Valve timing mechanism

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-1006105A	进气正时齿轮	Intake timing gear	1		√
2	LF479Q1-1006103A	消隙弹簧	Backlash spring	1		√
3	LF481Q1-1006101A	进气凸轮轴	Intake Camshaft	1		√
4	LF479Q1-1007018A	进气门油封	Intake valve seal	8		√
5	LF479Q1-1007021A-1	填隙片	Shim	demand	235×（10^{-2}）mm	√
5	LF479Q1-1007021A-2	填隙片	Shim	demand	240×（10^{-2}）mm	√
5	LF479Q1-1007021A-3	填隙片	Shim	demand	245×（10^{-2}）mm	√
5	LF479Q1-1007021A-4	填隙片	Shim	demand	250×（10^{-2}）mm	√
5	LF479Q1-1007021A-5	填隙片	Shim	demand	255×（10^{-2}）mm	√
5	LF479Q1-1007021A-6	填隙片	Shim	demand	260×（10^{-2}）mm	√
5	LF479Q1-1007021A-7	填隙片	Shim	demand	265×（10^{-2}）mm	√
5	LF479Q1-1007021A-8	填隙片	Shim	demand	270×（10^{-2}）mm	√
5	LF479Q1-1007021A-9	填隙片	Shim	demand	275×（10^{-2}）mm	√
5	LF479Q1-1007021A-10	填隙片	Shim	demand	280×（10^{-2}）mm	√
5	LF479Q1-1007021A-11	填隙片	Shim	demand	285×（10^{-2}）mm	√
5	LF479Q1-1007021A-12	填隙片	Shim	demand	290×（10^{-2}）mm	√
5	LF479Q1-1007021A-13	填隙片	Shim	demand	295×（10^{-2}）mm	√
5	LF479Q1-1007021A-14	填隙片	Shim	demand	300×（10^{-2}）mm	√
5	LF479Q1-1007021A-15	填隙片	Shim	demand	305×（10^{-2}）mm	√
5	LF479Q1-1007021A-16	填隙片	Shim	demand	310×（10^{-2}）mm	√


1.04 配气机构　Valve timing mechanism

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
5	LF479Q1-1007021A-17	填隙片	Shim	demand	315×（10^{-2}）mm	√
5	LF479Q1-1007021A-18	填隙片	Shim	demand	320×（10^{-2}）mm	√
5	LF479Q1-1007021A-19	填隙片	Shim	demand	325×（10^{-2}）mm	√
5	LF479Q1-1007021A-20	填隙片	Shim	demand	330×（10^{-2}）mm	√
5	LF479Q1-1007021A-21	填隙片	Shim	demand	335×（10^{-2}）mm	√
5	LF479Q1-1007021A-22	填隙片	Shim	demand	340×（10^{-2}）mm	√
5	LF479Q1-1007021A-23	填隙片	Shim	demand	345×（10^{-2}）mm	√
5	LF479Q1-1007021A-24	填隙片	Shim	demand	350×（10^{-2}）mm	√
6	LF479Q1-1007019A	挺柱	Tappet	16		√
6	LF479Q3-1007020A	整体式挺柱	Tappet	16		√
7	LF479Q1-1007016A	气门锁片	Valve Lock	32		√
8	LF479Q1-1007015A	气门弹簧座	Valve Spring Retainer	16		√
9	LF479Q1-1007013A	气门弹簧	Valve Spring	16		√
10	LF479Q1-1007017A	排气门油封	Exhaust Valve Seal	8		√
11	LF479Q1-1003121A	气门导管	Valve Guide	16	cannot supply separately	
12	LF479Q1-1007014A	气门弹簧底座	Valve Spring Seat	16		√
13	LF481Q1-1007011A	排气门	Exhaust Valve	8		√
14	LF481Q1-1007012A	进气门	Intake Valve	8		√
15	LF479Q1-1006202A	排气正时齿轮	Exhaust timing gear	1		√
16	LF481Q1-1006201A	排气凸轮轴	Exhaust Camshaft	1		√

1.04 配气机构　Valve timing mechanism

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
17	LF479Q1-1006203A	排气齿轮卡环	Exhaust gear snap ring	1		√
18	LF479Q1-1006011A	凸轮轴油封	Camshaft shaft seal	1		√
19	LF479Q1-1006107A	进气齿轮卡环	Exhaust gear snap ring	1		√
20	LF479Q1-1006104A	波形垫	Wave Washer	1		√
21	LF479Q1-1006106A	进气正时齿轮副齿	Intake timing sub gear	1		√


1.05 曲轴与活塞连杆　Crankshaft and piston rod



1.05 曲轴与活塞连杆　Crankshaft and piston rod

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1005010A	曲轴上轴瓦	Crankshaft bearing	1		√
2	LF481Q1-1005024A	曲轴下轴瓦	Crankshaft lower bearing	5		√
3	LF479Q1-1005013A	曲轴上止推片	Crankshaft upper thrust washer	2		√
4	LF479Q1-1005014A	曲轴下止推片	Crankshaft lower thrust washer	2		√
5	LF479Q1-1005022A	曲轴前油封	Crankshaft front seal	1		√
6	Q5500519	曲轴半圆键	Crankshaft woodruff key	1		√
7	LF481Q1-1005011A	曲轴	Crankshaft	1		√
8	LF479Q1-1004013A	活塞销	Piston Pin	4		√
9	LF481Q1-1004200A	活塞环组件	Piston ring kit	4		√
10	LF479Q1-1004010A	连杆轴瓦	Rod Bearing	1		√
11	LF479Q1-1004100A	连杆总成	Rod	4		√
11-1	LF479Q1-1004102A	连杆体	Rod	4		
11-2	LF479Q1-1004103A	连杆端盖	Rod cap	4		
11-3	LF479Q1-1004104A	连杆螺栓	Rod bolt	8		
11-4	LF479Q1-1004105A	连杆紧固螺母	Rod nut	8		
12	LF481Q1-1004012A	活塞	Piston	4		√


1.06 正时机构与前盖　Timing agency and front cover



1.06 正时机构与前盖　Timing agency and front cover

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	Q1840620	六角法兰面螺栓	Hex flange bolt	6		√
2	LF479Q1-1025021A	前罩壳上体	Front cover upper	1		√
3	LF479Q1-1025022A	前罩壳中体	Front cover middle	1		√
4	Q1840625	螺栓	Bolt	3		√
5	LF479Q1-1025023A	前罩壳下体	Front cover lower	1		√
6	LF479Q1-1025014A	凸轮轴正时皮带轮	Camshaft timing pulley	1		√
7	LF479Q1-1005023A	螺栓	Flywheel bolt	1		√
8	LF479Q1-1025100A	张紧轮总成	Tenioner	1		√
9	Q1841040	螺栓	Bolt	1		√
10	LF479Q1-1025025A	张紧轮弹簧	Tenioner spring	1		√
11	LF479Q1-1025018A	曲轴正时皮带轮前挡片	Front plate,crankshaft timing pulley	1		√
12	LF479Q1-1025012A	曲轴正时皮带轮	Crank shaft timing pulley	1		√
13	LF479Q1-1025019A	曲轴正时皮带轮后挡片	End plate ,crankshaft timing pulley	1		√
14	LF479Q1-1025016A	正时皮带	Timing belt	1		√


1.07 油底壳　Oil pan



1.07 油底壳　Oil pan

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-1010011A	机油集滤器密封垫	Gasket，oil strainer	1		√
2	Q123B0616	双头螺柱	Blot	2		√
3	Q32006	六角法兰面螺母	Hex flange bolt	2		√
4	LF479Q1-1010100A	机油集滤器总成	Oil strainer sub-assy	1		√
5	Q1840612	六角法兰面螺栓	Hex flange bolt	19		√
6	LF479Q1-1009100A	机油盘总成	Oil Pan	1		√
7	LF479Q1-1009012A	双头螺柱	Thru-stud	2		√
8	Q32006	六角法兰面螺母	Hex flange bolt	2		√
9	LF479Q1-1009013A	放油螺塞	Oil plug	1		√
10	Q40112T4F	放油螺塞垫片	Oil plug washer	1		√
11	LF479Q1-1009015A	油位计导管	Oil level gauge guide	1		√
12	LF479Q1-1009300A	油位计总成	Oil level gauge assy	1		√
13	LF479Q1-1009011A	油位计导管0型密封圈	O seal	1		√


1.08 进气歧管　In-manifold



1.08 进气歧管　In-manifold

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	Q1840825	螺栓	Bolt	3		√
2	Q32008	六角法兰面螺母	Hex flange nut	2		√
3	LF481Q1-1008201A	进气歧管上体	upper intake manifold	1		√
4	LF479Q1-1104014A	碳罐控制阀托架	Canister Control Valve bracket	1		√
4	LF479Q3-1104014A1	碳罐控制阀托架	Canister Control Valve bracket	1	Plastic in-manifold	√
5	LF479Q1-1108011A	油门拉索支架	Throttle cable bracket	1		√
5	LF479Q3-1108011A1	油门拉索支架	Throttle cable bracket	1	Plastic in-manifold	√
6	LF479Q1-3765011A	节气门体密封垫	Throttle gasket	1		√
7	Q1840650	螺栓	Throttle bolt	4		√
8	LF479Q1-1008203A	进气歧管上下体密封垫	Gasket upper&lower intake manifold	1		√
9	LF479Q1-1008202A	进气歧管下体	Lower intake manifold	1		√
10	LF479Q1-1008018A	双头螺柱	Thru-stud	2		√
11	LF479Q1-3614011A	进气温度压力传感器支架	Bracket,temperature&pressure sensor	1	Delphi	√
11	LF479Q3-3614011B	进气温度压力传感器支架	Bracket,temperature&pressure sensor		Sun&teck	√
12	LF479Q1-1008018A	双头螺柱	Thru-stud	2		√
13	Q32008	六角法兰面螺母	Hex flange nut	2		√
14	LF479Q1-1008014A	进气歧管密封垫	Intake manifold gasket	1		√
15	Q1840830	进气歧管螺栓	Bolt,Intake manifold	7		√


1.09 塑料进气歧管　In-manifold（plastic）



1.09 塑料进气歧管　In-manifold（plastic）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q3-1008200A1	进气歧管总成	Intake manifold assy.	1	Plastic in-manifold	√
1-1	LF479Q3-1008227A	进气歧管密封圈	Intake manifold seal	4	Plastic in-manifold	


1.10 排气歧管　Ex-manifold



1.10 排气歧管　Ex-manifold

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-1008013A	排气歧管隔热垫	Exhaust Manifold gasket	1		√
2	LF481Q1-1008100A	排气歧管总成	Exhaust Manifold	1		√
3	LF479Q1-1008011A	排气歧管上隔热罩	Heat Insulator upper	1		√
4	Q1840612	螺栓	Bolt	6		√
5	LF479Q1-1008012A	排气歧管下隔热罩	Heat insulator lower	1		√
6	Q32010	螺母	Nut	5		√
7	LF479Q1-1008017A	双头螺柱	Thru-stud	5		√
8	Q1840816	六角法兰面螺栓	Bolt	2		√
9	LF479Q1-1008016A	排气歧管支撑架	Exhaust manifold bracket	1		√
10	Q1841016	螺栓	Hex bolt	1		√


1.11 节温器　Thermostat



1.11 节温器　Thermostat

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-1306201A	节温器座	Thermostat seat	1		√
2	Q1840840	螺栓	Bolt	1		√
3	LF479Q1-1306100A	节温器总成	Thermostat assy	1		√
4	LF479Q1-1300015A	进水管	Inlet tube	1		√
5	Q1840620	六角法兰面螺栓	Hex flange bolt	2		√
6	Q32008	六角法兰面螺母	Hex flange nut	2		√
7	LF479Q1-1306012A	节温器座双头螺柱	Thru-stud,thermostat seat	2		√


1.12 轮系　Pulley system



1.12 轮系　Pulley system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	Q1840610	六角法兰面螺栓	Bolt	4		√
2	LF479Q1-1025011A	水泵皮带轮	Water pump pulley	1		√
3	LF479Q1-1025013A	曲轴皮带轮	Crankshaft Pulley	1		√
4	LF479Q1-1025015A	水泵、发电机皮带	Water pump and generator belt	1		√
5	Q40212	垫圈	Washer	1		√
6	LF479Q1-1025024A	曲轴皮带轮螺栓	Crankshaft pulley bolt	1		√


1.13 水泵　Water pump




1.13 水泵　Water pump

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-1307103A	水泵盖	Water Pump cap	1		
2	LF479Q1-1307108A	水泵体密封垫	Water Pump gasket	1		
3	LF479Q1-1307102A	水泵体	Water Pump Body	1		
4	LF479Q1-1307107A	轴连轴承	Bearing	1		
5	LF479Q1-1307106A	法兰	Flange	1		
6	LF479Q1-1307017A	双头螺柱	Bolt	2		√
7	Q676B45	管夹	Clip	2		√
8	LF479Q1-1307015A	水泵进水胶管	Inlet Water Hose	1		√
9	LF479Q1-1307013A	水泵进水管	Inlet Water Hose	1		√
10	Q1840610	螺栓	Bolt	1		√
11	Q32008	六角法兰面螺母	Hex flange nut	2		√
12	Q150B0835	螺栓	Bolt	3		
13	LF479Q3-1307100A-1	水泵总成	Water Pump	1		√
	LF479Q1-1307011B	水泵进水管密封垫	Inlet Water Hose gasket	1		√

1.14 起动电机和发电机 Starter and Generator



1.14 起动电机和发电机　Starter and Generator




1.14 起动电机和发电机　Starter and Generator

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-3701013A	发电机紧固螺母	Generator nut	1		√
2	LF481Q1-3701100A	发电机总成	Generator assy.	1		√
3	Q18410105	螺栓	Generator bracket bolt	1		√
4	LF481Q1-3708100A	启动电机总成	Startor assy.	1		√
5	Q1841040	螺栓	Bolt	2		√
2-1	LF481Q3-3701110A	皮带轮	Pulley	1	Generator spare part	
2-2	LF479Q3-3701120A	前端盖	Front cap	1	Generator spare part	
2-3	LF479Q3-3701130A	前滚动轴承	Bearing	1	Generator spare part	
2-4	LF481Q3-3701140A	定子	Stater	1	Generator spare part	
2-5	LF479Q3-3701150A	转子	Rotor	1	Generator spare part	
2-6	LF479Q3-3701160A	后滚动轴承	Bearing	1	Generator spare part	
2-7	LF481Q3-3701170A	后盖组成	End cap	1	Generator spare part	
2-8	LF479Q3-3701180A	电压调节器	Voltage regulator	1	Generator spare part	√
2-9	LF479Q3-3701190A	电刷总成	Brush	1	Generator spare part	
2-10	LF481Q3-3701111A	整流器	Rectifier	1	Generator spare part	√
2-11	LF479Q3-3701112A	绝缘套	Insulant	1	Generator spare part	
2-12	LF479Q3-3701113A	罩盖	Cover	1	Generator spare part	
4-1	LF481Q3-3708110A	前盖总成	Front cap assy.	1	Startor spare part	
4-2	LF481Q3-3708120A	单向器	unidirectional	1	Startor spare part	
4-3	LF479Q3-3708130A	电磁开关	Solenoid Switch	1	Startor spare part	√

1.14 起动电机和发电机　Starter and Generator

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
4-4	LF479Q3-3708140A	星轮轮轴总成	Star gear	1	Startor spare part	
4-5	LF479Q3-3708150A	减速齿轮总成	Reducing gear	1	Startor spare part	
4-6	LF479Q3-3708160A	星形齿轮总成	Spider gear	1	Startor spare part	
4-7	LF479Q3-3708170A	电枢总成	Armature	1	Startor spare part	
4-8	LF479Q3-3708180A	机壳总成	Shuck	1	Startor spare part	
4-9	LF479Q3-3708190A	刷架总成	Brush bracket	1	Startor spare part	
4-10	LF479Q3-3708111A	电刷端盖总成	Front cap with brush assy.	1	Startor spare part	
4-11	LF479Q3-3708112A	拨叉	Fork	1	Startor spare part	


1.15 辅助装置　Auxiliary device



1.15 辅助装置　Auxiliary device

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-3701011A	发电机调节支架	Generator adjusting bracket	1		√
2	LF479Q1-1024012A	缸盖右吊钩	Cylinder head right hook	1		√
3	LF479Q1-1001400A	发动机右安装支架	Engine right bracket	1		√
4	LF479Q1-1024011A	缸盖左吊钩	Cylinder head left hook	1		√
5	LF479Q1-3701012A	发电机调节块	Generator adjusting block	1		√
6	LF479Q1-3701200A	发电机托架总成	Generator bracket assy.	1		√
7	LF479Q1-3705011A	点火线圈支架	Ignition coil bracket	1		√
8	LF479Q1-1008015A	进气歧管支撑架	Intake manifold bracket	1		√
8	LF479Q3-1008015A1	进气歧管支撑架	Intake manifold bracket	1	plastic in-manifold	√


1.16 离合器　Clutch



1.16 离合器　Clutch

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	Q5220820	定位销	Pin	3		√
2	LF481Q1-1005100A	飞轮齿圈总成	Flywheel rim	1		√
3	LF479Q1-1005023A	飞轮螺栓	Flywheel bolt	6		√
4	LF481Q1-1601200A	离合器从动盘总成	Clutch Driven Plate	1		√
5	LF481Q1-1601100A	离合器压盘总成	Clutch press plate	1		√
6	LF479Q1-1601012A	离合器盖组合螺栓	Clutch cover bolt	6		√


1.17 机油泵　Oil pump



1.17 机油泵　Oil pump

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1011100A	机油泵总成	Oil Pump Assy	1		√
2		螺钉	Screw	5		
3	LF481Q1-1011104A	定位销	Set Pin	2		
4	LF481Q1-1011107A	机油泵外转子	Drive Gear，outer	1		
5	LF481Q1-1011106A	机油泵内转子	Drive Gear，inner	1		
6	LF479Q1-1011012A	机油泵定位销	Oil pump pin	2		√
7	Q61903	螺塞	Plug	2		
8	LF481Q1-1011108A	机油泵安全阀	Oil Pump Relief Valve	1		
9	Q1840825	六角法兰面螺栓	Bolt	3		√
10		双头螺柱	Bolt	2		
11	LF481Q1-1011101A	泵体	Oil Pump body	1		
12	LF481Q1-1011102A	泵盖	Oil Pump cap	1		
13	LF479Q1-1011011A	机油泵密封垫	Gasket，oil pump	1		√


1.18 发动机线束 Engine harness



1.18 发动机线束 Engine harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF479Q1-4001100A	发动机线束	Engine harness	1	Delphi	√
2	LF479Q1-4001100B	发动机线束	Engine harness	1	Delphi+OBD，plastic in-manifold	√
3	LF479Q3-4001100C1	发动机线束	Engine harness	1	Sun&teck	
4	LF479Q3-4001100B1	发动机线束	Engine harness	1	Sun&teck+OBD	√
5	LF479Q3-4001100B2	发动机线束	Engine harness	1	Sun&teck，plastic in-manifold	√
6	LF479Q3-4001100C20	发动机线束	Engine harness	1	Sun&teck，ACS integrated	√
7	LF479Q3-4001100C3	发动机线束	Engine harness	1	Sun&teck，ACS+OBD	√
8	LF479Q3-4001100C2	发动机线束	Engine harness	1	Sun&teck，ACS	√
9	LF479Q3-4001100C30	发动机线束	Engine harness	1	Sun&teck，ACS+OBD integrated	√
11	LF481Q3-4001100C13	发动机线束	Engine harness	1	Sun&teck，CVT+OBD	√

1.19 电喷系统 EFI system



1.19 电喷系统　EFI system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAL3612100	电子控制器	ECU	1	delphi	√
1	LAL3612100B2	电子控制器	ECU	1	sun&teck，Euro 3	√
2	LBA3705100	点火线圈总成	Ignition Coil	1	delphi	√
2	LBA3705100B1	点火线圈总成	Ignition Coil	1	sun&teck	√
3	LBA1121100	燃油分配管总成	Fuel Distributor	1	delphi	√
3	LBA1121100B1	燃油分配管总成	Fuel Distributor	1	sun&teck	√
3-1	LBA1124100B1	燃油喷射器	Fuel injector	4	sun&teck	√
4	LBA3612300	氧传感器	Oxygen Sensor	1	delphi	√
4	LBA3612300B1	氧传感器	Oxygen Sensor	1	sun&teck	√
4	LBF3612300	前氧传感器	Front oxygen Sensor	1	sun&teck，National 4，plastic in-manifold	
4	LBF3612300B1	后氧传感器	Rear oxygen Sensor	1	sun&teck，National 4，plastic in-manifold	
5	LBA3612600	曲轴位置传感器	Crankshaft Position Sensor	1	delphi	√
5	LBA3612600B1	曲轴位置传感器	Crankshaft Position Sensor	1	sun&teck	√
6	LBA1130310	碳罐控制阀	Canister Control Valve	1	delphi	√
6	LBA1130310B1	碳罐控制阀	Canister Control Valve	1	sun&teck	√
6-1	LBA1130311B1	碳罐电磁阀固定胶套	Canister control valve sleeve			
7	LBA3612400	爆震传感器	Knock Sensor	1	delphi	√

1.19 电喷系统　EFI system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
7	LBA3612400B1	爆震传感器	Knock Sensor	1	sun&teck	√

8	LBA1132100	节气门体总成	Throttle assy	1	delphi	√
8	LBA1132100B1	节气门体总成	Throttle assy	1	sun&teck	√
8	LBA1132100C1	节气门体总成	Throttle Assy	1	sun&teck，plastic in-manifold	√
8-1	LBA1132160	节气门位置传感器	Throttle position sensor	1	delphi	√
8-1	LBA1132160B1	节气门位置传感器	Throttle position sensor	1	sun&teck	√
8-2	LBA1132150	怠速步进电机	Idle motor	1	delphi	√
8-2	LBA1132150B1	怠速步进电机	Idle motor	1	sun&teck	√
9	LBA3612500	弱加速传感器	idle sensor	1	OBD only	√
10	LBA3614300	进气温度压力传感器	Temperature And Pressure Sensor	1	delphi	√
10	LBA3614300B1	进气温度压力传感器	Temperature And Pressure Sensor	1	sun&teck	√
11	LBA3616100	水温传感器	Water Temperature Sensor	1	delphi	√
11	LBA3616100B1	水温传感器	Water Temperature Sensor	1	sun&teck	√
	LF481Q1-3611011A	曲轴位置传感器垫片	Crankshaft Position Sensor gasket	1		√
	Q1840630	曲轴位置传感器螺栓	Crankshaft Position Sensor bolt	1		√

发动机总成　Engine assy.（without Transmission）


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
	LF481Q3-1000000A	发动机总成	Engine assy.	1		√

	LF481Q4-1000000A	发动机总成	Engine assy.	1	for CNG	√
	LF481Q3-1000000B	发动机总成	Engine assy.	1	Plastic in-manifold	√

2.Transmission(LF481)

2.01 变速器总成 Transmission assy







2.01 变速器总成　Transmission assy.

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1700000A	变速器总成	Transmission assy.	1		√

1	LF481Q1-1700000A2	变速器总成	Transmission assy.	1	improved	√
1	LF481Q1-1700000A1	变速器总成	Transmission assy.	1	for plastic in-manifold	√

2.02 变速器壳体总成 Transmission shell





2.02 变速器壳体总成 Transmission shell

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1701011A1	离合器壳体	Clutch shell	1	improved	√

1	LF481Q1-1701011A	离合器壳体	Clutch shell	1		√
2	LF481Q1-1701021A1	变速器壳体	Transmission shell	1	improved	√
2	LF481Q1-1701021A	变速器壳体	Transmission shell	1		√
3	LF481Q1-1701337A	油封堵	Plug	2		√
4	LF481Q1-2303322A	T型差速器油封	Differential T seal	2	improved	√
4	LF481Q1-2303321A	离合器油封	Differential T seal，clutch shell	1	45×68×12.5，old status	√
4	LF481Q1-2303314A	变速器壳油封	Differential T seal，transmission shell	1	45×80×10，old status	√
5	LF481Q1-1701334A	分离轴承	Throwout bearing	1		√
6	LF481Q1-1701332A	分离卡簧	Throwout circlip	1	1.6×29×100	√
7	LF481Q1-1701330A	分离拨叉	Throwout fork	1		√
8	LF481Q1-1701333A	分离拔叉支撑柱	Throwout fork support	1		√
9	LF481Q1-1701023A	连接螺栓	Connecting bolt	14	M8×35	√
10	LF481Q1-1702039A	换位拉线支架	Transposition cable bracket	1		√
11	LF481Q1-1702047A	拉线支架螺栓	Cable bracket bolt	5	M8×18	√
12	LF481Q1-1702038A	换档拉线支架	Shift cable bracket	1		√
13	LF481Q1-1702040A	换档换位拉索支架	Shift cable bracket	1	for plastic in-manifold	
14	LF481Q1-1702160A	离合器分泵	Clutch slave cylinder	1		√
15	LF481Q1-1702159A	离合器分泵螺栓	Bolt	2	M8×25	√
16	LF481Q1-1701331A	分离拔叉护套	Throwout fork sleeve	1		√

2.02 变速器壳体总成 Transmission shell

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
17	LF481Q1-1702170A	液压油管	Hydraulic tube	1		√

18	LF481Q1-1701026A	注放油塞	Hex bolt plug	2	M18×1.5	√
19	LF481Q1-1701029A	铝垫18.2×25×2	Aluminum washer	3		√
19	LF481Q1-1701029B	铜垫圈	Copper washer	3		√
20	LF481Q1-1701033A	换档定位总成	Shift position device	1		√
21	LF481Q1-1701034A	导油槽	Oil passage	1		√
22	LF481Q1-1702037A	变速器壳衬套	Transmission shell sleeve	1	15×18×10	√
23	LF481Q1-1701155A	端盖螺栓	End cover bolt	4	M6×18.5	√
24	LF481Q1-1701154A	端盖	End cover	1		√
25	LF481Q1-1701335A	线卡子	Clamp	2		√
26	LF481Q1-1701036A	带垫螺栓	Bolt with washer	2	M8×15	
27	LF481Q1-1702110A1	换档导轴组件	Shift shaft component	1	for plastic in-manifold	√
27	LF481Q1-1702110A	换档导轴组件	Shift shaft component	1		√
28	LF481Q1-1702157A	换档盖紧固螺栓	Bolt	2	M8×30	√
29	LF481Q1-1702158A	换档盖定位螺栓	Bolt	2	M8×35	√
30	LF481Q1-1701024A	油管支架	Tube bracket	1		√
31	LF481Q1-1701025A	油管支架螺栓	Tube bracket bolt	1	M8×15	√
32	LF481Q1-1701027A	倒档开关总成	Reverse light switch	1		√
33	LF481Q1-1701029A	铝垫18.2×25×2	Aluminum washer	3		√
34	LF481Q1-1701028A	定位销	Pin	2	10×25	√


2.02 变速器壳体总成 Transmission shell

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
35	LF481Q1-1701190A	导油端垫	Oil passage cap	1		√

36	LF481Q1-1701030A	输入轴S型油封	Input shaft S seal	1	23×37×7	√
37	LF481Q1-1701336A	方形磁体	Square magnet	1		√
38	LF481Q1-1701086A	铝垫	Aluminium washer	1		√

2.03 输入轴 Input shaft






2.03 输入轴　Input shaft

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1701041A	输入轴	Input shaft	1		√

2	LF481Q1-1701078A	输入轴前轴承	Input shaft bearing	1	25×62×17	√
3	LF481Q1-1701050A	三档主动齿轮总成	Third drive gear	1		√
4	LF481Q1-1701060A	三四档同步器总成	Third forth synchronize assy.	1		√
5	LF481Q1-1701053A	四档主动齿轮总成	Forth drive gear	1		√
6	LF481Q1-1701057A	五档主动齿轮总成	Fifth drive gear	1		√
7	LF481Q1-1701070A	五档同步器总成	Fifth synchronize assy.	1		√
8	LF481Q1-1701078A	输入轴后轴承	Input shaft bearing	1	25×62×17	√
9	LF481Q1-1701077A	五档滚针轴承	Fifth needle bearing	1	K31×36×20DTN	√
10	LF481Q1-1701069A	五档同步环	Fifth synchronize rim	1		√
11	LF481Q1-1701044A	输入四档止推垫定位球	Input forth thrust washer ball	1		√
12	LF481Q1-1701065A	四档同步环	Forth synchronize rim	1		√
13	LF481Q1-1701059A	三档同步环	Third synchronize rim	1		√
14	LF481Q1-1701076A	三、四档滚针轴承	Third forth needle bearing	2	K34×39×20DTN	√
15	LF481Q1-1701045A	输入四档止推垫	Input forth thrust washer	1		√
16	LF481Q1-1701046A	输入四档止推垫挡圈	Input forth thrust washer circlip	1	2.5/3×34.5	√
	LF481Q1-1701047A	输入五档滚针隔环	Input fifth needle spacer	1		√

2.04 输出轴 Output shaft






2.04 输出轴　Output shaft

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1701141A	输出轴前轴承	Output shaft front bearing	1	30×55×17	√

2	LF481Q1-1701110A	一档从动齿轮总成	First driven gear	1		√
3	LF481Q1-1701113A	一档同步环	First synchronize rim	1		√
4	LF481Q1-1701124A	二档同步环	Second gear synchronize rim	1		√
5	LF481Q1-1701127A	二档滚针轴承	Second gear needle bearing	1	K34×39×23TN	√
6	LF481Q1-1701138A	四档从动齿轮	Forth driven gear	1		√
7	LF481Q1-1701150A	输出轴后轴承	Output shaft rear bearing	1	20×47×15	√
8	LF481Q1-1701140A	五档从动齿轮	Fifth driven gear	1		√
9	LF481Q1-1701136A	三档从动齿轮	Third driven gear	1		√
10	LF481Q1-1701130A	二档从动齿轮总成	Second driven gear	1		√
11	LF481Q1-1701120A	一二档同步器总成	First second synchronize assy.	1		√
12	LF481Q1-1701103A	一档滚针轴承	First needle bearing	1	K34×39×28DTN	√
13	LF481Q1-1701106A	输出轴	Output shaft	1		√
14	LF481Q1-1701101A	输出五档挡圈	Output fifth circlip	1	2.6/3×24	√
15	LF481Q1-1701151A	输出轴轴承垫片	Output shaft spring washer	1		√
16	LF481Q1-1701137A	输出轴三档定位套	Output third position sleeve	1		√
17	LF481Q1-1701042A	一二、三四同步器档圈	Synchronize circlip	1	2.5/3x37	√
18	LF481Q1-1701043A	输出二档、输入四档滚针隔环	Input second，output forth space ring	2	34.2×38×1	√

2.05 拨叉轴 Fork shaft






2.05 拨叉轴　Fork shaft

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1702053A	一、二档换档拨叉	First second fork	1		√

2	LF481Q1-1702054A	换档叉止动螺栓	Shift fork stop bolt	2	M6×0.75×19	√
3	LF481Q1-1702051A	一、二档拨叉轴	First second fork shaft	1		√
4	LF481Q1-1702057A	叉轴挡圈	Fork shaft circlip	5	1.5×11.6×16.6	√
5	LF481Q1-1702056A	弹性圆柱销	Spring pin	2	5.5×22	√
6	LF481Q1-1702052A	一、二档换档导块	First second shift block	1		√
7	LF481Q1-1702082A	互锁销B	Interlock pin	1	6×17.5	√
8	LF481Q1-1702075A	倒档拨块	Reverse shift block	1		√
9	LF481Q1-1702072A	五、倒档换档导块	Fifth reverse shift block	1		√
10	LF481Q1-1702071A	五档、倒档拨叉轴	Fifth reverse fork shaft	1		√
11	LF481Q1-1702074A	拨叉回位弹簧	Fork spring	1	1.2×17.5×120×20	√
12	LF481Q1-1702073A	五档换档拨叉	Fifth fork	1		√
13	LF481Q1-1702061A	三、四档拨叉轴	Third forth fork shaft	1		√
14	LF481Q1-1702062A	三、四档换档拨叉	Third forth fork	1		√
15	LF481Q1-1702081A	互锁销A	Interlock pin	1	6×13.8	√

2.06 换选档机构 Shift system





2.06 换选档机构　Shift system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1702030A	换位摇臂组件	Transposition swing arm	1		√


2	LF481Q1-1702035A	换位摇臂油封	Transposition swing arm seal	1	16×26×7	√
3	LF481Q1-1702130A	通气塞总成	Vent valve assy.	1		√
4	LF481Q1-1702141A	通气塞垫片	Vent valve gasket	1	10×14×1.5	√
5	LF481Q1-1702151A	换档盖	Shift cap	1		√
6	LF481Q1-1702016A	换档盖定位环	Shift cap position ring	2	11×8.5×12	√
7	LF481Q1-1702114A	换位摆杆	Transposition swing lever	1		√
8	LF481Q1-1702115A	换位摆杆螺栓	Transposition swing lever bolt	1	M8×21	√
9	LF481Q1-1702122A	五、倒档互锁凸轮弹簧	Fifth reverse cam spring	1		√
10	LF481Q1-1702120A	五、倒档互锁凸轮	Fifth reverse cam	1		√
11	LF481Q1-1702121A	五、倒档互锁凸轮密封球	Fifth reverse cam seal ball	1	6,2	√
12	LF481Q1-1702123A	五、倒档互锁凸轮销	Fifth reverse cam pin	1		√
13	LF481Q1-1702036A	换档导轴油封	Shift shaft seal	1	18×28×8	√
14	LF481Q1-1702155A	回位弹簧	Return spring	1	B1.2×13.2×63×90	√
15	LF481Q1-1702154A	换档导轴尼龙垫圈	Shift shaft washer	1	14.5×9×3	√
16	LF481Q1-1702137A	换档导轴挡圈	Shift shaft circlip	1	A1.5/3×21	√
17	LF481Q1-1702116A	换档摆杆弹性圆柱销5.5×26	Pin	1		√
18	LF481Q1-1702108A	换档摆杆互锁架	Shift swinglever interlock bracket	1		√
19	LF481Q1-1702142A	换档摆杆	Shift swinglever	1		√
20	LF481Q1-1702138A	换档导轴挡圈	Shift shaft circlip	1	A15×21×1.5	√


2.06 换选档机构　Shift system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
21	LF481Q1-1702156A	回位弹簧	Return spring	1	A1.5×26.6×63×70.5	√

22	LF481Q1-1702128A	回位弹簧座	Return spring seat	1		√
23	LF481Q1-1702152A	换档盖衬套	Shift cap bush	1	18×21×10	√
24	LF481Q1-1702105A	换档导轴护套	Shift shaft sleeve	1		√
25	LF481Q1-1702110A1	换档导轴组件	Shift shaft component	1	for plastic in-manifold	√
	LF481Q1-1702110A	换档导轴组件	Shift shaft component	1		√

2.07 差速器 Differential






2.07 差速器　Differential

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-2303316A	差速器圆锥滚子轴承	Differential roller bearing	2	HR32008XJ,improved status	√

1	LF481Q1-2303312A	差速器后轴承	Differential rear bearing	1	6308	√
1	LF481Q1-2303310A	差速器前轴承	Differential front bearing	1	6208	√
2	LF481Q1-2303311A	差速器螺栓	Differential bolt	10	M12×1×19.5	√
3	LF481Q1-2303308A	差速器齿圈	Differential roller bearing	1		√
4	LF481Q1-2303309A	里程表主动齿轮	Speedometer drive gear	1	for separated Speedometer	√
5	Q5240535	滚花圆柱销	Pin	1		√
5	LF481Q1-2303307A	行星齿轮弹性圆柱销4×36	Pin	1	Q5210436	√
6	LF481Q1-2303301A	差速器壳体	Differential shell	1		√
7	LF481Q1-2303304A	半轴齿轮垫片	Differential axle gear washer	2		√
8	LF481Q1-2303302A	半轴齿轮	Differential axle gear	2		√
9	LF481Q1-2303305A	行星齿轮垫片	Planet gear washer	2		√
10	LF481Q1-2303303A	行星齿轮	Planet gear	2		√
11	LF481Q1-2303306A	行星齿轮轴	Planet gear shaft	1		√
12	LF481Q1-2303315A	齿圈螺栓锁紧片	Locker washer	2		√
	LF481Q1-2303300A	差速器总成	Differential assy.	1		√

2.08 里程表 Speedometer






2.08 里程表　Speedometer

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1701211A	里程表被动齿轮	Speedometer driven gear	1	for separated speedometer	√

2	LF481Q1-1701215A	里程表定位卡簧	Speedometer circlip	1	for separated speedometer	√
3	LF481Q1-1701212A	里程表被动轮套	Speedometer driven gear sleeve	1	for separated speedometer	√
4	LF481Q1-1701214A	里程表O型圈	O seal	1	for separated speedometer	√
5	LF481Q1-1701213A	里程表油封	Speedometer seal	1	9.5×15.5×8，for separated speedometer	√
6	LF481Q1-1701217A	里程表护套	Speedometer sleeve	1	for separated speedometer	√
7	LF481Q1-1600500A	里程表定位螺栓	Speedometer bolt	1	M8×15，for separated speedometer	
7	LF481Q1-1600501A	里程表定位螺栓 M8×25 头部带孔	Speedometer bolt	1	for integrated speedometer	√
8	LF481Q1-1701216A	里程表锁片	Speedometer locker	1	for separated speedometer	√
9	LF481Q1-1701200A	里程表传动总成	Speedometer assy.	1	for separated speedometer	√
	LF481Q1-3802100B1	整体式车速传感器	Speedometer sensor	1	integrated	√
	LF479Q1-3802100A	里程表传感器	Speedometer sensor	1	separated	√

2.09 倒挡机构 Reverse mechanism






2.09 倒档机构　Reverse mechanism

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LF481Q1-1701083A	倒档中间齿轮螺栓	Bolt	1	M8×35	√


2	LF481Q1-1701081A	倒档中间齿轮轴	Reverse middle gear shaft	1		√
3	LF481Q1-1701080A	倒档中间齿轮总成	Reverse middle gear assy.	1		√
4	LF481Q1-1701095A	倒档摆臂支架螺栓	Bolt	2	M8×22	√
5	LF481Q1-1701090A	倒档摆臂支架总成	Reverse swing arm bracket	1		√
6	LF481Q1-1701085A	倒档摆臂支架垫	Washer	1		√
7	LF481Q1-1701093A	复位扭簧	Spring	1	2.3×25.3×8.5×24.4	√

3.Chassis

3.01 发动机悬置 Engine mount



20



3.01 发动机悬置　Engine mount

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAL1001320	左悬置上连接支架	Left suspension bracket，upper	1		√


2	231-1025TF3	六角法兰面螺栓	Hex flange bolt	11		√
3	LAL1001330	左悬置下连接支架	Left suspension bracket，lower	1		√
4	133-1212	焊接方螺母	Nut	1		√
5	231-1292TF3	六角法兰面螺栓	Hex flange bolt	1		√
6	LAL1001310	发动机左悬置组件	Left suspension component	1		√
7	LAL1001340	左悬置支架	Left suspension bracket	1		√
8	LAL1001230	发动机后悬置支架组件	Rear suspension bracket	1		√
9	101-1212T2F3	六角法兰面螺母	Hex flange nut	1		√
10	231-12100TF3	六角法兰面螺栓	Hex flange bolt	1		√
11	LAL1001210	后悬置组件	Rear suspension component	1		√
12	214-1030TF30	六角头螺栓、弹簧垫圈和平垫圈组合	Hex bolt and washer	1		√
13	214-1035TF30	六角头螺栓、弹簧垫圈和平垫圈组合	Hex bolt and washer	2		√
14	Q33010T13F3	全金属六角法兰面锁紧螺母	Nut	1		√
15	LBA1001401	发动机右悬置连接支架	Right suspension bracket	1		√
16	LBA1001430	右悬置限位块	Right suspension stopper	1		√
17	LBA1001420	发动机右悬置组件	Right suspension component	1		√
18	Q1841025TF30	六角法兰面螺栓	Hex flange bolt	2		√
19	LBA1001410	发动机右悬置支架总成	Right suspension bracket	1		√
20	Q340B10	Ⅰ型六角螺母	Nut	3		√

3.01 发动机悬置　Engine mount


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
21	215-1035TF30	六角法兰面螺栓、弹簧垫圈和平垫圈组合	Hex flange bolt and washer	2		√

22	231-1040TF30	六角法兰面螺栓	Hex flange bolt	1		√
23	GB/T889.2	Ⅰ型非金属嵌件六角锁紧螺母（M10X1.25）	Nut	1	M10X1.25	√

3.02 前悬架 Front suspension







3.02 前悬架　Front suspension

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	Q150B0816TF30	六角头螺栓	Hex bolt	8		√

2	Q41908	锥形弹性垫圈	Taper elastic washer	8		√
3	Q3810T13F3	Ⅰ型非金属嵌件六角锁紧螺母	Nut	10		
4	Q40110	平垫圈	Flat washer	2		
5	L2906110	纵拉杆总成	Longitudinal tie assy.	2		√
6	Q1841065TF3	六角法兰面螺栓	Hex flange bolt	2		√
7	L2906014	右防尘罩	Right dust shield	1		√
8	Q32810T13F3	I型非金属嵌件六角锁紧螺母	Nut	2		√
9	L2901012	垫片	Washer	2		√
10	Q1841050TF3	六角法兰面螺栓	Hex flange bolt	2		√
11	231-1075TF3	六角法兰面螺栓	Hex flange bolt	2		√
12	Q32810T13F3	I型非金属嵌件六角锁紧螺母	Nut	2		√
13	L2904100	左摆臂总成	Left control arm assy.	1		
13	L2904200	右摆臂总成	Right control arm assy.	1		
13-1	Q2101030TF2	内六角花型圆柱头螺钉	Screw	6		√
13-2	Q40310	弹簧垫圈	Elastic washer	6		√
13-3	L2904120	球销总成	Ball joint assy.	2		√
13-4	Q32810T13F3	I型非金属嵌件六角锁紧螺母	Nut	6		√
13-5	L2904110	左摆臂	Left control arm	1		√
13-5	L2904210	右摆臂	Right control arm	1		√


3.02 前悬架　Front suspension

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
13-6	L2904130	隔离套总成	Spacer sleeve	2		

13-7	L2904140	缓冲件套总成	Buffer sleeve	2		
14	244-1295TF3	六角头螺栓	Hex bolt	2		√
15	Q40112T16F3	平垫圈	Flat washer	4		
16	197-1233T2F3	螺母	Nut	2		√
17	L2810109	支架总成	Bracket	2		√
18	Q1410820	六角头螺栓和锥形弹性垫合件	Hex bolt and taper elastic washer	4		√
19	L2906013	左防尘罩	Left dust shield	1		√
20	Q33810T13F3	非金属嵌件六角法兰面琐紧螺母	Nut	2		√
21	L2906120	橡胶块总成	Rubber block	2		√
22	L2906012	固定板	Fixing plate	2		√
23	Q40212	大垫圈	Washer	6		√
24	231-1270TF3	六角法兰面螺栓	Hex flange bolt	6		√
25	Q41910	锥形弹性垫圈	Taper elastic washer	2		√
26	231-1020T1F3	六角法兰面螺栓	Hex flange bolt	2		√
27	LBA2810100	副车架总成	Sub-frame assy.	1		√
28	175-1212T13F3	方螺母	Nut	2		√
29	L2906011	横向稳定杆	Stabilizer bar，front suspension	1		√

3.03 前减振器　Front shock absorber






3.03 前减振器　Front shock absorber

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LBA2905100	左前减振器总成	Left front shock absorber assy.	1		√

1	LBA2905200	右前减振器总成	Right front shock absorber assy.	1		√
1-1	LBA2905110	左前减振器	Left front shock absorber	1		√
1-1	LBA2905210	右前减振器	Right front shock absorber	1		√
1-2	L2905104	前缓冲块	Front bumper block	2		√
1-3	L2905103	前减振器保护套	Front shock absorber sleeve	2		√
1-4	Q40114F34	平垫圈	Flat washer	2		
1-5	L2905101	前悬架螺旋弹簧	Front shock absorber spring	2		√
1-6	L2905102	弹簧上支架	Spring bracket	2		√
1-7	L2905105	止推球轴承	Ball bearing	2		√
1-8	L2905106	前减振器连接板	Front shock absorber connect plate	2		√
1-9	L2905107	减压限位罩	Stop washer	2		√
1-10	Q33014T13F3	全金属法兰面自锁螺母	Nut	2		
2	L2905111	前减震器防水胶套	Front shock absorber waterproof	2		√

3.04 后悬架 Rear axle





3.04 后悬架　Rear axle

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L2916100	后桥总成	Rear axle assy.	1		√


1	L2916100B1	后桥总成	Rear axle assy.	1	Improved	√
1-1	L2916109	后桥轴管左支架	Stabilizer bar bracket，left	1		
1-2	Q340B08	Ⅰ型六角螺母	Nut	2		√
1-3	Q40308	弹簧垫圈	Elastic washer	2		√
1-4	Q40108	平垫圈	Flat washer	2		√
1-5	L2916103	前扭杆	Front torsion-bar	1		√
1-6	L2916120	横向稳定杆	Stabilizer bar，rear axle	1		√
1-7	L2916111	油封	Seal	2		√
1-8	L2916110	管形横梁总成	Tubular beam assy.	1		√
1-9	L2916104	后扭杆	Rear torsion-bar	1		√
1-10	L2916112	后桥轴管右支架	Stabilizer bar bracket，right	1		
1-11	Q2630620	十字槽沉头自攻锁紧螺钉	Screw	2		
1-12	L2916102	限位高度调节块	Stopper height adjuster	2		√
1-13	L2916105	右护板	Right side plate，rear swing arm	1		√
1-14	Q1410825L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	2		√
1-15	L2916151	护板垫片	Side plate washer	2		√
1-16	L2916153	护板衬套	Side plate sleeve	2		√
1-17	L2916107	内轴承	Inner bearing	2		√
1-18	L2916108	外轴承	Outer bearing	2		√


3.04 后悬架　Rear axle

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1-19	L2916140	右后摆臂	Right rear swing arm	1		√

1-20	L2916115	后轴	Rear pin	2		
1-22	Q32814T13F3	Ⅰ型非金属嵌件六角锁紧螺母	Nut	2		
1-23	Q40114	平垫圈	Flat washer	2		√
1-24	L2916101	左护板	Left side plate，rear swing arm	1		√
1-25	L2916130	左后摆臂	Left rear swing arm	1		√
1-26	Q151B14115TF3	六角头螺栓	Hex bolt	2		
1-27	L2916125	横向稳定杆防尘堵盖	Stabilizer bar plug	2		
2	L2920102	限位块壳	Stopper shuck	2		√
3	Q1410825L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	2		√
4	L2920101	限位块	Stopper	2		√

3.05






3.05 托架　Rear axle bracket

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L2915100	托架总成	Rear axle bracket assy.	1		

1-1	Q33010T13F3	全金属六角法兰面锁紧螺母	Nut	4		√
1-2	L2915150	前左弹性缓冲块总成	Front left bumper block	1		√
1-2	L2915160	前右弹性缓冲块总成	Front right bumper block	1		√
1-3	Q151B1290TF3	六角头螺栓	Hex bolt	4		√
1-4	Q40112	平垫圈	Flat washer	10		√
1-5	Q151B1265TF3	六角头螺栓	Hex bolt	2		√
1-6	L2915130	后减振器	Rear shock absorber	2		√
1-7	Q33010T13F3	全金属六角法兰面锁紧螺母	Nut	2		√
1-8	L2915110	左支架	Left bracket	1		√
1-8	L2915120	右支架	Right bracket	1		√
1-9	113-1216T13F3	Ⅰ型非金属嵌件六角锁紧螺母	Nut	6		√
1-10	L2915140	后弹性缓冲块总成	Rear bumper block	2		√
1-11	Q33810T13F3	非金属嵌件六角锁紧螺母	Nut	2		√

3.06 转动轴　Axle shaft





3.06 转动轴　Axle shaft


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAL2203100	左传动轴总成	Left axle shaft assy.	1		√

2	LAL2203200	右传动轴总成	Right axle shaft assy.	1		√
3	SLAL22001	差速器侧万向节维修包（左）	Joint kit，differential，left	1		√
4	SLAL22002	差速器侧防护罩维修包	Seal kit，differential	2		√
5	SLAL22003	车轮侧万向节维修包	Joint kit，wheel	2		√
6	SLAL22004	车轮侧防护罩维修包	Seal kit，wheel	2		√
7	SLAL22005	差速器侧万向节维修包(右)	Joint，differential，right	1		√
8	SLAL22006	螺母组件	Nuts kit	1		√

3.07 换挡机构 Shift mechanism







3.07 换挡机构　Shift mechanism

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX1703120B02	换挡手柄球	Gear shift handle	1		√

2	LAX1703160C02	换档皮套带卡圈组件	Gear shift sleeve and circlip	1		√
2	LAX1703160B1C02	换档皮套带卡圈组件	Gear shift sleeve and circlip	1	improved，bigger	√
2-1	LAX1703102B02	换档皮套	Gear shift sleeve	1		√
2-2	LAX1703107C02	换档皮套卡圈	Gear shift sleeve circlip	1		√
2-2	LAX1703107B1C02	换档皮套卡圈	Gear shift sleeve circlip	1	improved，bigger	√
3	L1703100	换档支座总成	Gearshift mount assy.	1		√
3-1	L1703103	皮套扎带	Gear shift sleeve belt	1		√
3-2	L1703130	换档手柄杆	Gear shift lever	1		
3-3	L1703112	锁紧套	Lock sleeve	1		
3-4	Q43680	挡圈	Circlip	1		
3-5	Q40404	弹簧垫圈	Elastic washer	1		
3-6	Q40004	小垫圈	Washer	1		
3-7	Q2713595	十字槽盘头自攻螺钉	Screw	1		
3-8	L1703111	壳体	Gearshift mount	1		
3-9	L1703114	减振套	Damper sleeve	4		
3-10	L1703113	支座安装轴承	Gearshift mount bearing	4		
3-11	Q40008	小垫圈	Washer，Gearshift mount	1		√
3-12	L1703221	小胶套	Little sleeve	2		
3-13	L1703117	回位弹簧	Retain spring	1		


3.07 换挡机构　Shift mechanism

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
3-14	L1703118	大胶套	Sleeve	1		

3-15	L1703116	摇位臂	Swing arm，Gearshift mount	1		
3-16	L1703115	换档摇臂回转销	Swing arm pin	1		
4	Q33008T13F3	全金属六角法兰面锁紧螺母	Nut	4		√
5	Q5002020	开口销	Cotter pin	1		√
6	Q40008	小垫圈	Washer，Gearshift mount	1		√
7	Q1410825L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	2		√
8	L1703017	E型卡	“E” Clip	2		√
9	L1703016	变速拉索接头固定卡	End clip，gear shift cable	2		√
10	L1703012	卡片	Clip	2		√
11	LAL1703200	换、选档软轴总成	Gear shift cable	1		√
11-1	L1703216	弹性卡子	Elastic clip	1		
11-2	L1703232	密封胶套压板	Seal plate	1		
11-3	L1703212	大振减胶套	Damper sleeve	1		
11-4	L1703222	振减胶套	Damper sleeve	1		

3.08 离合操纵机构 Clutch mechanism





3.08 离合操纵机构　Clutch mechanism

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L1602100	离合踏板总成	Clutch pedal assy.	1		√

1-1	L1602140	离合踏板支架组件	Clutch pedal bracket	1		
1-2	Q150B0870	六角头螺栓	Hex bolt	1		
1-3	L1602105	撑管	Pin	1		
1-4	L1602102	档套	Sleeve	2		
1-5	Q32808	Ⅰ型非金属嵌件六角锁紧螺母	Nut	1		√
1-6	L1602110	离合踏板组件	Clutch pedal	1		
1-7	L1602107	踏板套	Pedal sleeve	1		√
2	L1608000	离合器总泵	Clutch master cylinder	1		√
2-1	L1608016	推杆叉	Push rod fork	1		
2-2	Q340B08	Ⅰ型六角螺母	Nut	1		√
3	Q32206	六角螺母和锥形弹性垫圈组合件	Hex nut and taper elastic washer	2		√
4	Q32808T13F3	Ⅰ型非金属嵌件六角锁紧螺母	Nut	2		√
5	L1600012	缓冲垫	Damper washer	1		√
6	Q67516	A型蜗杆传动式软管环箍	Hoop	1		√
7	Q673B13	钢带型弹性环箍	Hoop	1		√
8	L1607011	软管	Hose	1		√
9	L1600014	垫密圈	Ring seal	2		√
10	221-1022	带孔螺栓	Eye bolt	1		√
11	LAL1607100B1	软管总成	Clutch hose assy.	1		√

3.08 离合操纵机构　Clutch mechanism

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
12	L1600013	卡片	Clip	1		√


13	L1602130	垫片	Washer	2		√
14	Q40010	小垫圈	Washer	1		√
15	Q5003230	开口销	Cotter pin	1		√
16	L1602120	销轴	Axle pin	1		√

3.09









3.09 转向系统　Steering system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LBA3408000	转向动力泵储油罐	Steering oil reservior	1		√

1-1	LBA3408012	转向动力泵储油罐盖	Steering oil reservior cap	1		√
2	Q67516	A型蜗杆传动式软管环箍	Hoop	2		√
3	LBA3406300B1	转向器回油管总成	Steering oil return pipe assy.	1		√
4	Q67525	A型蜗杆传动式软管环箍	Hoop	2		√
5	LBA3406100B1	转向油泵进油管	Steering pump oil inlet pipe	1		√
6	L3612340	动力转向开关组件	Power steering switch	1		√
7	Q32810T13F3	I型非金属嵌件六角锁紧螺母	Nut	2		√
8	Q40010	小垫圈	Washer	2		√
9	LBA3406200B1	转向器进油管总成	Steering gear oil inlet pipe	1		√
10	LBA3407100	动力转向油泵总成	Power steering pump	1		√
10-1	Q150B1030	六角头螺栓	Hex bolt	1		
10-2	Q40310	弹簧垫圈	Elastic washer	1		√
10-3	507-1024	平垫圈	Flat washer	1		√
10-4	LBA3407110	动力转向油泵皮带轮	Power steering pump pulley	1		
10-5	Q1460816	六角头螺栓、弹簧垫圈和平垫圈组合	Hex bolt and washer	3		
11	LBA3407102	转向油泵调节支架	Power steering pump adjuster	1		√
12	231-1020TIF3	六角法兰面螺栓	Hex flange bolt	2		√
13	LBA3407103	皮带	Pulley belt	1		√
14	LBA3407101	转向油泵支架	Power steering pump bracket	1		√

3.09 转向系统　Steering system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
14-1	Q150B1080	六角头螺栓	Hex bolt	1		

14-2	Q40310	弹簧垫圈	Elastic washer	1		√
14-3	Q340B10	Ⅰ型六角螺母	Nut	1		√
14-4	LBA3407101	转向油泵支架座	Power steering pump mount	1		√
15	Q1410825L	六角头螺栓和锥形弹性垫圈组合	Hex bolt and taper elastic washer	2		√
16	231-1025T1F3	六角法兰面螺栓	Hex flange bolt	1		√
17	231-1075TF3	六角法兰面螺栓	Hex flange bolt	2		√
18	Q33008T13F3	全金属六角法兰面锁紧螺母	Nut	1		√
19	Q1410840TF3	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	2		√
20	Q1410616L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	2		√
21	204-0825T1F3	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	4		√
22	LBA3406821	转向回油管支架Ⅱ	Steering oil return pipe bracket II	1		√
22-1	L3406304	回油管橡胶套	Steering oil return pipe sleeve	2		√
22-2	L3406201	转向器回油管卡	Steering oil return pipe clip	1		
22-3	L3406301	转向器回油管支架	Steering oil return pipe bracket	1		√
22-4	Q1410616L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	1		√
22-5	Q340B06	Ⅰ型六角螺母	Nut	1		√
23	Q40206	大垫圈	Washer	2		√
24	Q32208T13F3	六角螺母和锥形弹性垫圈组合件	Hex nut and taper elastic washer	2		√
25	LAX3403100	转向管柱支架总成	Steering gear bracket	1		√


3.09 转向系统　Steering system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
26	Q33006	全金属六角法兰面锁紧螺母	Nut	2		√

27	204-0870T1F3	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	1		√
28	204-0885T1F3	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	1		√
29	L3404300	转向轴防尘套	Steering gear dust sleeve	1		√
30	L3404100	上转向轴总成	Upper steering shaft assy.	1	Union	√
30	L3404100B1	上转向轴总成	Upper steering shaft assy.	1	Henglong	√
31	L3404200	下转向轴总成	Lower steering shaft assy.	1	Union	√
31	L3404200B1	下转向轴总成	Lower steering shaft assy.	1	Henglong	√
32	199-10115T1F3	方锁紧螺母	Nut	2		√
33	L3401011	长方平垫圈	Square washer	2		√

3.10 [illegible]






3.10 助力转向器　Steering gear


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L3411000	动力转向器总成	Steering gear assy.	1		√

1-1	L3411210	外球节总成	Tie rod，outer	2		√
1-2	L3411201	六角螺母	Nut	2		
1-3	L3411220	内球节总成	Tie rod，inner	2		√
1-4	L3411202	齿条防护罩	Gear rack guard	2		√
1-5	L3411203	单耳无级卡箍	Hoop	2		√
1-6	L3411310	左油管总成	Left oil pipe，steering gear	1		√
1-7	L3411320	右油管总成	Right oil pipe，steering gear	1		√

3.11







3.11 供给系装置　Fuel supply system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	Q67512	A型蜗杆传动式软管环箍	Hoop	13		√

2	LBA1130107C1	软管V	Hose V	1	National III emission	√
3	LBA1130310	碳罐电磁阀	Canister control valve	1	delphi	√
3	LBA1130310B1	碳罐电磁阀	Canister Control Valve	1	Sun&teck	√
3-1	LBA1130311B1	碳罐电磁阀固定胶套	Canister control valve sleeve	1		
4	LBA1130108	软管VI	Hose VI	1		√
4	LBA1130108C1	软管VI	Hose VI	1	National III emission	√
5	L1130200	碳罐总成	Canister	1		√
6	Q673B13	钢带弹性环箍	Hoop	1		√
7	L1130111C1	碳罐接大气软管	Canister hose	1	National III emission	√
8	LBA1104120D1	出油软管III总成	Fuel outlet hose III	1	MABS	√
8	LBA1104120C1	出油软管III总成	Fuel outlet hose III	1	National III emission	√
9	BL247	扎带	Tie	2		√
10	LBA1130130C1	软管IV总成	Hose IV	1	National III emission	√
11	L1104015	塑料卡扣	Plastic clip	2		
12	L1104012	硬管管卡	Tube clip	11		√
13	L1104140C1	出油塑料硬管总成	Fuel outlet plastic tube	1	National III emission	√
14	L1130120C1	塑料硬管总成	Plastic tube	1	National III emission	√
15	L1130101C1	软管I	Hose I	1	National III emission	√
16	L1104011C1	油箱出气连接软管	Fuel tank hose	1	National III emission	√


3.11 供给系装置　Fuel supply system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
17	Q67525	A型蜗杆传动式软管环箍	Hoop	2		√

18	L1104110C1	出油软管I总成	Fuel outlet hose I	1	National III emission	√
19	L1104130C1	回油软管总成	Fuel return hose	1	National III emission	√
20	L1117100	汽油滤清器总成	Fuel filter	1		√
20	L1104101C1	出油软管II	Fuel outlet hose II	1	National III emission	√
21	L1104101C1	出油软管II	Fuel outlet hose II	1	National III emission	√
22	Q67407100	塑料紧箍带	Tie	1		√
23	Q32206	六角螺母和锥形弹性垫圈组合件	Hex nut and taper elastic washer	1		√
24	LCA1101200C1	加注管总成	Fuel filler pipe assy.	1		√
24-1	LCA1101210	加油口盖组件	Fuel filler cap	1		√
24-2	LCA1101242	加油口护罩上卡簧	Fuel filler cap sleeve circlip，upper	1		
24-3	LCA1101241	加油口护罩	Fuel filler cap sleeve	1		
24-4	LCA1101243	加油口护罩下卡簧	Fuel filler cap sleeve circlip，lower	1		
24-5	LCA1101251C1	加注管	Fuel filler pipe	1		
24-6	L1101205	软管III	Hose III	1		√
24-7	L1101204	软管 II	Hose II	1		√
24-8	L1101201	注油口与油箱连接软管	Hose connecting fuel filler and tank	1		√
24-9	Q67529	A型蜗杆传动式软管环箍	Hoop	2		
24-10	Q673B12	钢带型弹性环箍	Hoop	2		√

3.12 空气滤清器装置 Air filt






3.12 空气滤清器装置　Air filter

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LBA1109100	空气滤清器总成	Air filter	1		√

1-1	LBA1109120	上壳体总成	Air filter shell,upper	1		√
1-2	LBA1109102	滤芯总成	Air filter element	1		√
1-3	LBA1109110	下壳体总成	Air filter shell,lower	1		√
2	Q1840830	六角法兰面螺栓	Bolt,Intake manifold	3		√
3	Q1840816	六角法兰面螺栓	Bolt	3		√
4	Q33010T13F3	全金属六角法兰面锁紧螺母	Nut	3		√
5	LBA1109200	空气滤清器支架	Air filter bracket	1		√
6	LBA1109010	发动机进气连接管	Engine section pipe	1		√
6-1	LBA1109012	曲轴箱通风管	Crank case tube	1		√
6-2	Q67570	A型蜗杆传动式软管环箍	Hoop	2		

3.13






3.13 油门操纵机构　Accelerator mechanism

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L1108100	油门踏板带支架和铰座总成	Accelerator pedal assy.	1		√

1	LBA1108100	油门踏板带支架和铰座总成	Accelerator pedal assy.	1	connection improved	
1-1	L1108103	油门踏板支架	Accelerator pedal bracket	1		
1-2	L1108110	油门踏板臂	Accelerator pedal	1		
1-3	L1108104	弹簧	Spring	1		
1-4	L1108101	踏板套	Accelerator pedal sleeve	1		√
1-5	L1108105	轴套	Axle sleeve	2		
1-6	L1108102	减震垫	Damper	1		
1-7	Q43660	开口挡圈	Cotter circlip	1		
2	Q33006	全金属六角法兰面锁紧螺母	Nut	3		√
3	LBA1108300B1	油门拉索总成	Accelerator cable	1		√
3	LBA1108300C1	油门拉索总成	Accelerator cable	1	connection improved	
3	LBA1108300A2	油门拉索总成	Accelerator cable	1	with stop spring,for RUS	√

3.14





3.14 燃油箱　Fuel tank


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L1101100C1	燃油箱总成	Fuel tank	1	National III emission，Shichang	√

1	L1101100B1	燃油箱总成	Fuel tank	1	Flat bottomed	√
1	L1101100D1	燃油箱总成	Fuel tank	1	National III emission，Dongfang	√
1-1	L1101104	燃油泵压紧盖密封垫	Fuel pump cap seal	1		√
1-2	L1101101	燃油泵压紧盖	Fuel pump cap	1	huangyan	√
1-2	L1101101C1	燃油泵压紧盖	Fuel pump cap	1	shichang	√
1-2	L1101101D1	燃油泵压紧盖	Fuel pump cap	1	dongfang	√
1-3	L1101102	传感器压紧盖	Fuel level sensor cap	1	huangyan	√
1-3	L1101102C1	传感器压紧盖	Fuel level sensor cap	1	shichang	√
1-3	L1101102D1	传感器压紧盖	Fuel level sensor cap	1	dongfang	√
1-4	L1101103	传感器压紧盖密封件	Fuel level sensor cap seal	1		√
2	L1123100	电子燃油泵总成	Fuel pump	1		√
3	L3614100	燃油油量传感器	Fuel level sensor	1		√
4	L1101015	大垫圈	Washer	1		√
5	Q1410825L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	3		√
6	L1101012	锁紧片	Locker	4		√
7	L1101013	油箱侧面托架	Fuel tank side bracket	1		√
8	Q33008T13F3	全金属六角法兰面锁紧螺母	Nut	1		√
9	L1101014B1	油箱中心托架	Fuel tank side bracket	1	Flat bottomed	√

3.15







3.15 制动系统　Brake system（EABS）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	Q1840620	六角法兰面螺栓	Hex flange bolt	3		√

2	L3550011B1	橡胶垫	Rubber pad	3	APG&TRW	√
2	L3550011	橡胶垫	Rubber pad	3		√
3	271-0616TF3	内六角螺栓	Hex bolt	3		√
4	LBA3550200B1	ABS支架总成	ABS bracket	1	APG	√
5	L3550100	ABS控制单元HECU	ABS HECU	1	wanxiang	√
5	L3550100B1	ABS控制单元HECU	ABS HECU	1	APG	
6	LBA3506120	制动硬管Ⅰ	Brake tube I	1	wanxiang	√
6	LBA3506120B1	制动硬管Ⅰ	Brake tube I	1	APG	√
7	LBA3506110	制动硬管	Brake tube	1	wanxiang	√
7	LBA3506110B1	制动硬管	Brake tube	1	APG	√
7	LBA3506110F1	制动硬管	Brake tube	1	for plastic in-manifold	√
8	LBA3506140B1	制动硬管Ⅲ	Brake tube III	1		√
9	L3506106	E型卡片	“E” clip	6		√
10	L3506107	管夹Ⅰ	Tube clip I	2		√
11	L3506113	管夹Ⅶ	Tube clip VII	4		√
12	L3506180	前制动软管总成	Front brake hose	2		√
13	L3506102	前制动软管右支架	Front brake hose bracket，right	1		√
14	Q1410820	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	2		√
15	Q33005	全金属六角法兰面锁紧螺母	Nut	2		√

3.15 制动系统　Brake system（EABS）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
16	Q1410512L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	2		√


17	L3506111	管夹Ⅴ	Tube clip V	2		√
18	L3506162	二通阀	Twoway valve	2		√
19	Q33006	全金属六角法兰面锁紧螺母	Nut	2		√
20	L3506151	制动硬管	Brake tube	1	wanxiang	√
20	L3506151B1	制动硬管	Brake tube	1	APG	√
21	LBA3506161B1	制动硬管	Brake tube	1		√
22	LBA3506130	制动硬管Ⅱ	Brake tube II	1	wanxiang	√
22	LBA3506130B1	制动硬管Ⅱ	Brake tube II	1	APG	√
23	L3506112	管夹Ⅵ	Tube clip VI	6		√
24	L3506101	前制动软管左支架	Front brake hose bracket，left	1		√
25	Q67407100	塑料紧箍带	Tie	2		√
26	L3781120	制动灯开关	Brake light switch	1		√
27	Q32008	六角法兰面螺母	Hex flange nut	4		√
28	L3506164	制动硬管	Brake tube	1		√
29	L3506152	制动硬管	Brake tube	1		√
30	L3506108	管夹Ⅲ	Tube clip III	12		√
31	LAX3508300	驻车制动操纵杆总成	Parking brake lever assy.	1		√
31-1	LAX3508320	驻车制动操纵杆组件	Parking brake lever	1		
31-2	L3508310	平衡块	Balance weight	1		√


3.15 制动系统　Brake system（EABS）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
31-3	Q32808	Ⅰ型非金属嵌件锁紧螺母	Nut	1		√

32	Q33008T13F3	全金属六角法兰面锁紧螺母	Nut	3		√
33	L3508100B2	驻车制动左拉索总成	Parking brake cable，left	1		√
34	L3508200B2	驻车制动右拉索总成	Parking brake cable，right	1		√
35	L3508013	驻车制动拉索导向支架	Parking brake cable guide	1		√
36	Q33006	全金属六角法兰面锁紧螺母	Nut	2		√
37	L3506163	制动硬管	Brake tube II，rear part	1		√
38	L3508012	右拉索支架	Parking brake right cable bracket	1		√
39	131-2216T2F3	六角凸缘螺母	Nut	2	CSG TRW	√
39	131B-2216T2F3	六角凸缘螺母	Nut	2		√
40	L3506115B1	制动硬管Ⅴ	Brake tube V	1		√
41	L3506104	后制动软管右支架	Rear brake hose bracket，right	1		√
42	L3506190	后制动软管总成	Rear brake hose	2		√
43	L3506103	后制动软管左支架	Rear brake hose bracket，left	1		√
44	L3508011	左拉索支架	Parking brake left cable bracket	1		√
45	L3506170B1	制动硬管Ⅵ	Brake tube VI	1		√

3.10





3.16 制动系统（机械ABS）Brake system（MABS）


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L3506151D1	制动硬管	Brake tube	1		√

2	L3506112	管夹Ⅵ	Tube clip VI	6		√
3	L3506111	管夹Ⅴ	Tube clip V	4		√
4	Q1840835TF3	六角法兰面螺栓	Hex flange bolt	1		√
5	L3550400	比例阀	Proportional valve	1		√
6	L3550500	比例阀支架	Proportional valve bracket	1		√
6	L3550500B1	比例阀支架	Proportional valve bracket	1	CSG TRW	√
7	L3506131D1	制动管II前段	Brake tube II，fore part	1		√
8	L3506121D1	制动管I前段	Brake tube I，fore part	1		√
9	L3506124D1	制动硬管	Brake tube	1		√
10	L3506134D1	制动硬管	Brake tube	1		√
11	L3506140D1	制动硬管III	Brake tube III	1		√
12	L3550300D1	MABS	MABS	2		√
13	Q33008T13F3	全金属六角法兰面锁紧螺母	Nut	2		√
14	L3506122D1	二通阀	Twoway valve	2		√
15	L3506123D1	制动管I后段	Brake tube I，rear part	2		√
16	L3506132D1	制动管II中段	Brake tube II，fore part	1		√

3.1









3.17 制动系统（比例阀） Brake system（proportional valve）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L3506151D1	制动硬管	Brake tube	1		√

2	L3506140D1	制动硬管III	Brake tube III	1		√
3	Q1840835TF3	六角法兰面螺栓	Hex flange bolt	1		√
4	L3550400	比例阀	Proportional valve	1		√
5	L3550500	比例阀支架	Proportional valve bracket	1		√
5	L3550500B1	比例阀支架	Proportional valve bracket	1	CSG TRW	√
6	L3506123D1	制动管I后段	Brake tube I，rear part	1		√
7	L3506132D1	制动管II中段	Brake tube II，fore part	1		√
8	L3506135E1	制动硬管VIII	Brake tube VIII	1		√
9	L3506125E1	制动硬管VII	Brake tube VII	1		√

3.18 制动






3.18 制动总泵带助力器装置　Brake pump

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L3540000	制动总泵带助力器带油壶总成	Brake pump assy.	1		√

1-1	SL35400	制动总泵带油壶组件维修包	Brake pump with reservior	1		√
1-1-1	L3540200	制动油壶总成	Brake oil reservior	1		√
1-1-1-1	L3540210	制动油壶盖	Brake oil reservior cap	1		√
1-1-2	L3540112	密封圈	Ring seal	2		√
1-2	L3540120	制动助力器	Brake booster	1		√
1-3	L3540122	凸缘螺母	Nut	1		
1-4	L3540130	制动助力器连接真空管组件	Brake booster junction	1		
2	Q5100824	销轴	Pin	1		√
3	Q41808	波形弹性垫圈	Elastic washer	1		√
4	Q40108	平垫圈	Flat washer	1		√
5	Q5003220	开口销	Cotter pin	1		√
6	LBA3540011	发动机连接管	Engine connecting pipe	1		√
6	LBA3540011B1	发动机连接管	Engine connecting pipe	1	for plastic in-manifold	√
7	Q67516	A型蜗杆传动式软管环箍	Hoop	2		√

3.19






3.19 制动踏板装置　Brake pedal

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L3504001	制动踏板装置	Brake pedal mechanism	1		√

1	LBX3504001	制动踏板装置	Brake pedal mechanism	1	for ACS	√
1-1	Q198B0620	承面凸焊螺栓	Bolt	6		√
1-2	L3504100	制动踏板支架组件	Brake pedal bracket assy.	1		
1-2-1	L3504101	支架座	Brake pedal bracket seat	1		
1-2-2	L3504102	支架	Brake pedal bracket	1		
1-2-3	L3504103	限位支架	Stopper bracket	1		
1-3	Q150B0875	六角头螺栓	Hex bolt	1		
1-4	Q32808	Ⅰ型非金属嵌件六角锁紧螺母	Nut	1		√
1-5	L3504013	隔音垫	Noise insulator	1		√
1-6	L3504012	制动踏板导管套	Brake pedal shaft sleeve	2		√
1-7	L3504200	制动踏板总成	Brake pedal assy.	1		√
1-7-1	L3504201	踏板转动管	Brake pedal shaft	1		
1-7-2	I3504204	制动踏板	Brake pedal	1		
1-7-3	L3504203	限位块	Stopp block	1		
1-7-4	L3504205	踏板套	Brake pedal sleeve	1		√
1-8	L3504011	制动踏板导管	Brake pedal shaft core	1		
1-9	Q33008T13F3	全金属六角法兰面锁紧螺母	Nut	4		√

3.20





3.20 前制动器　Front brake

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L3501100	左前制动器带转向节总成	Left front brake with knuckle assy.	1	wanxiang	√

1	LAL3501100	左前制动器带转向节总成	Left front brake with knuckle assy.	1	CSG TRW	√
1	L3501200	右前制动器带转向节总成	Right front brake with knuckle assy.	1	wanxiang	√
1	LAL3501200	右前制动器带转向节总成	Right front brake with knuckle assy.	1	CSG TRW	√
1-1	L3501110	左前制动器卡钳总成	Left front brake caliper assy.	1	wanxiang	√
1-1	LAL3501110	左前制动器卡钳总成	Left front brake caliper assy.	1	CSG TRW	√
1-1	L3501210	右前制动器卡钳总成	Right front brake caliper assy.	1	wanxiang	√
1-1	LAL3501210	右前制动器卡钳总成	Right front brake caliper assy.	1	CSG TRW	√
1-1-1	L3501124	轴销螺钉	Bolt	4	wanxiang	√
1-1-1	LAL3501124	轴销螺钉	Bolt	4	CSG TRW	√
1-1-2	L3501122	轴销	Axle pin	4	wanxiang	√
1-1-2	LAL3501122	轴销	Axle pin	4	CSG TRW	√
1-1-3	L3501111	放气螺钉	Venting screw	2	wanxiang	√
1-1-3	LAL3501111	放气螺钉	Venting screw	2	CSG TRW	√
1-1-4	L3501112	放气螺钉罩	Venting screw cap	2	wanxiang	√
1-1-4	LAL3501112	放气螺钉罩	Venting screw cap	2	CSG TRW	√
1-1-5	L3501120	左前制动卡钳组件	Left front brake caliper	1	wanxiang	
1-1-5	LAL3501120	左前制动卡钳组件	Left front brake caliper	1	CSG TRW	
1-1-5	L3501220	右前制动卡钳组件	Right front brake caliper	1	wanxiang	
1-1-5	LAL3501220	右前制动卡钳组件	Right front brake caliper	1	CSG TRW	

3.20 前制动器　Front brake

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1-1-6	L3501123	轴销防尘套	Axle pin sleeve	4	wanxiang	√


1-1-6	LAL3501123	轴销防尘套	Axle pin sleeve	4	CSG TRW	√
1-1-7	LAL3501121	卡钳支架(左)	Caliper bracket left	1	CSG TRW	√
1-1-7	L3501121	卡钳支架(左)	Caliper bracket left	1	wanxiang	√
1-1-7	LAL3501221	卡钳支架(右)	Caliper bracket right	1	CSG TRW	√
1-1-7	L3501221	卡钳支架(右)	Caliper bracket right	1	wanxiang	√
1-2	L3001104	挡圈	Circlip	2	wanxiang	√
1-2	LAL3001104	挡圈	Circlip	2	CSG TRW	√
1-2	L3001104B1	挡圈	Circlip	2	wanxiang improved	√
1-3	L3001103	前轮毂轴承	Front hub bearing	2	wanxiang	√
1-3	LAL3001103	前轮毂轴承	Front hub bearing	2	CSG TRW	√
1-3	L3001103B1	前轮毂轴承	Front hub bearing	2	wanxiang improved	√
1-4	L3001101	左转向节	Left knuckle	1	wanxiang	√
1-4	LAL3001101	左转向节	Left knuckle	1	CSG TRW	√
1-4	L3001101B1	左转向节	Left knuckle	1	wanxiang improved	√
1-4	L3001201	右转向节	Right knuckle	1	wanxiang	√
1-4	LAL3001201	右转向节	Right knuckle	1	CSG TRW	√
1-4	L3001201B1	右转向节	Right knuckle	1	wanxiang improved	√
1-5	L3001102	前轮毂	Front hub	2	wanxiang	√
1-5	LAL3001102	前轮毂	Front hub	2	CSG TRW	√


3.20 前制动器　Front brake

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1-5	L3001102B1	前轮毂	Front hub	2	wanxiang improved	√

1-6	L3501101	制动盘	Brake disc	2	wanxiang	√
1-6	LAL3501101	制动盘	Brake disc	2	CSG TRW	√
1-7	L3501105	沉头螺钉	Screw	4	wanxiang	√
1-7	LAL3501105	沉头螺钉	Screw	4	CSG TRW	√
1-8	SL35002	制动片（1车付）	Brake lining suite（4 pcs）	1	M-wear warning	√
1-8	SL35003	制动片（1车付）	Brake lining suite（4 pcs）	1	E-wear warning	
1-8	SLAL35002	制动片（1车付）	Brake lining suite（4 pcs）	1	CSG TRW，E-wear warning	
1-8	SL35001	制动片（1车付）	Brake lining suite（4 pcs）	1	honeywell，E-wear warning	√
1-8	SL35005	制动片（1车付）	Brake lining suite（4 pcs）	1	honeywell，M-wear warning	√
1-9	L3501103	卡钳紧固螺栓	Caliper bolt	4	wanxiang	√
1-9	LAL3501103	卡钳紧固螺栓	Caliper bolt	4	CSG TRW	√
1-10	L3501104	垫圈	Washer	4	wanxiang	√
1-10	LAL3501104	垫圈	Washer	4	CSG TRW	√

3.21





3.21 后制动器　Rear brake

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L3502190	左后制动底板带制动蹄组件	Left rear brake assy.	1	wanxiang	√

1	LAL3502190	左后制动底板带制动蹄组件	Left rear brake assy.	1	CSG TRW	√
1	L3502290	右后制动底板带制动蹄组件	Right rear brake assy.	1	wanxiang	√
1	LAL3502290	右后制动底板带制动蹄组件	Right rear brake assy.	1	CSG TRW	√
1-1	L3502110	左后制动底板总成	Left backing plate	1	wanxiang	√
1-1	LAL3502110	左后制动底板总成	Left backing plate	1	CSG TRW	√
1-1	L3502210	右后制动底板总成	Right backing plate	1	wanxiang	√
1-1	LAL3502210	右后制动底板总成	Right backing plate	1	CSG TRW	√
1-2	L3502150	制动轮缸总成	Brake wheel cylinder	2	wanxiang	√
1-2	LAL3502150	制动轮缸总成	Brake wheel cylinder	2	CSG TRW	√
1-2-1	L3502152	放气螺钉罩	Venting screw cap	2	wanxiang	√
1-2-1	LAL3502152	放气螺钉罩	Venting screw cap	2	CSG TRW	√
1-2-2	L3502151	放气螺钉	Venting screw	2	wanxiang	√
1-2-2	LAL3502151	放气螺钉	Venting screw	2	CSG TRW	√
1-3	L3502154	轮缸固定螺钉	Brake wheel cylinder bolt	4	wanxiang	√
1-3	LAL3502154	轮缸固定螺钉	Brake wheel cylinder bolt	4	CSG TRW	√
1-4	L3502153	弹性垫圈	Elastic washer	4	wanxiang	√
1-4	LAL3502153	弹性垫圈	Elastic washer	4	CSG TRW	
1-5	L3502141	观察孔塞	Plug	2	wanxiang	
1-5	LAL3502141	观察孔塞	Plug	2	CSG TRW	

3.21 后制动器　Rear brake

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1-6	L3502140	复位弹簧组件	Retain spring	2	wanxiang	√


1-7	L3502230	右调整组件	Right adjusting components	1	wanxiang	√
1-7	L3502130	左调整组件	Left adjusting components	1	wanxiang	√
1-8	L3502196	上拉力弹簧	Spring	2	wanxiang	√
1-8	LAL3502196	上拉力弹簧	Spring	2	CSG TRW	√
1-9	SL35004	制动蹄（1车副）	Left brake shoe（suite）	1	wanxiang	√
1-9	SLAL35004	制动蹄（1车副）	Left brake shoe（suite）	1	CSG TRW	
1-10	L3502146	下拉力弹簧	Spring	2	wanxiang	
1-10	LAL3502146	下拉力弹簧	Spring	2	CSG TRW	
2	L3502120	后制动鼓总成	Brake drum assy.	2	wanxiang	√
2	LAL3502120	后制动鼓总成	Brake drum assy.	2	CSG TRW	√
2-1	L3502125	轮毂密封垫圈	Hub seal	2	wanxiang	√
2-1	LAL3502125	轮毂密封垫圈	Hub seal	2	CSG TRW	√
2-2	L3502123	隔套	Spacer	2	wanxiang	√
2-2	LAL3502123	隔套	Spacer	2	CSG TRW	√
2-3	L3502129	后ABS齿圈	ABS gear	2	wanxiang	√
2-3	LAL3502129	后ABS齿圈	ABS gear	2	CSG TRW	
2-4	L3502126	后轮毂轴承	Rear hub bearing	2	wanxiang	√
2-4	LAL3502126	后轮毂轴承	Rear hub bearing	2	CSG TRW	√
2-5	L3502121	后制动鼓	Brake drum	2	wanxiang	


3.21 后制动器　Rear brake

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
2-5	LAL3502121	后制动鼓	Brake drum	2	CSG TRW	

2-6	L3502127	挡环	Circlip	2	wanxiang	√
2-6	LAL3502127	挡环	Circlip	2	CSG TRW	√
3	131B-2216T2F3	六角凸缘螺母	Nut	2	wanxiang	√
3	131-2216T2F3	六角凸缘螺母	Nut	2	CSG TRW	√
4	L3502124	碗型塞	Plug	2	wanxiang	√
4	LAL3502124	碗型塞	Plug	2	CSG TRW	√
5	307-0820TF30	内六角圆柱头螺钉	Bolt	8		√
6	Q40308	弹簧垫圈	Elastic washer	8		√

3





3.22 散热器　Radiator

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LBA1301000	散热器总成	Radiator	1	Old status	√


1	LBA1301000B1	散热器总成	Radiator	1	New status	√
1	LBA1301000B2	散热器总成	Radiator	1	For Iran and other hot area	
1-1	LBA1301001	上水室	Upper water chamber	1		
1-2	LBA1301020B1	散热器压力阀组件	Radiator pressure valve	1	New status only	√
1-3	LBA1301003	下水室	Lower water chamber	1		
2	Q1460612T1F30	六角头螺栓弹簧垫圈平垫圈组合件	Hex bolt and washers	2		√
3	LBA1302100	散热器上安装支架总成	Radiator bracket	2		√
4	LBA1302011	散热器下缓冲垫	Radiator damper,lower	2		√
5	Q340B06	Ⅰ型六角螺母	Nut	2		√
6	Q1410614	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	2		√
7	LBA1308100B1	电子风扇带护风罩总成	Radiator fan assy.	1		√
7	LBA1308100C1	电子风扇带护风罩总成	Radiator fan assy.	1	For Iran and other hot area	
7-1	LBA1308120	护风罩	Radiator fan shroud	1	Old status	√
7-1	LBA1308120B1	护风罩	Radiator fan shroud	1	New status	√
7-2	L1308110	电子风扇叶片	Radiator fan blade	1		√
8	Q33005	全金属六角法兰面锁紧螺母	Nut	1		√
9	Q37105	焊接方螺母	Square nut	3		
10	Q40305	弹簧垫圈	Elastic washer	3		√
11	Q2140512	十字槽盘头螺钉	Screw	3		√


3.22 散热器　Radiator

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
12	LAX3749100	电子风扇电机	Radiator fan motor	1		√

12	LAX3749100A2	电子风扇电机	Radiator fan motor	1	For Iran and other hot area	
13	LAX3749130	调速模块	Adjustable resistance	1		√

3.23






3.23 冷却管路　Cooling line

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LBA1303140C1	溢水管及环箍总成	Overflow pipe assy.	1		√

1-1	Q673B12	钢带弹性卡箍	Hoop	2		√
2	LBA1311100B1	储水壶总成	Surge tank	1		√
2-1	LBA1311102B1	储水壶盖	Surge tank cap	1		√
3	Q1410520L	六角头螺栓和平垫组合件	Hex bolt and taper elastic washer	1		√
4	LBA1303120B1	散热器回水管及环箍总成	Radiator reflux pipe assy.	1		√
4-1	Q67550	A型蜗杆传动式软管环箍	Hoop	2		
5	LBA1303110B1	散热器出水管及环箍总成	Radiator drain pipe assy.	1		√
5-1	Q67550	A型蜗杆传动式软管环箍	Hoop	2		
	Q675B12	钢带弹性卡箍	Hoop	1		√

3.24





3.24 排气系统　Exhaust system


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAL1200018	前排气管密封圈	Exhaust pipe gasket	1		√


2	231-1025T1F3	六角法兰面螺栓	Hex flange bolt	1		√
3	LBA1203105	吊耳	Lug	1		√
4	Q33010T13F3	全金属六角法兰面锁紧螺母	Nut	1		√
5	LAL1203100	前排气管前段总成	Front exhaust pipe	1	without OBD	√
	LAL1203100B1	前排气管前段总成	Front exhaust pipe	1	OBD	√
6	LBA1203102	管夹	Tube clip	1		√
7	Q1841020	六角法兰面螺栓	Hex flange bolt	1		√
8	Q33010T13F3	全金属六角法兰面锁紧螺母	Nut	6		√
9	L1208012	中隔热罩	Middle heat insulator	1		√
10	Q1841035TF3	六角法兰面螺栓	Hex flange bolt	6		√
11	LAL1203300	前排气管后段总成	Rear part of front exhaust pipe	1	without OBD	√
	LAL1203300B1	前排气管后段总成	Rear part of front exhaust pipe	1	OBD	√
12	L1200017	小密封垫	Gasket	3		√
13	LBA1201100	前消声器总成	Front muffler	1		√
14	LCB1201200	后消声器总成	Rear muffler	1	DX	√
	LCB1201200B1	后消声器总成	Rear muffler	1	EX	√
15	L1200014	大橡胶支座	Rubber seat	2		√
16	L1208014	塑料平垫	Plastic washer	4		√
17	Q32206	六角螺母和锥形弹性垫圈组合件	Hex nut and taper elastic washer	4		√

3.25









3.25 车轮 Wheels（steel）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L3105110	旋转盖组件	Wheel cap	1		√

2	L3105101	橡胶垫	Rubber gasket	1		√
3	L3106100	轮胎	Tyre	4	185/60R14	
4	L3106300	轮胎(备用)	Spare tyre	1	165/70R14	
5	L3113100F01	轮辋总成	Tyre rim（steel）	5	electrophoretic paint	√
6	L3102011A3	车轮装饰罩	Wheel cover	4		√
7	L3113012A2	5g夹式平衡块	Clip balancing weight,5g	demand		
7	L3113013A2	10g夹式平衡块	Clip balancing weight,10g	demand		
7	L3113014A2	15g夹式平衡块	Clip balancing weight,15g	demand		
7	L3113015A2	20g夹式平衡块	Clip balancing weight,20g	demand		
7	L3113016A2	25g夹式平衡块	Clip balancing weight,25g	demand		
7	L3113017A2	30g夹式平衡块	Clip balancing weight,30g	demand		
7	L3113018A2	35g夹式平衡块	Clip balancing weight,35g	demand		
7	L3113019A2	40g夹式平衡块	Clip balancing weight,40g	demand		
7	L3113021A2	45g夹式平衡块	Clip balancing weight,45g	demand		
7	L3113022A2	50g夹式平衡块	Clip balancing weight,50g	demand		
7	L3113023A2	55g夹式平衡块	Clip balancing weight,55g	demand		
7	L3113024A2	60g夹式平衡块	Clip balancing weight,60g	demand		
8	L3106200	轮胎气门嘴总成	Tyre valve assy.	5		
8-1	L3106201	气门嘴	Tyre valve	5		


3.25 车轮 Wheels


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
8-2	L3106202	气门嘴防护帽	Valve cap	5		

9	261B-1254TF13	紧固螺栓	Wheel bolt	16		√

3.26









3.26 车轮（铝） Wheels（aluminum）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L3105110B1	旋转盖组件	Wheel cap	1		√

2	L3105101	橡胶垫	Rubber gasket	1		√
3	L3106300	轮胎(备用)	Spare tyre	1	165/70R14	
4	L3106100	轮胎	tyre	4	185/60R14	
5	L3113100F01	轮辋总成	Tyre rim（steel）	5	electrophoretic paint	√
6	LAX3113210	铝轮毂盖板	Aluminum wheel hub cap	4		√
6	B3102510BLACK		Aluminum wheel hub cap		для диска L3101111RU	√
6-1	LAX3113211	轮毂中心标牌	Wheel emblem	1		√
6-2	L3113212B1	盖板	Hub cap	1		
6-3	L3113213B1	卡簧	Circlip	1		
7	L3113011A2	粘式平衡块	Glue balancing weight,5g	demand		
7	L3113033A2	粘式平衡块	Glue balancing weight,60g	demand		
8	L3106200	轮胎气门嘴总成	Tyre valve assy.	5		
8-1	L3106201	气门嘴	Tyre valve	5		
8-2	L3106202	气门嘴防护帽	Valve cap	5		
9	261-1254TF13	紧固螺栓	Bolt	16		√
10	LAX3113201	铝轮毂	Aluminum wheel hub	4	5 спиц	√
10	L3101111RU	铝轮毂	Aluminum wheel hub	4	7 спиц	√

4.Electrical Equipment





4.01 前舱电器　Electrical equipment in front compartment


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	L3741100	前刮水器电动机	Front wiper motor	1		√
2	L5207201	电动洗涤泵	Windshield washer pump	1		√
3	LBA3612500	弱加速传感器	idle sensor	1		√
4	L3721100A2	双音电喇叭总成	Horn assy.	1		√
4-1	Q150B0820	六角头螺栓	Hex bolt	2		
4-2	Q40108	平垫圈	Flat washer	2		√
4-3	L3721120B1	低音喇叭	Horn（bass）	1		√
4-4	Q340B08	Ⅰ型六角螺母	Nut	2		√
4-5	Q40308	弹簧垫圈	Elastic washer	2		√
4-6	L3721101B1	喇叭支架	Horn bracket	1		√
4-7	L3721110B1	高音喇叭	Horn（alt）	1		√
5	LAX3722200B1	发动机舱电器中央控制盒总成	Central control case，engine compartment	1		
5-1	LAX3722400B1	发动机舱电气中央控制盒上盖组件	Central control case cap，upper	1		√
5-2	LAX3722300B1	发动机舱电气中央控制盒本体总成	Central control case body	1		
5-3	LAX3722220B1	发动机舱电气中央控制盒下盖	Central control case cap，lower	1		
5-4	LAX3722610B1	保险丝	Fuse	4	ATN 5A ,mini fuse	√
5-4	LAX3722620B1	保险丝	Fuse	1	ATN 10A,mini fuse	√
5-4	LAX3722630B1	保险丝	Fuse	1	ATN 15A,mini fuse	√
5-4	LAX3722640B1	保险丝	Fuse	3	ATN 20A,mini fuse	√
5-4	LAX3722650B1	保险丝	Fuse	1	ATN 25A,mini fuse	√

4.01 前舱电器　Electrical equipment in front compartment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

5-4	LAX3722660B1	保险丝	Fuse	3	ATN 30A,mini fuse	√
5-4	L3722150	保险丝	Fuse	3	ATS 5A，ordinary fuse	√
5-4	L3722160	保险丝	Fuse	9	ATS 10A，ordinary fuse	√
5-4	L3722180	保险丝	Fuse	9	ATS 15A，ordinary fuse	√
5-4	L3722130	保险丝	Fuse	2	ATS 20A，ordinary fuse	√
5-4	L3722140	保险丝	Fuse	1	ATS 25A，ordinary fuse	√
5-4	L3722170	保险丝	Fuse	3	ATS 30A，ordinary fuse	√
5-4	LAX3722540B1	保险丝	Fuse	1	ANS 60A，hole joint	√
5-4	LAX3722530B1	保险丝	Fuse	2	ANS 50A，hole joint	√
5-4	LAX3722510	保险丝	Fuse	2	FLF 30A，hole joint	√
5-4	LAX3722530	保险丝	Fuse	2	FLF 50A，flat fuse	√
5-4	LAX3722540	保险丝	Fuse	1	FLF 60A，flat fuse	√
5-5	LAX3735110	主继电器	Main relay	1	JD1927	√
5-5	LAX3735610	空调压缩机继电器	Relay，compressor	1	JD1927	√
5-5	LAX3735400A2	冷却风扇继电器（高速）	Relay，fan，high speed	3	JD1927	√
5-5	LAX3735400B1	冷却风扇继电器(低速）	Relay，fan，low speed	3	JD109-001	√
5-5	LAX3735500	喇叭继电器	Relay，horn	1	JD1927	√
5-6	LAX3722102	拔片器	Sheet puller	1		
6	L3612310	惯性开关	Inertia switch	1		√
7	Q33005	全金属六角法兰面锁紧螺母	Nut	2		√





4.02 蓄电池 Battery

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	L3703100	蓄电池总成	Battery	1		√
2	Q1840835	六角法兰面螺栓	Hex flange bolt	1		√
3	LAX3703223	蓄电池压块	Battery press plate	1		√
4	Q1840816	六角法兰面螺栓	Hex flange bolt	3		√
5	LAL3703202	蓄电池托盘	Battery carrier	1		√
6	LAL3703220	蓄电池安装支架	Battery bracket	1		

4.03





4.03 仪表板内电器　Center control box and security system


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply


1	Q1840616	六角法兰面螺栓	Hex flange bolt	2		√
2	LAX3605100	防盗ECU	Security ECU	1		√
2-1	LAX3605011	防盗芯片	Security chip	1	Inside key	√
2-2	L3704101	装饰盖	Trim cover	1		√
2-2	LAX3605200	防盗系统读写识别线圈	Security system R/W recognition	1	Only for security system	√
3	LAX3722100	驾驶舱电器中央控制盒总成	Central control case，driver's compartment	1		√
3	LAX3722100A2	驾驶舱电器中央控制盒总成	Central control case，driver's compartment	1	For mini fuse	√
3	LAX3722100B1	驾驶舱电器中央控制盒总成	Central control case，driver's compartment	1	extra defrost function	
3-1	Q1840616	六角法兰面螺栓	Hex flange bolt	4		√
3-2	L3722110	驾驶舱电器中央控制盒本体总成	Central control case body	1		√
3-2	LAX3722110	驾驶舱电器中央控制盒本体总成	Central control case body	1		
3-3	L3722150	保险丝	Fuse	3	ATS 5A，ordinary fuse	√
3-3	L3722160	保险丝	Fuse	9	ATS 10A，ordinary fuse	√
3-3	L3722180	保险丝	Fuse	9	ATS 15A，ordinary fuse	√
3-3	L3722130	保险丝	Fuse	2	ATS 20A，ordinary fuse	√
3-3	L3722140	保险丝	Fuse	1	ATS 25A，ordinary fuse	√
3-3	L3722170	保险丝	Fuse	3	ATS 30A，ordinary fuse	√
3-3	LAX3722610B1	保险丝	Fuse	4	ATN 5A ,mini fuse	√
3-3	LAX3722620B1	保险丝	Fuse	1	ATN 10A,mini fuse	√
3-3	LAX3722630B1	保险丝	Fuse	1	ATN 15A,mini fuse	√

4.03 仪表板内电器　Center control box and security system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

3-3	LAX3722640B1	保险丝	Fuse	3	ATN 20A,mini fuse	√
3-3	LAX3722650B1	保险丝	Fuse	1	ATN 25A,mini fuse	√
3-3	LAX3722660B1	保险丝	Fuse	1	ATN 30A,mini fuse	√
3-4	L3735150	雾灯继电器	Relay，fog lamp	1		√
3-4	L3735190	后风窗除霜继电器	Relay，rear windshield defroster	1		√
3-4	LAX3735750	远光灯继电器	Relay，high beam	1		√
3-4	LAX3735730	近光灯继电器	Relay，low beam	1		√
3-4	LAX3735740	位置灯继电器	Relay，position lamp	1		√
3-5	L3735120	燃油泵继电器	Relay，fuel pump	1		√
3-5	L3735160	闪光继电器	Relay，flash	1		√
3-5	L3735210	转向灯继电器	Relay，steering light	1		√
3-5	L3735180	刮水间歇继电器	Relay，windshield wiper	1		√
3-6	LAX3722101	定义标示	Identification	1		
3-7	LAX3722102	拨片器	Sheet puller	1		
4	L3612340	动力转向开关组件	Power steering switch	1		√
5	LBA3791100B1	遥控接收控制盒	Central lock case	1		√
6	L5120312	中控锁ECU支架	Bracket，central lock ECU	1		√
7	Q2734816	十字槽大半圆头自攻螺钉	Screw	2		√
	LBX3722770	断电器	Circuit Breaker	1		√





4.04 仪表板电器　Electrical equipment in dashboard


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LAX7901400	磁带机装置	Tape player	1		
1	LAX7901100A2	CD机装置	CD player	1		√
1	LAX7901500	DVD带支架总成	DVD player with bracket	1		
1	LAX7901520	DVD总成	DVD player	1		
1	LAX7901300	六碟CD总成	CD player（6 disc）	1		
2	LAX3710400	警示开关	Warning switch	1		√
3	LBX3820100	组合仪表总成	Instrument cluster	1	ABS+OBD	√
3	LBX3820100B1	组合仪表总成	Instrument cluster	1	ABS+OBD+errors display	
3	LBX3820100C1	组合仪表总成	Instrument cluster	1	ABS+OBD+120km/h warning+ACS	
3	LBX3820100D1	组合仪表总成	Instrument cluster	1	ABS+OBD+120km/h warning+ACS+errors display	
3	LBE3820100E1	组合仪表总成	Instrument cluster	1	Water temperature gauge improved for hot area	
4	Q2734816	十字槽大半圆头自攻螺钉	Screw	3		√
5	LAX3750100A2	卡片盒及开关组件总成	Card case and switch component	1	Central lock button switch	√
5	LAX3750100D1	卡片盒及开关组件总成	Card case and switch component	1	Low beam adjustable,Central lock button switch	
5	LAX3750100E1	卡片盒及开关组件总成	Card case and switch component	1	LX,without background light adjuster,without central lock	
5	LAX3750100B1	卡片盒及开关组件总成	Card case and switch component	1	Centrol lock button switch	
5	LAX3750100C1	卡片盒及开关组件总成	Card case and switch component	1	without background light adjuster,with central lock	
5-1	LAX3750101	卡片盒	Card case	1		√
5-2	LAX3750120	仪表背光调节开关总成	Background light adjuster	1		√
5-2	LAX3710230	近光灯光轴调整开关总成	Low beam adjuster	1		√

4.04 仪表板电器　Electrical equipment in dashboard

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

5-3	LAX3787820	中控锁开关	Central lock switch	1		√
6	L3781120	制动踏板开关	Brake pedal switch	1		√
7	LAX3710310	前雾灯开关总成	Front fog lamp switch	1		√
8	LAX3710350	后雾灯开关总成	Rear fog lamp switch	1		√
8	LAX3710350B1	后雾灯开关总成	Rear fog lamp switch	1	extra defrost function	
9	LAX5306603	中控台开关堵盖2	Switch plug2	1		√
10	LAX5306602	中控台开关堵盖1	Switch plug1	1		√
11	LAX3820105	回零杆	fly-back lever	1		




4.05 倒车监视系统　Reverse monitor system

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LAX3776200	倒车视频监视系统	Reverse monitor system	1		
1-1	L3776204	倒车摄像头安装螺母	Reverse camera nut	1		√
1-2	LAX3776202	倒车摄像头线束Ⅰ	Reverse camera harness I	1		√
1-3	L3776201	倒车摄像头	Reverse camera	1		√
1-4	LAX3776203	倒车摄像头线束Ⅱ	Reverse camera harness II	1		√
2	LCA3603000	防撞雷达装置	Reverse radar system	1		√
2-1	LCA3603600	倒车雷达ECU总成	Reverse radar	1		
2-2	Q2715519	十字槽盘头自攻螺钉	Screw	2		√
2-3	LCA3603810	倒车雷达传感器A	Ultrasonic probe A	1		√
2-4	LCA3603820	倒车雷达传感器B	Ultrasonic probe B	1		√
2-5	LCA3603830	倒车雷达传感器C	Ultrasonic probe C	1		√
2-6	LCA3603840	倒车雷达传感器D	Ultrasonic probe D	1		√
2-7	LCA4002800	倒车雷达线束	Reverse radar harness	1		

4.06 开关 Wiper and lamp combination switch




4.06 开关　Wiper and lamp combination switch

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LCA3774000	组合开关总成	Steering wheel switch assy.	1	for airbag	√
1	LCA3774000B1	组合开关总成	Steering wheel switch assy.	1		√
1-1	LCA3774200	雨刮喷水组合开关	Wiper switch	1	for airbag	√
1-1	LCA3774200B1	雨刮喷水组合开关	Wiper switch	1		
1-2	Q2734216	十字槽大半圆头自攻螺钉	Screw	4		√
1-3	301-0616F3	内六角花形圆柱头螺钉	Screw	3		√
1-4	LAX3774300	开关底座	Switch seat	1		√
1-5	LAX3774100	灯光组合开关	Lamp switch	1		√
1-6	LAX3774030	组合开关喇叭触头组件	Horn switch contact	1		√






4.07 扶手板开关　Inner handrail switch

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	L3791300	左前门闭锁器	Lock controller，front left door	1		√
2	L3791400	右前门闭锁器	Lock controller，front right door	1		√
3	L3791500	后门闭锁器	Lock controller，rear door	2		√
4	LAX3746100	左前门内拉手板及扶手开关总成	Inner handrail with switches，front left door	1	4+2	√
4	LAX3746100B1	左前门内拉手板及扶手开关总成	Inner handrail with switches，front left door	1	2+1	
4-1	LAX3746101A2	左前门内拉手板	Inner handrail，front left door	1	4+2	√
4-1	LAX3746101B1	左前门内拉手板	Inner handrail，front left door	1	2+1	
4-2	LAX3746110	司机门玻璃升降器开关	Glass lifter switches，front left door	1	4+2	√
4-2	LAX3746110B1	司机门玻璃升降器开关	Glass lifter switches，front left door	1	2+1	
4-2-1	LAX3746170	安全锁开关	Glass lock switch	1		
4-3	LAX3782070	电动外后视镜开关	Outside mirror switch	1		√
4-4	303-3512	十字槽盘头自攻螺钉	Screw	3		
5	LAX3746200A2	右前门内拉手板及乘客门玻璃升降开关总成	Inner handrail with switch，front right door	1		√
5-1	LAX3746201	右前门内拉手板	Inner handrail，front right door	1		√
5-2	LAX3746210	乘客门玻璃升降开关总成	Glass lifter switch，passengers' door	3		√
6	LAX3746300	左后门内拉手板及开关总成	Inner handrail with switch，rear left door	1		√
6-1	LAX3746301	左后门内拉手板	Inner handrail，rear left door	1		√
7	LAX3746400	右后门内拉手板及开关总成	Inner handrail with switch，rear right door	1		√
7-1	LAX3746401	右后门内拉手板	Inner handrail，rear right door	1		√







4.08 玻璃升降电机　Windows glass lifter motor

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	L3746500	电动玻璃升降器电机	Glasslifter motor	4		
2	Q33006	全金属六角法兰面锁紧螺母	Nut	20		√

4.09





4.09 副仪表　Console


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LAX3725100	点烟器总成	Cigarette lighter	1	white backlight	√
1	LAX3725100A2	点烟器总成	Cigarette lighter	1	red backlight	√
1-1	LAX3725110	点烟器提扭及发热盘	Cigarette lighter component	1		√
1-2	LAX3725120	外壳	Cigarette lighter shell	1		√
1-3	LAX3725136	光圈	Cigarette lighter ring	1		√
1-4	LAX3725130	背光指示灯	Cigarette lighter light	1		√
2	L3781110	驻车制动开关	Parking brake switch	1		√
3	LAX3658100	安全气囊ECU	Airbag ECU	1	4 hoop	
3	LAX3658100B1	安全气囊ECU	Airbag ECU	1	2 hoop	√
3	LAX3658100C1	安全气囊ECU	Airbag ECU	1	for single airbag	
3	LAX3658100D1	安全气囊ECU	Airbag ECU	1	2 hoop，improved	√

4.1








4.10 锁芯　Lock and keys

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	SL37001	钥匙锁件维修包	Lock cylinders and key	1		√
2	SLBA37002	遥控装置套件	Remote device kit	1		√
3	Q2140406	十字槽盘头螺钉	Screw	2		√
4	LAX3704210	钥匙	Key	2		√
4	LAX3704200B1	白坯钥匙	Key	demand	shapeless	√
4-1	LAX3704232	手柄下盖	key handle upper	1		√
4-2	LAX3704231	手柄上盖	key handle lower	1		√
4-3	LAX3791233	钥匙片	Key plate	1		√
5	LAX3791212	摇控发射器电池	Battery，remote transmitter	2		√
	SL300001	白坯钥匙片	Key plate	1	shapelss	√

4.1






4.11 车用信息通讯与声像设备　Communication and A/V device

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	L7903101	天线线束Ⅰ	Antenna harness I	1		√
2	Q2713513	十字槽盘头自攻螺钉	Screw	4		
3	LAX7909100B1	扬声器(高音头)	Speaker	2	VIP	√
4	LAX7909100	扬声器(高音)	Speaker，alt	2	DX,EX	√
4	LAX7909100A2	扬声器(中音)	Speaker，mid	2	LX/TOP	√
5	Q2734816A	十字槽大半圆头自攻螺钉	Screw	12		√
6	L7903102	天线线束Ⅱ	Antenna harness II	1		√
7	LAX7909100A3	扬声器(四寸低音)	Speaker，bass	2		√
8	L7903000	天线	Antenna	1		√
8-1	L7903200	天线杆	Antenna mast	1		
8-2	L7903300	天线座	Antenna base	1		
9	LAX7901312	六碟机支架	CD player bracket，6 disc	1		
10	LAX7901320	六碟CD碟盒总成	CD case，6 disc	1		√
11	LAX7901530	DVD遥控器总成	DVD remote	1		√
12	LAX7901311	六碟机电缆	CD player cable，6 disc	1		√
13	Q2734816A	十字槽大半圆头自攻螺钉	Screw	4		√





4.12 全车灯系　Vehicle lamps

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply


1	LAX4121200	右前组合灯总成	Right head lamp	1		
1	LAX4121200B1	右前组合灯总成	Right head lamp	1	Low beam adjustable	√
2	Q1840816T1F30	六角法兰面螺栓	Hex flange bolt	6		√
3	PY21W 12V/GB 15776-2001	前转向灯灯泡	Steering bulb	2	PY21W	√
4	H1 12V/GB 15776-2001	近光灯泡	Low beam bulb	2		√
5	H1 12V/GB 15776-2001	远光灯泡	High beam bulb	2		√
6	W5W 12V/GB 15776-2001	灯泡	Bulb	2	W5W	√
7	H3/GB 15766-2001	前雾灯灯泡	Front fog lamp bulb	2	12V 55W	√
8	LCA4116200	右前雾灯	Front right fog lamp	1		√
9	Q2140406	十字槽盘头螺钉	Screw	4		√
10	L4116301	灯泡	Bulb	4	12V 21W	√
11	LAX4121100	左前组合灯总成	Left head lamp	1		
11	LAX4121100B1	左前组合灯总成	Left head lamp	1	Low beam adjustable	√
12	LCA4116100	左前雾灯	Front left fog lamp	1		√
13	LCA4134100	高位制动灯	Brake lamp	1		√
14	L4111200	右侧转向灯总成	Steering lamp，right	1		√
15	L4111100	左侧转向灯总成	Steering lamp，left	1		√
16	L4123100B01	前顶灯总成	Room light，front	1	yellow	
16	L4123100B02	前顶灯总成	Room light，front	1	black	√
16	L4123100B03	前顶灯总成	Room light，front	1	grey	

4.12 全车灯系　Vehicle lamps

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

17	LAX4131200B06	右前门灯总成	Door lamp，front right door			√
18	LAX4135200	右前门灯反射器总成	Door lamp reflector，front right door	1		√
19	LAX4131100B06	左前门灯总成	Door lamp，front left door	1		√
20	LAX4135100	左前门灯反射器总成	Door lamp reflector，front left door	1		√
21	LAX4131400B06	右后门灯总成	Door lamp，rear right door	1		√
22	LAX4135400	右后门灯反射器总成	Door lamp reflector，rear right door	1		√
23	LAX4131300B06	左后门灯总成	Door lamp，rear left door	1		√
24	LAX4135300	左后门灯反射器总成	Door lamp reflector，rear left door	1		√
25	L3661310	近光灯光轴高低调整电机组件	Low beam adjustor	2		
26	L4127000	行李箱灯	Trunk light	1		√
27	L4127040	行李箱灯泡	Trunk light bulb	1		√
28	LAX4123200B01	后顶灯	Room light，rear	1	yellow	
28	LAX4123200B02	后顶灯	Room light，rear	1	black	√
28	LAX4123200B03	后顶灯	Room light，rear	1	grey	
29	L4108100	后牌照灯	License light	1		√
30	LCA4133200	右后组合灯	Right tail lamp	1		√
31	LCA4133100	左后组合灯	Left tail lamp	1		√
32	Q33006	全金属六角法兰面锁紧螺母	Nut	6		√
33	Q2140510	十字槽盘头螺栓	Screw	4		√





4.13 前部线束　Front harness


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LAL4011000	前部线束	Front harness	1	Sun&teck	√
	LAL4011000B1	前部线束	Front harness	1	Sun&teck+ABS	√
	LAL4011000C1	前部线束	Front harness	1	Delphi	√
	LAL4011000D1	前部线束	Front harness	1	Delphi+ABS	√
	LAL4011000G1	前部线束	Front harness	1	Sun&teck+ABS+low beam adjustable	√
	LAL4011000H1	前部线束	Front harness	1	Delphi+ABS+low beam adjustable	√
	LAL4011000E1	前部线束	Front harness	1	Sun&teck+ABS+ACS integrated	√
	LAL4011000F1	前部线束	Front harness	1	Delphi+ABS+ACS integrated	√
	LAL4011000R1	前部线束	Front harness	1	Sun&teck+ABS+ACS separated	√
	Q1840616	六角法兰面螺栓	Hex flange bolt	3		√
	NXK-M4-7	线卡	Clip	19		
	Q67407200	扎带	Tie	2		
	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	3		√
	L4011771	前部线束过线橡胶护套	Front harness sleeve	11		√

4.14 仪表板线束 Dashboard harness

接背光调 接前雾灯 接后雾灯 接中控锁

security ECU




4.14 仪表板线束　Dashborad harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LCA4003100	仪表板线束总成	Dashborad harness	1		√
	LCA4003100C1	仪表板线束总成	Dashborad harness	1	Low beam adjustable	√
	XJ-66	线卡	Clip	1		
	Q1840616	六角法兰面螺栓	Hex flange bolt	1		√
	L4003011	锁紧片	Locker washer	1		
	Q67407200	塑料紧箍带	Tie	5		
	Q1840616T1F30	六角法兰面螺栓	Hex flange bolt	2		√

4.15 发电机B端线束　Generator B wire






4.15 发电机B端线束　Generator B wire

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LBX4008120	发电机B端子线束	Generator B wire	1		√
	DWJ-L08	卡子	Clip	1		
	Q33006	全金属六角法兰面锁紧螺母	Nut	1		√
	Q33008T13F3	全金属六角法兰面锁紧螺母	Nut	1		√
	L1000027A1	长支撑片	Support piece	2		
	Q67407200	扎带	Tie	2		

4.16 顶棚线束　Headlining harness




4.16 顶棚线束　Headlining harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LAX4005000	顶棚线束总成	Headlining harness	1		√
	NXK-M4-7	线卡	Clip	5		

4.17 左车身线束 Left body harness




4.17 左车身线束　Left body harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LCA4002100	左车身线束总成	Left body harness	1		√
1	LBX4002100B1	左车身线束总成	Left body harness	1	extra defrost function	
	Q18400616	六角法兰面螺栓	Hex flange bolt	2		
	Q41206	外锯齿锁紧垫圈	External teeth serrated lock washer	2		√

4.18 右前门线束 Right door harness






4.18 右前门线束　Right door harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LAX4007200B1	右前门线束总成	Right front door harness	1		√
1	LBX4007200B1	右前门线束总成	Right front door harness	1	extra defrost function	
	L4007171	前车门线束过线橡胶护套	Front door harness sleeve	1		√

4.19





4.19 左前门线束　Left door harness


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LAX4007100B1	左前门线束总成	Left front door harness	1		√
1	LBX4007100B1	左前门线束总成	Left front door harness	1	extra defrost function	
	L4007171	前车门线束过线橡胶护套	Front door harness sleeve	1		√

4.20 后车门线束 Rear door harness

接玻璃升降副开关

glass lifter switch




4.20 后车门线束　Rear door harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LAX4007300	左、右后车门线束总成	Rear door harness	2	LX	√
	LAX4007300B1	左、右后车门线束总成	Rear door harness	2		√
	NXK-M4-7	线卡	Clip	5		
	L4007371	后车门线束过线橡胶护套	Rear door harness sleeve	2		√

4.21 后厢门线束　Tail door harness




4.21 后厢门线束　Tail door harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LCA4006600	后厢门线束	Tail door harness	1		√
	NXK-M4-7	线卡	Clip	5		

4.22 后厢门转接线束　Tail door adapter harness





4.22 后厢门转接线束　Tail door adapter harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LCA4006700	后厢门转接线束	Tail door adapter harness	1		√
	CSO2	线卡	Clip	3		

4.23






4.23 右地板线束　Right floor harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LAX4002200	右地板线束总成	Right floor harness	1		√
1	LBX4002200B1	右地板线束总成	Right floor harness	1	extra defrost function	

4.24 蓄电池负极线束　Battery negative wire






4.24 蓄电池负极线束　Battery negative wire

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LAL4008110	蓄电池负极线束总成	Battery negative wire	1		√
	Q1840616	六角法兰面螺栓	Hex flange bolt	1		√
	Q33008T2F30	全金属六角法兰面锁紧螺母	Nut	1		√

4.25 制动蹄片磨损检测线束　Brake shoe worm inspection harness




4.25 制动蹄片磨损检测线束　Brake shoe worm inspection harness

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LBA4008150	制动蹄片磨损检测线束总成	Brake shoe worm inspection harness	2		√
	Q1410516	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	4		√

4.26 ABS传感器　ABS sensor




4.26 ABS传感器　ABS sensor

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	L3630400	后轮速传感器总成	Rear wheel speed sensor	2	wanxiang	√
1	L3630400B1	后轮速传感器总成	Rear wheel speed sensor	2	APG	√
2	L3630300	前轮速传感器总成	Front wheel speed sensor	2	wanxiang	√
2	L3630300B1	前轮速传感器总成	Front wheel speed sensor	2	APG	√

4.27 安全气囊线束 Airbag harness




4.27 安全气囊线束　Airbag harness


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply

1	LAX4008140	安全气囊线束	Airbag harness	1		√
	LAX4008140B1	安全气囊线束	Airbag harness	1	Improve designed	√

5.Vehicle body

5.01 白车身焊







5.01 白车身焊接总成　Vehicle body assy.

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LCB5010000	白车身焊接总成	Vehicle body assy.	1		

5.02 机舱盖







5.02 机舱盖　Engine hood

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L8402010	发动机罩焊接总成	Engine hood	1		√
2	L8402210	发动机罩左铰链	Engine hood left hinge	1		√
3	Q1420620	六角头螺栓和弹簧垫圈组合	Hex bolt and washers	4		√

4	Q1460620	六角头螺栓、弹簧垫圈和平垫圈组合件	Hex bolt and washers	4		√
5	L8402220	发动机罩右铰链	Engine hood right hinge	1		√
6	507-0818	大垫圈	Washer	4		√

5.03 水箱横梁　Ra







5.03 水箱横梁　Radiator beam

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L8401000	水箱横梁总成	Radiator beam assy.	1		√
1-1	L8401100	水箱上横梁组件	Radiator upper beam component	1		√
1-1-1	L8401104	水箱上横梁右连接板	Radiator upper beam right connecting panel	1		√
1-1-2	L8401106	水箱上横梁右支架	Radiator upper beam right bracket	1		√
1-1-3	L8401107	水箱上横梁中支架	Radiator upper beam middle bracket	1		√

1-1-4	L8401105	水箱上横梁左支架	Radiator upper beam left bracket	1		√
1-1-5	L8401103	水箱上横梁左连接板	Radiator upper beam left connecting panel	1		√
1-1-6	L8401101	水箱上横梁	Radiator upper beam	1		√
1-1-7	L5120306	熔焊卡条	Clip	4		√
1-2	L8401200	水箱下横梁组件	Radiator lower beam component	1		√

5.04 防撞横梁　Anti-collision beam







5.04 防撞横梁　Anti-collision beam

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L8400500	防撞横梁组件	Anti-collision beam assy.	1		√

5.05 前围 I







5.05 前围　Dash panel

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L5301200	前围下挡板组件	Dash panel lower assy.	1		√
1-1	L5301204	前围下挡板右加强板	Right stiffener，dash panel lower	1		√
1-2	L5301203	前围下挡板左加强板	Left stiffener，dash panel lower	1		√
1-3	L5301201	前围下挡板	Dash panel lower	1		√
2	L5301300	前围上横梁总成	Dash panel upper beam	1		√
2-1	L5301324	副雨刮器安装板	Sub wiper panel	1		√
2-2	L5301323	雨刮器安装板	Wiper panel	1		√
3	LAL8400241	ABS安装支架I	ABS bracket	1		√
4	LAL5301100	前围上挡板组件	Dash panel upper	1		√

5	L5301400	前围挡板中横梁组件	Dash panel central beam	1		√

5.06 左前纵梁及前





5.06 左前纵梁及前轮罩总成　Left front longeron and front wheel house


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAL8400100	左前纵梁及前轮罩总成	Left front longeron and front wheel cap assy.	1		√
1-1	L8400301	左前轮罩前部	Left front wheel cap front part	1		√
1-2	L8400308	翼子板左安装板	Left fix board，fender	1		√
1-3	L8400302	左前轮罩内板	Left front wheel cap inner panel	1		√
1-4	L8400305	左固定加强板	Left stiffener	1		√
1-5	L8400304	左悬挂固定板	Left suspension plate	1		√
1-6	L8400306	左前轮罩后部	Left front wheel cap rear part	1		√
1-7	L8400309	ECU安装支架	ECU bracket	1		√
1-8	Q198B0520	承面凸焊螺栓	Bolt	2	M5×20	
1-9	L8400307	惯性开关安装支架	Inertia switch bracket	1		√
1-10	L8400112	左前纵梁面板	Left front longeron panel	1		√

1-11	L8400117	左前纵梁支架板	Left front longeron bracket	1		√
1-12	L8400126	前牵引挂钩	Drag hook	1		√
1-13	L8400116	副车架左安装支架	Sub-frame bracket，left	1		√
1-14	L8400113	左前纵梁端板	Left front longeron end panel	1		√
1-15	L8400122	左前纵梁连接板	Left front longeron connecting panel	1		√
1-16	LAL8400111	左前纵梁	Left front longeron	1		√
1-17	LAL8400119	左前纵梁前盖板	Left front longeron fore cover	1		√

5.06 左前纵梁及前轮罩总成　Left front longeron and front wheel house

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1-18	LAL8400137	左前纵梁螺母套	Nut sleeve	1		√
1-19	L8400121	左前纵梁后盖板	Left front longeron rear cover	1		√
1-20	LAL8400118	左前纵梁加强板	Left front longeron stiffener	1		√
1-21	L8400123	左后纵梁	Left rear longeron	1		√
1-22	L8400114	左挡泥板安装支架	Mud guard bracket	1		√
1-23	L8400130	左前副车架安装板组件	Sub-frame bracket component，left	1		√
1-24	L5120605	车身定位左支架	Left positioning bracket	1		√
2	L8403110	左前翼子板内板组件	Left fender，inner panel	1		√

5.07 右前纵梁及


1
1-1
1-2
1-3
1-4
1-5
1-6
1-7
1-8
1-9
1-10
1-11
1-12
1-13
1-14
1-15
1-16
1-17
1-18
1-19
1-20
1-21
1-22
1-23
1-25
2



5.07 右前纵梁及前轮罩总成　Right front longeron and front wheel house


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LBA8400200C1	右前纵梁及前轮罩总成	Right front longeron and front wheel cap assy.	1	出口车用	√
1-1	L8400401	右前轮罩前部	Right front wheel cap front part	1		√
1-2	L8400408	翼子板右安装板	Right fix board ， fender	1		√
1-3	LBA8400402	右前轮罩内板	Right front wheel cap inner panel	1		√
1-4	L8400403	转向油壶限位支架	Steering oil reservior bracket	1		√
1-5	L8400405	右固定加强板	Right stiffener	1		√
1-6	L8400404	右悬挂固定板	Right suspension plate	1		√
1-7	L8400406	右前轮罩后部	Right front wheel cap rear part	1		√
1-8	LBA8400409	机舱盖称杆支架	Holding rod bracket	1		√
1-9	L8400217	右前纵梁支架板	Right front longeron bracket	1		√
1-10	L8400212	右前纵梁面板	Right front longeron panel	1		√
1-11	L8400213	右前纵梁端板	Right front longeron end panel	1		√
1-12	L8400218	右前纵梁加强板	Right front longeron stiffener	1		√
1-13	L8400216	副车架右安装支架	Sub-frame bracket，right	1		√

1-14	L8400211	右前纵梁	Right front longeron	1		√
1-15	L8400222	右前纵梁连接板	Right front longeron connecting panel	1		√
1-16	L8400224	碳罐支架	Canister bracket	1		√
1-17	L8400226	空调管支架	Air conditioner pipeline bracket	1		√

5.07 右前纵梁及前轮罩总成 Right front longeron and front wheel house

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1-18	L8400215	右制动软管固定支架	Brake hose right bracket	1		√
1-19	L8400219	右前纵梁前盖板	Right front longeron fore cover	1		√
1-20	L8400225	螺母套	Nut sleeve	2	M10	√
1-21	L8400221	右前纵梁后盖板	Right front longeron rear cover	1		√
1-22	L8400223	右后纵梁	Right rear longeron	1		√
1-23	L8400227	右前牵引挂钩	Drag hook	1		
1-24	L8400230	右前副车架安装板组件	Sub-frame bracket component，right	1		√
1-25	L5120606	车身定位右支架	Right positioning bracket	1		√
2	L8403211	右前翼子板内板	Right fender inner panel	1		√


5.08 顶盖　Roof



5.08 顶盖　Roof

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LCA5701000	顶盖骨架及盖板	Roof assy.	1		√
1-1	LCA5701011	顶盖外板	Roof panel	1		√
1-2	LCA5701020	顶盖前横梁总成	Roof beam，front	1		√
1-3	LCA5701014	顶盖中横梁	Roof beam，middle	1		√
1-4	LCA5701030	顶盖后横梁总成	Roof beam，rear 1	1		√
1-5	LCA5701040	顶盖后横梁组件	Roof beam，rear 2	1		√


5.09 左侧围 Left cowl



5.09 左侧围　Left cowl

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LCA5401010	左侧围总成	Left cowl assy.	1		√

5.10 右侧围　Right cowl




5.10 右侧围　Right cowl

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LCA5401020	右侧围总成	Right cowl assy.	1		√
1-1	LCA5401510	加油口盖总成	Fuel filler panel	1		√

5.11 左前车门 Front left door






5.11 左前车门　Front left door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX6101001	左前车门总成	Front left door	1		√

2	L6106010	左车门铰链总成	Left door hinge	2		√

5.12 左后车门 Rear left door






5.12 左后车门　Rear left door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX6201001	左后车门总成	Rear left door	1		√
2	L6106010	左车门铰链总成	Left door hinge	2		√

5.13 右前车门 Front right door







5.13 右前车门　Front right door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX6101002	右前车门总成	Front Right door	1		√
2	L6106020	右车门铰链总成	Right door hinge	2		√

5.14 右后车门 Rear right door







5.14 右后车门　Rear right door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX6201002	右后车门总成	Rear Right door	1		√
2	L6106020	右车门铰链总成	Right door hinge	2		√

5.15 后背门 Back door







5.15 后背门 Back door

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LCA6301000	后背门总成	Back door	1		√
2	LCA6306100	后背门铰链总成	Back door hinge	1		√
3	Q1840816	六角法兰面螺栓	Bolt	4		√
4	Q33008T13F3	全金属六角法兰面锁紧螺母	Nut	4		√

5.16 前地板总成　Front floor







5.16 前地板总成　Front floor

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L5120200	右内纵梁总成	Right floor longeron	1		√
2	L5120210	右前座椅后安装支架组件	Front right seat mount	1		√
3	L5120300	操纵台底板组件	Console mount	1		√
4	L5120110	左前座椅后安装支架组件	Front left seat mount	1		√
5	L5120100	左内纵梁总成	Left floor longeron	1		√
6	L5120600	前地板组件	Front floor	1		√

5.17 后地板总成　Rear floor







5.17 后地板总成　Rear floor

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LCA5130000B1	后地板总成	Rear floor assy.	1		√

5.18 后围　Rear cowl






5.18 后围　Rear cowl

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LCA5601100	后围裙板总成	Rear cowl assy.	1		
1-1	LCA5601120	后围裙板内板组件	Rear cowl inner panel	1		√
1-2	LCA5601111	后围裙板外板	Rear cowl outer panel	1		√
1-3	LCA5601130	背门锁扣安装加强板组件	Back door buckle panel	1		√

5.19 前翼子板组件 Front fender panel






5.19 前翼子板组件 Front fender panel

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L8403101	左前翼子板外板	Left fender outer panel	1		√
2	L8403201	右前翼子板外板	Right fender outer panel	1		√
3	Q1840810	六角法兰面螺栓	Bolt	16		√

6.Body attachment


6.01 发动机罩 Engine hood attachment




6.01 发动机罩 Engine hood attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L8402014	发动机罩后密封条	Rear seal，engine hood	1		√
2	L8402016	塑料卡扣	Plastic clip	14		√
3	L8402011	发动机罩隔热垫	Heat insulator，engine hood	1		√
4	L8402012	塑料卡扣	Plastic clip	15		√
5	L8402013	发动机罩前密封条	Front seal，engine hood	1		√
6	L8402016	塑料卡扣	Plastic clip	6		√
7	LCA8402400	格栅组件	Griile	1		
7	LCA8402400A2E01	格栅组件	Griile	1	chromium	
7	LCA8402400A2E01	格栅组件	Griile	1	9 grade chromium	√
7-1	LCA8402404	密封条	Griile seal	1		√
7-2	Q32006	六角法兰面螺母	Hex flange nut	2		√
7-3	LCA8402401	前格栅本体	Griile body	1		

6.02 前围(上) Front cowl attachment（upper）






6.02 前围(上) Front cowl attachment（upper）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L5206100	风窗玻璃及内视镜底座总成	Front windshield with inside mirror seat	1		
1-1	L8201016	内视镜	Inside mirror	1		√
1-2	L8201017	内视镜底座	Inside mirror seat	1		
1-3	L5206101	前挡风玻璃	Front windshield	1		√
2	L5310013	前围挡板右阻尼垫	Front cowl damper pad，right	1		√
3	L8121017	新风进风罩外板	Air changer cap	1		√
4	L5206103	挡风玻璃密封条	Front windshield seal	1		√
5-1	L5302101	上横梁护板	Upper beam fender	1		√
5-2	L5302105	过度胶条	Upper beam fender seal	1		√
6	Q1410614	六角头螺栓和锥型弹性垫圈组合件	Hex bolt and taper elastic washer	6		√
7	Q1410625T1F30	六角头螺栓和锥型弹性垫圈组合件	Hex bolt and taper elastic washer	4		√
8	L5302102	塑料螺母	Plastic nut	6		√
9	L5302104	螺钉盖帽	Screw cap	6		√
10	335-4216F30	内六角花形大盘头螺钉	Screw	6		
11	L5302103	安装卡扣	Clip	2		√
12	L5310012	前围挡板左阻尼垫	Front cowl damper pad，left	1		√
13	Q2140510	十字槽盘头螺钉	Screw	1		√
14	Q39748202	A型簧片螺母	Nut	1		√

15	Q2214819	十字槽盘头自攻螺钉和大垫圈组合件	Screw and washer	1		√

6.03 前围(下) Front cowl attachment（lower）





6.03 前围(下) Front cowl attachment（lower）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L5109014	塑料卡扣	Plastic clip	11		√
2	LBA5310011	前围挡板隔热垫	Heat insulator，dash panel	1		√
3	LBA5310014	前舱隔音垫	Noise insulator，engine room	1		√
4	LAL5310022	前右侧围隔热垫	Heat insulator，right side	1		√
5	L8403021	右前翼子板防擦条	Molding，right fender	1		√
6	LAX5310024B01	前右侧围隔热垫护板	Heat insulator guard，right side	1	yellow	
6	LAX5310024B02	前右侧围隔热垫护板	Heat insulator guard，right side	1	black	√
7	L5402132	塑料螺母	Plastic nut	4		√
8	305-4820F30	内六角花形大半圆头自攻螺钉	Screw	24		√
9	L8403022	右前挡泥皮	Front right mud guard	1		√
9	LBA8403022	右前挡泥皮	Front right mud guard	1	EX	
10	305-4820F30	内六角花形盘头自攻螺钉	Screw	4		√
11	Q39748202	A型簧片螺母	Nut	4		√
12	LAL5310015	前围下挡板隔热垫	Low heat insulator，dash panel	1		√
13	L8402500	发动机罩撑杆组件	Holding rod assy.engine hood	1		√
13-1	LBA8402504	发动机罩撑杆固定板	Rod fixed panel	1		√
13-2	L8402502	发动机罩撑杆固定块	Rod fixed plate	1		√
13-3	L8402503	发动机罩撑杆护套	Rod sleeve	1		√

13-4	LBA8402500	发动机罩撑杆	Holding rod	1		√
14	L8403023	右前挡泥板	Front right mud guard 2	1	Optional	√

6.03 前围(下) Front cowl attachment（lower）


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
15	L8402021	缓冲块	Dmaper block	1		√
16	LAX5310023B01	前左侧围隔热垫护板	Heat insulator guard，left side	1	yellow	
16	LAX5310023B02	前左侧围隔热垫护板	Heat insulator guard，left side	1	black	√
17	L8402600	发动机罩拉索总成	Engine hood cable assy.	1		√
17-1	L8402600	发动机罩拉索	Engine hood cable	1		√
17-2	L8402603	护套	Cable sleeve	1		√
17-3	L8402602	线卡	Cable clip	4		√
18	LCA2803000	前保险杠总成	Front bumper assy.	1		√
18-1	LCA2803011	前保险杠	Front bumper	1		√
18-2	LCA2803022	前保险杠右缓冲块	Right damper block，front bumper	1		√
18-3	LCA2803021	前保险杠左缓冲块	Left damper block，front bumper	1		√
18-4	L2803026	前保险杠右加强块	Right stiffener，front bumper	1		√
18-5	L2803025	前保险杠右加强块	Left stiffener，front bumper	1		√
19	L8403012	左前挡泥皮	Front left mud guard	1		√
19	LBA8403012	左前挡泥皮	Front left mud guard	1	EX	
20	LAL5310021	前左侧围隔热垫	Heat insulator，left side	1		√
21	L8403013	左前挡泥板	Front left mud guard 2	1	Optional	√
22	Q1410614T1F30	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	3		√

23	L8402700	发动机罩锁总成	Engine hood buckle	1		√
24	L2802011	发动机下部护板	Engine bottom protector	1		√

6.03 前围(下) Front cowl attachment（lower）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
25	L8403011	左前翼子板防擦条	Molding，left fender	1		√
26	Q1460630T1F30	六角头螺栓、弹性垫圈和平垫圈组合件	Hex bolt and washers	6		√
27	Q150B0620T1F30	六角头螺栓	Hex bolt	4		√
28	Q40206F30	大垫圈	Washer	4		√
29	Q31206	B型板簧螺母	Nut	2		√
30	Q1840820	六角法兰面螺栓	Hex flange bolt	2		√

6.04 雨刮 Windshield wiper





6.04 雨刮 Windshield wiper


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L5205120	副雨刮臂总成	Sub-wiper assy.	1		√
1-1	L5205150	副雨刮刮刷组件	Sub-wiper brush assy.	1		√
1-1-1	L5205152	副雨刮刮刷钢片	Sub-wiper brush plate	2		
1-1-2	L5205151	副雨刮刮片	Sub-wiper brush	1		
1-1-3	L5205153	副雨刮骨架	Sub-wiper frame	1		
1-2	L5205170	副雨刮刮臂组件	Sub-wiper arm	1		√
2	L3741100	前刮水器电动机	Front wiper motor	1		√
3	L5205110	主雨刮臂总成	Master wiper assy.	1		√
3-1	L5205140	主雨刮刮刷组件	Master wiper brush assy.	1		√
3-1-1	L5205141	主雨刮刮片	Master wiper brush	1		
3-1-2	L5205142	主雨刮刮刷钢片	Master wiper brush plate	2		
3-1-3	L5205143	主雨刮骨架	Master wiper frame	1		
3-2	L5205160	主雨刮刮臂组件	Master wiper arm	1		√
4	Q360B08	二型六角螺母	Nut	2		√
5	L5205113	雨刮臂盖帽	Wiper arm cap	2		√
A	L5205100	雨刮器连杆机构组件	Wiper con-rod assy.	1		√
6	L5205131	雨刮连杆	Wiper con-rod	1		
7	L5205132	主雨刮臂传动轴	Master wiper arm shaft	1		

8	L5205133	副雨刮臂传动轴	Sub-wiper arm shaft	1		
9	L5205124	雨刮臂防尘套	Wiper dust cap	2		√

6.04 雨刮 Windshield wiper

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
10	L5205134	雨刮臂传动轴胶套	Wiper dust sleeve	2		

6.05 洗涤壶　Windshield washer






6.05 洗涤壶　Windshield washer

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L5207110	注水管带盖子	Windshield washer filling hose assy.	1		√
1-1	L5207106	洗涤器密封圈	Windshield washer seal	1		√
1-2	L5207111	注水管	Filling hose	1		
1-3	L5207112	洗涤壶盖子	Windshield washer can cap	1		
2	L5207300	洗涤器软管总成	Windshield washer hose assy.	1		√
2-1	L5207202	洗涤器软管	Windshield washer hose	1		√
2-2	L5207104	橡胶垫圈	Rubber ring	2	8*12	√
2-3	L5207107	直通管	Direct connecting pipe	1		
2-4	L5207301	喷嘴	Nozzle	2		√
2-5	L5207317	橡胶堵塞Φ25	Rubber plug	1		√
2-6	L5207306	洗涤壶三通	T vavle	1		√
3	L5207201	电动洗涤泵	Windshield washer pump	1		√
4	L5207203	电机密封圈	Seal，washer pump motor	1		√
5	L5207105	金属嵌件	Wiper can metal component	1		√
6	L5207100	洗涤壶组件	Windshield washer can assy.	1		√

6.06 仪表板　Dashboard trims





6.06 仪表板 Dashboard trims

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX5306000B02	仪表板总成	Dashboard	1	maofeng，black	√
1	LAX5306000B98	仪表板总成	Dashboard	1	maofeng，upper black lower grey	
1	LAX5306000B99	仪表板总成	Dashboard	1	maofeng，yellow	
1	LAX5306000A2B02	仪表板总成	Dashboard	1	danyang，black	
1	LAX5306000A2B98	仪表板总成	Dashboard	1	danyang，upper black lower grey	
1	LAX5306000A2B99	仪表板总成	Dashboard	1	danyang，yellow	
1-1	LAX8117150	中间过渡风道总成	Air passage	1		√
1-2	LAX5306310B04	左空调风口总成	Air conditioner left nozzle	1	yellow	
1-2	LAX5306310B02	左空调风口总成	Air conditioner left nozzle	1	Black	√
1-3	LAX5306330B04	双联空调风口总成	Air conditioner center nozzle	1	yellow	
1-3	LAX5306330B02	双联空调风口总成	Air conditioner center nozzle	1	Black	√
1-4	LAX5306320B04	右空调风口总成	Air conditioner right nozzle	1	yellow	
1-4	LAX5306320B02	右空调风口总成	Air conditioner right nozzle	1	Black	√
2	LAX5306022B04	上仪表罩	Instrument cluster cover，upper	1	yellow	
2	LAX5306022B02	上仪表罩	Instrument cluster cover，upper	1	Black	√
3	LAX5306105B04	副安全气囊盖板	Passenger airbag cover	1	yellow，for config without airbag	
3	LAX5306105B02	副安全气囊盖板	Passenger airbag cover	1	Black，for config without airbag	√
4	LAX5305304	装饰条卡扣	Dashboard trim clip	1		√


5	LAX5306104B02	仪表板装饰条	Dashboard trim	1	maofeng，Black	
5	LAX5306104C02	仪表板装饰条	Dashboard trim	1	maofeng，Argent	√

6.06 仪表板　Dashboard trims

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
5	LAX5306104B1B02	仪表板装饰条	Dashboard trim	1	danyang，Black	
5	LAX5306104B1C02	仪表板装饰条	Dashboard trim	1	danyang，Argent	
6	Q2734816	十字槽大半圆头自攻螺钉	Screw	5		√
7	LAX5306601	中控面板总成	Instrument molding	1	golden	
7	LAX5306601C02	中控面板总成	Instrument molding	1	Argent	√
7	LAX5306601B03	中控面板总成	Instrument molding	1	grey	
8	LAX5306701B04	转向柱上护罩	Steering pillar shield upper	1	yellow	√
8	LAX5306701B02	转向柱上护罩	Steering pillar shield upper	1	Black	√
9	LAX5306702B04	转向柱下护罩	Steering pillar shield lower	1	yellow	√
9	LAX5306702B02	转向柱下护罩	Steering pillar shield lower	1	Black	√
10	LAX5306023B04	下仪表罩	Instrument cluster cover，lower	1	yellow	
10	LAX5306023B02	下仪表罩	Instrument cluster cover，lower	1	Black	√
11	LAX5306019B02	仪表板左下盖板	Left lower panel，dashboard	1	black	√
11	LAX5306019B03	仪表板左下盖板	Left lower panel，dashboard	1	grey	
11	LAX5306019B05	仪表板左下盖板	Left lower panel，dashboard	1	yellow	
12	305B-0630T1F30	内六花大圆头螺栓	Screw	2		√
13	Q2734216	自攻螺钉	Screw	1		√
14	LAL5531251	仪表板上吸音垫	Dashboard noise insulater，upper	1		√

15	LAL5531252	仪表板下吸音垫	Dashboard noise insulater，lower	1		√

6.07 副仪表板　Console trims





6.07 副仪表板 Console trims

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX5305300	中下部面罩总成	Console cover assy.	1	maofeng，golden	
1	LAX5305300B02	中下部面罩总成	Console cover assy.	1	maofeng，Black	√
1	LAX5305300B03	中下部面罩总成	Console cover assy.	1	maofeng，grey	
1	LAX5305300B1	中下部面罩总成	Console cover assy.	1	danyang，golden	
1	LAX5305300B1B02	中下部面罩总成	Console cover assy.	1	danyang，Black	√
1	LAX5305300B1B03	中下部面罩总成	Console cover assy.	1	danyang，grey	
1-1	LAX5305312	前部烟灰盒面板	Front ashtray panel	1		
1-2	LAX8203100	前部烟灰缸总成	Front ashtray	1		√
	LAX8203100B1	前部烟灰缸总成	Front ashtray	1		
1-3	LAX5305116	前部烟灰盒开关	Front ashtray switch	1		√
1-4	LAX5305330	阻尼器组件	Damper component	2		
1-5	LAX5305313	阻尼器转轴	Damper shaft	2		
1-6	LAX5305311	中下部面罩	Console cover	1		
1-7	LAX5305314	弹簧	Spring	2		
2	LAX5305000B02	副仪表板总成	Console assy.	1	maofeng，Black	√
2	LAX5305000B03	副仪表板总成	Console assy.	1	maofeng，grey	
2	LAX5305000B05	副仪表板总成	Console assy.	1	maofeng，yellow	
2	LAX5305000A2B02	副仪表板总成	Console assy.	1	danyang，Black	√


2	LAX5305000A2B03	副仪表板总成	Console assy.	1	danyang，grey	
2	LAX5305000A2B05	副仪表板总成	Console assy.	1	danyang，yellow	

6.07 副仪表板 Console trims

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
2-1	LAX5305220	后部物品盒上盖组件	Rear glovebox cover	1		
2-1-1	LAX5305228	后部物品盒上盖覆皮骨架	Rear glovebox cover frame	1		
2-1-2	LAX5305221	后部物品盒上盖内衬板	Rear glovebox cover inner	1		
2-1-3	LAX5305232	后部物品盒开关开关座	Rear glovebox switch seat	1		√
2-2	LAX5305240	后部物品盒底板组件	Rear glovebox	1		
2-2-1	LAX5305241	后部物品盒底板	Rear glovebox bottom	1		
2-2-2	LAX5305242	后部物品盒开关A	Rear glovebox switch 1	1		
2-3	LAX5305212	橡胶缓冲块	Rubber damper	1		
2-4	LAX5305112	铰链	Hinge	1		
2-5	LAX5305211	后部物品盒开关	Rear glovebox switch 2	1		√
2-6	LAX8203200B01	后部烟灰缸总成	Rear ashtray	1	yellow	
2-6	LAX8203200B02	后部烟灰缸总成	Rear ashtray	1	black	√
2-6	LAX8203200B03	后部烟灰缸总成	Rear ashtray	1	grey	
3	LAX5305109	钣金支架	Console bracket	1		√
4	373-4213	塑料螺母	Plastic nut	2		√
5	Q2734816F30	十字槽大半圆头自攻螺钉	Screw	2		√
6	LAX5305121B01	手刹盖板	Parking brake panel	1	yellow	
6	LAX5305121B02	手刹盖板	Parking brake panel	1	black	√

6	LAX5305121B03	手刹盖板	Parking brake panel	1	grey	
7	Q2734816F30	十字槽大半圆头自攻螺钉	Screw	3		√

6.08 杂物箱 Glovebox






6.08 杂物箱 Glovebox

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX5303000B02	杂物箱	Glove box	1	maofeng,black	√
1	LAX5303000B03	杂物箱	Glove box	1	maofeng,grey	
1	LAX5303000B05	杂物箱	Glove box	1	maofeng,yellow	
1	LAX5303000B1B02	杂物箱	Glove box	1	danyang,black	
1	LAX5303000B1B03	杂物箱	Glove box	1	danyang,grey	
1	LAX5303000B1B05	杂物箱	Glove box	1	danyang,yellow	
1-1	LAX5303120B1B02	杂物箱支座组件	Glove box seat	1	danyang	
1-2	Q2734816	十字槽大半圆头自攻螺钉	Screw	7		√
1-3	LAX5303101	杂物箱限位胶套	Glove box sleeve	2		
1-4	LAX5303102	转轴插销	Glove box shaft	2		
1-5	LAX5303110	杂物箱本体组件	Glove box body	1		

6.09 方向盘及安全气囊　Steering wheel and Airbags





6.09 方向盘及安全气囊 Steering wheel and Airbags


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX5824100B02	驾驶员气囊模块	Driver airbag	1	Black	√
1	LAX5824100B04	驾驶员气囊模块	Driver airbag	1	yellow	
1	LAX3402111C1B02	方向盘喇叭盖板	Steering wheel top cover	1	black,for config without airbag	
1	LAX3402111C1B04	方向盘喇叭盖板	Steering wheel top cover	1	yellow,for config without airbag	
2						
2-1	LAX5306102	副安全气囊安装支架	Passenger airbag bracket	1		√
2-2	Q40206	大垫圈	Washer	4		√
2-3	Q33005	全金属六角法兰面锁紧螺母	Nut	4		√
2-4	Q39748202	A型簧片螺母	Nut	6		√
2-5	Q2734816	十字槽大半圆头自攻螺钉	Screw	6		√
3	LAX5824200B02	副驾驶员气囊模块	Passenger airbag	1	Black	√
3	LAX5824200B04	副驾驶员气囊模块	Passenger airbag	1	yellow	
4	Q40112T16F3	平垫圈	Washer	1		
5	Q150B1225	六角头螺栓	Hex bolt	1		√
6	Q1410614	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	2		√
7	LAX3402110B02	方向盘	Steering wheel	1	airbag optional，leather,black	
7	LAX3402110B04	方向盘	Steering wheel	1	airbag optional，leather,yellow	
7	LAX3402110B1B02	方向盘	Steering wheel	1	airbag optional，sponge,black	


7	LAX3402110B1B04	方向盘	Steering wheel	1	airbag optional，sponge,yellow	
7	LAX3402110C1B02	方向盘	Steering wheel	1	airbag unavailable,sponge,black	√

6.09 方向盘及安全气囊 Steering wheel and Airbags

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
7	LAX3402110C1B04	方向盘	Steering wheel	1	airbag unavailable,sponge,yellow	
8	LAX3658300	安全气囊时钟弹簧	Airbag spring	1		√

6.10 顶盖 Headlining







6.10 顶盖 Headlining


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LCA5704200	顶盖右装饰条组件	Headinling trim，right	1		√
2	LCA5704100	顶盖左装饰条组件	Headinling trim，left	1		√
3	LCA5702100B02	顶蓬	Headinling	1	black	√
3	LCA5702100B03	顶蓬	Headinling	1	grey	
3	LCA5702100B07	顶蓬	Headinling	1	yellow	
4	Q2360520	十字槽盘头螺钉、弹簧垫圈和平垫圈组合件	Screw	6		√
5	LBA8215100B07	安全拉手	Ceiling handle	3	yellow	
5	LBA8215100B02	安全拉手	Ceiling handle	3	black	√
5	LBA8215100B03	安全拉手	Ceiling handle	3	grey	
6	L5602012B01	塑料卡扣	Plastic clip	2	yellow	
6	L5602012B02	塑料卡扣	Plastic clip	2	black	√
6	L5602012B03	塑料卡扣	Plastic clip	2	grey	
7	L8204200B01	右遮阳板总成	Right sunvisor	1	yellow	
7	L8204200B02	右遮阳板总成	Right sunvisor	1	black	√
7	L8204200B03	右遮阳板总成	Right sunvisor	1	grey	
8	335-4820F30	内六角花形盘头螺钉	Screw	2		√
9	335-4216F30	内六角花形盘头螺钉	Screw	2		
10	L8204100B01	左遮阳板总成	Left sunvisor	1	yellow	

10	L8204100B02	左遮阳板总成	Left sunvisor	1	black	√
10	L8204100B03	左遮阳板总成	Left sunvisor	1	grey	

6.10 顶盖 Headlining

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
11	LCA5704103	顶盖左装饰条后部件	Headinling trim component，left	1		
12	LCA5704203	顶盖右装饰条后部件	Headinling trim component，right	1		

6.11 左侧围（上） Left side body attachment（upper）





6.11 左侧围（上） Left side body attachment（upper）


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX5402111B02	A柱左护板	A pillar trim，left	1	black	√
1	LAX5402111B03	A柱左护板	A pillar trim，left	1	grey	√
1	LAX5402111B04	A柱左护板	A pillar trim，left	1	yellow	
2	L5402112	卡扣	Clip	2		√
3	LAX5402120	B柱左护板总成	B pillar trim assy.left	1		
3-1	LAX5402131B02	B柱左下护板	B pillar trim ， left lower	1	black	√
3-1	LAX5402131B05	B柱左下护板	B pillar trim ， left lower	1	yellow	
3-2	LAX5402121B02	B柱左上护板	B pillar trim ， left upper	1	black	√
3-2	LAX5402121B03	B柱左上护板	B pillar trim ， left upper	1	grey	
3-2	LAX5402121B05	B柱左上护板	B pillar trim ， left upper	1	yellow	
3-3	L5402123	导板限位板	Safety belt panel stopper	1	PP	
3-4	LAX5402122B02	安全带导板	Safety belt panel	1	black	√
3-4	LAX5402122B05	安全带导板	Safety belt panel	1	yellow	
4	L5402124	金属卡扣	Metal clip	7	65Mn	√
5	L5402132	塑料螺母	Plastic nut	4	PA66	√
6	335-4216F30	内六角花形大盘头螺钉	Screw	6		
7	LCA5402140B02	C柱左上护板组件	C pillar trim ， left upper	1	black	√
7	LCA5402140B03	C柱左上护板组件	C pillar trim ， left upper	1	grey	√

7	LCA5402140B05	C柱左上护板组件	C pillar trim， left upper	1	yellow	
7-2	LCA5402142	C柱上护板缓冲海绵	Sponge damper	3		

6.11 左侧围（上） Left side body attachment（upper）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
8	L5402124	金属卡扣	Metal clip	7	65Mn	√
9	LCA5402150	C柱左下护板组件	C pillar trim assy.left lower	1		
9-1	LCA5402151B02	C柱左下护板	C pillar trim， left lower	1	black	√
9-1	LCA5402151B05	C柱左下护板	C pillar trim， left lower	1	yellow	
9-2	LCA5402152B02	C柱左下护板螺钉孔盖板	Screw cap	1	black	√
9-2	LCA5402152B05	C柱左下护板螺钉孔盖板	Screw cap	1	yellow	
10	Q2734216	十字槽半圆头自攻螺钉	Screw	3		√
11	Q398B03	A型通孔式塑料卡扣	Plastic nut	3		√

6.12 左侧围（下） Left side body attachment（lower）




6.12 左侧围（下） Left side body attachment（lower）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LCA5407101	后背门导向块	Tail door guide	1		√
2	Q2620620	十字槽盘头自攻锁紧螺钉	Screw	2	M6	√
3	Q32006	六角法兰面螺母	Hex flange nut	2	M6	√
4	LCA5207400	洗涤壶组件（后）	Rear windshield washer	1		√
5	Q25808616T1F30	内六角花形沉头螺钉	Screw	8		√
6	L5408650	门锁扣组件	Door buckle	4		√
7	LCA8212011	左后挡泥板	Rear left mud guard 1	1		√
8	Q39748202	A型簧片螺母	Nut	2		√
9	LCA8212013	左后下挡泥板	Rear left mud guard 2	1		√
10	L8212012	子母扣	Inlay clip	3		√
11	LCA5406100B1	左侧窗玻璃总成	Left quarter Window glass assy.	1		
11-1	LCA5406101	左侧窗玻璃	Left quarter Window glass	1		√
11-2	LCA5406102	左侧窗玻璃密封条	Seal，left quarter Window glass	1		√
12	LCA5407112	天窗水管橡胶套	Pipe sleeve，left	1		
13	LAX6107012A2B03	左前车门密封条	Weather strip，front left door	1	yellow	
13	LAX6107012B02	左前车门密封条	Weather strip，front left door	1	black	√
14	LAX6207012A2B03	左后车门密封条	Weather strip，rear left door	1	yellow	
14	LAX6207012B02	左后车门密封条	Weather strip，rear left door	1	black	√

15	L6107111	左门框密封条	Weather strip，roof left side	1		√

6.13 右侧围（上） Right side body attachment（upper）





6.13 石侧围（上） Right side body attachment（upper）


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX5402211B02	A柱右护板	A pillar trim，right	1	black	√
1	LAX5402211B03	A柱右护板	A pillar trim，right	1	grey	√
1	LAX5402211B04	A柱右护板	A pillar trim，right	1	yellow	
2	LAX5402220	B柱右护板总成	B pillar trim assy.right	1		
2-1	LAX5402221B02	B柱右上护板	B pillar trim，right upper	1	black	√
2-1	LAX5402221B03	B柱右上护板	B pillar trim，right upper	1	grey	√
2-1	LAX5402221B05	B柱右上护板	B pillar trim，right upper	1	yellow	
2-2	LAX5402122B02	安全带导板	Safety belt panel	1	black	√
2-2	LAX5402122B05	安全带导板	Safety belt panel	1	yellow	
2-3	L5402123	导板限位板	Safety belt panel stopper	1		
2-4	LAX5402231B02	B柱右下护板	B pillar trim，right lower	1	black	√
2-4	LAX5402231B05	B柱右下护板	B pillar trim，right lower	1	yellow	
3	LCA5402240B02	C柱右上护板组件	C pillar trim，right upper	1	black	√
3	LCA5402240B03	C柱右上护板组件	C pillar trim，right upper	1	grey	√
3	LCA5402240B05	C柱右上护板组件	C pillar trim，right upper	1	yellow	
3-2	LCA5402142	C柱上护板缓冲海绵	Sponge damper	3		
4	LCA5402250	C柱右下护板组件	C pillar trim assy.right lower	1		
4-1	LCA5402251B02	C柱右下护板	C pillar trim，right lower	1	black	√

4-1	LCA5402251B05	C柱右下护板	C pillar trim，right lower	1	yellow	
4-2	LCA5402252B02	C柱右下护板螺钉孔盖板	Screw cap	1	black	√

6.13 右侧围（上） Right side body attachment（upper）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
4-2	LCA5402252B05	C柱右下护板螺钉孔盖板	Screw cap	1	yellow	
5	L5402112	卡扣	Clip	2		√
6	L5402124	金属卡扣	Metal clip	7		√
7	Q2734216	十字槽大半圆头自攻螺钉	Screw	2		√
8	L5402132	塑料螺母	Plastic nut	2		√
9	Q2620620	十字槽盘头自攻锁紧螺钉	Screw	2	M6	√
10	LCA5407101	后背门导向块	Tail door guide	1		√
11	Q2734216	十字槽大半圆头自攻螺钉	Screw	3		√
12	Q398B03	A型通孔式嵌装塑料螺母	Plastic nut	3		√

6.14 右侧围（下） Right side body attachment（lower）






6.14 右侧围（下） Right side body attachment（lower）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L6107211	右门框密封条	Weather strip，roof right side	1		√
2	LCA5406200B1	右侧窗玻璃总成	Left quarter Window glass assy.	1		
2-1	LCA5406202	右侧窗玻璃密封条	Seal，left quarter Window glass	1		√
2-2	LCA5406201	右侧窗玻璃	Left quarter Window glass	1		√
3	LAX6207022B02	右后车门密封条	Weather strip，rear right door	1	black	√
3	LAX6207022A2B03	右后车门密封条	Weather strip，rear right door	1	yellow	
4	LAX6107022B02	右前车门密封条	Weather strip，front right door	1	black	√
4	LAX6107022A2B03	右前车门密封条	Weather strip，front right door	1	yellow	
5	Q2580616T1F30	内六角花形沉头螺钉	Screw	8		√
6	L5408650	门锁扣组件	Door buckle	4		√
7	LCA8123630	通风口组件	Vent	1		√
8	LCA5407102	天窗水管橡胶套	Pipe sleeve，right	1		
9	L8212012	子母扣	Inlay clip	3		√
10	LCA8212022	右后下挡泥板	Rear right mud guard 2	1		√
11	LCA8212021	右后挡泥板	Rear right mud guard 1	1		√

6.15 前侧车门　Front door attachment





6.15 前侧车门 Front door attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L6103111	左前车门玻璃	Glass，front left window	1		√
1	L6103112	右前车门玻璃	Glass，front right window	1		√
2	L6103113	车门玻璃导向块	Glass locating piece	2		√
3	L6103114	玻璃卡扣	Clip	2		√
4	L6107113A2	左前车门玻璃外胶条	Outside glass seal，front left window	1		√
4	L6107214A2	右前车门玻璃外胶条	Outside glass seal，front right window	1		√
5	L6107117	左前车门防擦条	Molding，front left door	1		√
5	L6107218	右前车门防擦条	Molding，front right door	1		√
6	L5402311	B柱左饰板一	B pillar left decoration 1	1		√
6	L5402411	B柱右饰板一	B pillar right decoration 1	1		√
7	L6105150	左前车门外扣手组件	Outer handle,front left door	1		√
7	L6105260	右前车门外扣手组件	Outer handle, front right door	1		√
8	L8202100	左后视镜带转向灯总成	Outside mirror，left	1	Donnelly	√
8	L8202100A2	左后视镜带转向灯总成	Outside mirror，left	1	Dongguang	
8	L8202100B1	左后视镜带转向灯总成(手动)	Outside mirror，left	1	manual	
8	L8202100C1	左后视镜带转向灯总成	Outside mirror，left	1	extra defrost function	√
8	L8202200	右后视镜带转向灯总成	Outside mirror，right	1	Donnelly	√
8	L8202200A2	右后视镜带转向灯总成	Outside mirror，right	1	Dongguang	

8	L8202200B1	右后视镜带转向灯总成(手动)	Outside mirror，right	1	manual	
8	L8202200C1	右后视镜带转向灯总成	Outside mirror，right	1	extra defrost function	√

6.15 前侧车门 Front door attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
8-1	L4111100	左后视镜转向灯	Steering light,left outside mirror	1	Donnelly	√
8-1	L4111100D1	左后视镜转向灯	Steering light,left outside mirror		Dongguang	
8-1	L4111200	右后视镜转向灯	Steering light,right outside mirror	1	Donnelly	√
8-1	L4111200D1	右后视镜转向灯	Steering light,right outside mirror	1	Dongguang	
8-2	L8202103	左后视镜外壳（电动）	Outside mirror shell，left	1	Donnelly	√
8-2	L8202103D1	左后视镜外壳（电动）	Outside mirror shell，left	1	Dongguang	
8-2	L8202203	右后视镜外壳（电动）	Outside mirror shell，right	1	Donnelly	√
8-2	L8202203D1	右后视镜外壳（电动）	Outside mirror shell，right	1	Dongguang	
8-3	L8202102	左后视镜底座	Outside mirror mount，left	1	Donnelly	
8-3	L8202102D1	左后视镜底座	Outside mirror mount，left	1	Dongguang	
8-3	L8202202	右后视镜底座	Outside mirror mount，right	1	Donnelly	
8-3	L8202202D1	右后视镜底座	Outside mirror mount，right	1	Dongguang	
8-4	L8202105	左后视镜镜片	Outside mirror lens，left	1	Donnelly	√
8-4	L8202105D1	左后视镜镜片	Outside mirror lens，left	1	Dongguang	
8-4	L8202205	右后视镜镜片	Outside mirror lens，right	1	Donnelly	√
8-4	L8202205D1	右后视镜镜片	Outside mirror lens，right	1	Dongguang	
9	Q33006	全金属六角法兰面锁紧螺母	Nut	6		√
10	L6107123	车门外板减振垫	Door damper pad	2		√

11	L6104100	左前车门玻璃升降器总成	Window lifter，front left	1		
11	L6104100A2	左前车门玻璃升降器总成	Window lifter，front left	1	motor made in china	√

6.15 前侧车门 Front door attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
11	L6104200	右前车门玻璃升降器总成	Window lifter，front right	1		
11	L6104200A2	右前车门玻璃升降器总成	Window lifter，front right	1	motor made in china	√
12	LAX6105121	左前车门内开保险拉杆	Safety rod，front left door	1		√
12	LAX6105232	右前车门内开保险拉杆	Safety rod，front right door	1		√
13	L6105113	左前车门门锁外拉手连杆	Connecting rod，front left door	1		√
13	L6105224	右前车门门锁外拉手连杆	Connecting rod，front left door	1		√
14	L6105110	左前车门门锁组件	Lock，front left door	1		√
14	L6105220	右前车门门锁组件	Lock，front right door	1		√
15	LAX6105123	左前门内开锁拉索	Lock cable，front left door	1		√
15	LAX6105223	右前门内开锁拉索	Lock cable，front right door	1		√
16	L6109100	车门限位器总成	Door stopper	2		√
17	L8202113	后视镜盖板卡扣	Clip，Outside mirror cap	4	canceled	√
18	LAX8202111B01	左后视镜盖板	Outside mirror cap，left	1	yellow	
18	LAX8202111B02	左后视镜盖板	Outside mirror cap，left	1	black	√
18	LAX8202211B01	右后视镜盖板	Outside mirror cap，right	1	yellow	
18	LAX8202211B02	右后视镜盖板	Outside mirror cap，right	1	black	√
19	L6107114	左前车门泥槽	Mud groove,front left door	1		√
19	L6107212	右前车门泥槽	Mud groove,front right door	1		√

20	LAX6107115	左前车门玻璃内胶条	Inner glass seal,front left door	1		√
20	LAX6107216	右前车门玻璃内胶条	Inner glass seal,front right door	1		√

6.15 前侧车门 Front door attachment


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
21	LAX6102021A2	左前门防雨帘	Rain proof,front left door	1		√
21	LAX6102022A2	右前门防雨帘	Rain proof,front right door	1		√
22	L6102101	卡扣	Clip	14		√
23	LAX6105810B02	车门锁止器	Door lock component	4	black	√
23	LAX6105810B04	车门锁止器	Door lock component	4	yellow	
24	LAX6105821B02	车门锁止器座	Door lock seat	4	black	√
24	LAX6105821B04	车门锁止器座	Door lock seat	4	yellow	
25	LAX6102100B02	左前门内饰总成	Front left door trim	1	black	√
25	LAX6102100B98	左前门内饰总成	Front left door trim	1	upper black lower grey	√
25	LAX6102100B99	左前门内饰总成	Front left door trim	1	yellow	
25	LAX6102200B02	右前门内饰总成	Front right door trim	1	black	√
25	LAX6102200B98	右前门内饰总成	Front right door trim	1	upper black lower grey	√
25	LAX6102200B99	右前门内饰总成	Front right door trim	1	yellow	
26	LAX6105300B02	左车门内扣手组件	Inner handle,left door	1	black	√
26	LAX6105300B03	左车门内扣手组件	Inner handle,left door	1	grey	
26	LAX6105300B05	左车门内扣手组件	Inner handle,left door	1	yellow	
26	LAX6105400B02	右车门内扣手组件	Inner handle,right door	1	black	√
26	LAX6105400B03	右车门内扣手组件	Inner handle,right door	1	grey	

26	LAX6105400B05	右车门内扣手组件	Inner handle,right door	1	yellow	
27	Q33006	全金属六角法兰面锁紧螺母	Nut	10		√

6.15 前侧车门 Front door attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
28	BL1202	卡扣	Clip	6		√
29	Q2580616T1F30	内六角花形沉头螺钉	Screw	2		√

6.16 后侧车门　Rear door attachment





6.16 后侧车门 Rear door attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L6207218	右后车门防擦条	Molding，rear right door	1		√
1	L6207117	左后车门防擦条	Molding，rear left door	1		√
2	L6203212	右后车门玻璃	Glass，rear right window	1		√
2	L6203111	左后车门玻璃	Glass，rear left window	1		√
3	L6103113	车门玻璃导向块	Glass locating piece	2		√
4	L5402321	C柱左饰板	C pillar left decoration	1		√
4	L5402421	C柱右饰板	C pillar right decoration	1		√
5	L6103114	玻璃卡扣	Clip	2		√
6	L6207214A2	右后车门玻璃外胶条	Outside glass seal,front right door	1		√
6	L6207113A2	左后车门玻璃外胶条	Outside glass seal,front left door	1		√
7	L5402312	B柱左饰板二	B pillar left decoration 2	1		√
7	L5402412	B柱右饰板二	B pillar right decoration 2	1		√
8	L6205150	左后车门外扣手组件	Outer handle,rear left door	1		√
8	L6205260	右后车门外扣手组件	Outer handle, rear right door	1		√
9	L6107123	车门外板减振垫	Door damper pad	2		√
10	L6204100	左后车门玻璃升降器总成	Window lifter，rear left	1		
10	L6204100A2	左后车门玻璃升降器总成	Window lifter，rear left	1	motor made in china	√
10	L6204200	右后车门玻璃升降器总成	Window lifter，rear right	1		

10	L6204200A2	右后车门玻璃升降器总成	Window lifter，rear right	1	motor made in china	√
11	L6205228	右后门内开保险拉杆前段	Safety rod fore part，rear right door	1		√

6.16 后侧车门 Rear door attachment


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
11	L6205117	左后门内开保险拉杆前段	Safety rod fore part，rear left door	1		√
12	LAX6205134	左后车门内开门拉索	Lock cable，rear left door	1		√
12	LAX6205234	右后车门内开门拉索	Lock cable，rear right door	1		√
13	L6205220	右后车门门锁组件	Lock，rear right door	1		√
13	L6205110	左后车门门锁组件	Lock，rear left door	1		√
14	L6109100	车门限位器总成	Door stopper	2		√
15	L6205224	右后车门内开门锁转换块	Lock switch，rear right door	1		√
15	L6205113	左后车门内开门锁转换块	Lock switch，rear left door	1		√
16	LAX6205232	右后门内开保险拉杆后段	Safety rod rear part，rear right door	1		√
16	LAX6205121	左后门内开保险拉杆后段	Safety rod rear part，rear left door	1		√
17	L6207111	左后车门泥槽	Mud groove,rear left door	1		√
17	L6207212	右后车门泥槽	Mud groove,rear right door	1		√
18	LAX6207216	右后车门玻璃内胶条	Inner glass seal,rear right door	1		√
18	LAX6207115	左后车门玻璃内胶条	Inner glass seal,rear left door	1		√
19	LAX6202021A2	左后门防雨帘	Rain proof,rear left door	1		√
19	LAX6202022A2	右后门防雨帘	Rain proof,rear right door	1		√
20	Q2580616T1F30	内六角花形沉头螺钉	Screw	12		√
21	LAX6105810B02	车门锁止器	Door lock component	4	black	√

21	LAX6105810B04	车门锁止器	Door lock component	4	yellow	
22	LAX6105821B02	车门锁止器座	Door lock seat	4	black	√

6.16 后侧车门 Rear door attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
22	LAX6105821B04	车门锁止器座	Door lock seat	4	yellow	
23	LAX6202200B02	右后门内饰板总成	Rear right door trim	1	black	√
23	LAX6202200B98	右后门内饰板总成	Rear right door trim	1	upper black lower grey	√
23	LAX6202200B99	右后门内饰板总成	Rear right door trim	1	yellow	
23	LAX6202100B02	左后门内饰板总成	Rear left door trim	1	black	√
23	LAX6202100B98	左后门内饰板总成	Rear left door trim	1	upper black lower grey	√
23	LAX6202100B99	左后门内饰板总成	Rear left door trim	1	yellow	
24	LAX6105300B02	左车门内扣手组件	Inner handle,left door	1	black	√
24	LAX6105300B03	左车门内扣手组件	Inner handle,left door	1	grey	
24	LAX6105300B05	左车门内扣手组件	Inner handle,left door	1	yellow	
24	LAX6105400B02	右车门内扣手组件	Inner handle,right door	1	black	√
24	LAX6105400B03	右车门内扣手组件	Inner handle,right door	1	grey	
24	LAX6105400B05	右车门内扣手组件	Inner handle,right door	1	yellow	
25	Q33006	全金属六角法兰面锁紧螺母	Nut	10		√
26	L6205111	后车门锁杆固定卡扣	Rear door clip	2		√
27	L6205115	转换块卡扣	Lock switch clip	2		√
28	L6207126	左后门前胶条	Front glass channel,rear left door	1		√
28	L6207226	右后门前胶条	Front glass channel,rear right door	1		√

6.17 后背门内饰 Tail door interior







6.17 后背门内饰 Tail door interior

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LCA6302112B02	后背门上右护板	Tail door trim,right upper	1	black	√
1	LCA6302112B05	后背门上右护板	Tail door trim,right upper	1	yellow	
2	L6102101	卡扣	Clip	10		√
3	LCA6302116B02	搁物板挂钩	Hook for trunk shelf	2	black	√
3	LCA6302116B05	搁物板挂钩	Hook for trunk shelf	2	yellow	
4	L5402124	金属卡扣	Metal clip	4		√
5	LCA6302113B02	后背门上中护板	Tail door trim,upper	1	black	√
5	LCA6302113B05	后背门上中护板	Tail door trim,upper	1	yellow	
6	Q2734216	十字槽大半圆头自攻螺钉	Screw	10		√
7	Q398B03	A型通孔式嵌装塑料螺母	Nut	10		√
8	LCA6302111B02	后背门上左护板	Tail door trim,left upper	1	black	√
8	LCA6302111B05	后背门上左护板	Tail door trim,left upper	1	yellow	
9	LCA6302120B02	后背门下护板总成	Tail door trim,lower	1	black	√
9	LCA6302120B05	后背门下护板总成	Tail door trim,lower	1	yellow	
9-1	LCA6302122	后背门缓冲海绵	Tail door trim sponge damper	1		
10	LCA6302115	后背门搁物板压块	Tail door trim fixer	2		√
11	LCA6302114B02	后背门拉手	Tail door handle	1	black	√
11	LCA6302114B05	后背门拉手	Tail door handle	1	yellow	

12	Q2360620	十字槽盘头螺钉、弹垫、平垫组合件	Bolt and washers	2		√

6.18 后背门外饰 Tail door exterior







6.18 后背门外饰 Tail door exterior


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LCA6314101	后扰流板本体	Rear spoiler panel	1		√
2	LCA6302101	后背门穿线孔堵塞	Tail door wire plug	2		√
3	LCA6306100	后背门铰链总成	Tail door hinge	2		√
4	LCA6307101	后背门框密封条	Weather strip，tail door	1		√
5	LCA6314103	后扰流板密封垫	Rear spoiler seal	1		√
6	LCA5207401	洗涤壶喷嘴（后）	Rear washer nozzle	1		√
7	Q2734816	十字槽半圆头自攻螺钉	Screw	2		√
8	LCA6302102	后背门水管堵塞	Tail door pipe plug	1		√
9	LCA6310110	后背门雨刮臂总成	Rear windshield wiper arm	1		√
10	LCA6309110	后背门气弹簧总成	Tail door pneumatic spring	2		√
11	LCA6307102	后背门玻璃左右侧密封条	Rear windshield side seal	2		√
12	LCA6310100	后背门刮水器总成	Rear windshield washer	1		
13	Q1840620	六角法兰面螺栓	Hex flange bolt	3		√
14	LCA6305110	后背门锁总成	Tail door lock system	1		√
14-1	LCA6305140	后背门扣手总成	Tail door opening switch	1		√
14-2	LCA6305110	后背门锁体总成	Tail door buckle	1		√
14-3	LCA6305150	后背门拉线组件	Tail door opening cable	1		√
15	LCA3921012	车身后标识牌	Rear logo emblem“LLL”	1	chromium 8 grade	


15	LCA3921012A2	车身后标识牌	Rear logo emblem“LLL”	1	chromium 9 grade	√
16	L8402815	行李箱缓冲块	Tail door damper block	2		

6.18 后背门外饰 Tail door exterior

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
17	Q2300616	十字槽盘头螺钉和平垫圈组合件	Screw and washer	2		√
18	LCA5506102	牌照灯外饰板密封条	Seal,lisence plate trim	1		
19	LCA5506100	后牌照灯饰板组件	Lisence plate trim	1	chromium 8 grade	
19	LCA5506100A2	后牌照灯饰板组件	Lisence plate trim	1	chromium 9 grade	√
20	LCA6303101	后背门玻璃	Rear windshield	1		√
21	LCA6307116	后挡风玻璃下密封条	Rear windshield lower seal	1		√
22	LCA5401530	加油口盖拉锁组合	Fuel filler opening cable	1		√
23	LCA5401531	密封堵塞	Plug	1		
24	Q1840616	六角法兰面螺栓	Hex flange bolt	3		√

6.19 后围(上） Rear cowl attachment（upper）






6.19 后围(上） Rear cowl attachment（upper）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LCA5608400	搁物板组件	Trunk shelf assy.	1		√
1-1	LCA5608411B02	搁物板	Trunk shelf	1	black	√
1-1	LCA5608411B09	搁物板	Trunk shelf	1	yellow	
1-2	LCA5608414	搁物板右支撑板	Trunk shelf support，right	1		√
1-3	LCA5608413	搁物板左支撑板	Trunk shelf support，left	1		√
1-4	LCA5608412B02	搁物板拉绳	Trunk shelf rope	2		√
2	LCA5608110B02	行李箱左侧护面组件	Trunk side trim assy.left	1		√
2-1	LCA5608111	行李箱左侧护面	Trunk side trim，left	1		√
2-2	LCA5608112	行李箱护面减振垫	Trunk side trim damper	1		√
3	LCA5608210B02	行李箱右侧护面组件	Trunk side trim assy.right	1		√
3-1	LCA5608112	行李箱护面减振垫	Trunk side trim damper	1		√
3-2	LCA5608211	行李箱右侧护面	Trunk side trim，right	1		√
4	LCA5608300	行李箱地毯组件	Trunk carpet assy.	1		√
4-1	LCA5608320	备胎盖板组件	Spare tyre cover	1		√
4-2	LCA5608311	行李箱地毯	Trunk carpet	1		√
5	Q2734216	十字槽大半圆头自攻螺钉	Screw	10		√
6	Q398B03	塑料螺母	Plastic nut	10		√
7	L5602012	塑料卡扣	Plastic clip	12		√

6.20 后围(下） Rear cowl attachment（lower）






6.20 后围(下） Rear cowl attachment（lower）

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LCA5602010B02	后裙板护板	Rear skirt panel trim	1		√
2	LCA5602013	后裙板护板缓冲海绵	Rear skirt panel trim damper	1		
3	L5602012B01	塑料卡扣	Plastic clip	5	yellow	
3	L5602012B02	塑料卡扣	Plastic clip	5	black	√
3	L5602012B03	塑料卡扣	Plastic clip	5	grey	
4	L5402124	金属卡扣	Metal clip	4		√
5	Q150B0620T1F30	六角头螺栓	Hex bolt	14		√
6	Q4400516	开口型扁圆头抽芯铆钉	Rivet	8		√
7	Q2735519	十字槽大半圆头自攻螺钉	Screw	4		
8	LCA2804000	后保险杠总成	Rear bumper	1		√
8	LCA2804000B1	后保险杠总成	Rear bumper	1	for reverse radar	
8-1	LCA2804101	后保险杠左缓冲块	Rear bumper damper，left	1		√
8-2	LCA2804102	后保险杠右缓冲块	Rear bumper damper，right	1		√
8-3	LCA2804030	后保险杠左侧加强板组件	Rear bumper stiffender，left	1		√
8-4	LCA2804032	卡扣A	Clip	4	M6	√
8-6	LCA2804040	后保险杠右侧加强板组件	Rear bumper stiffender，right	1		√
9	Q31206	B型板簧螺母	Nut	4		√

6.21 地板　Floor attachment





6.21 地板　Floor attachment


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX5109012	前地毯右前踏板	Carpet footrest	1		
2	LAX5109011	前地毯左前踏板	Carpet footrest	1		
3	L5109016	前地毯后门固定槽	Carpet channel，rear door	2		
4	LCA5109000B02	前地毯	Carpet	1	black	√
4	LCA5109000B08	前地毯	Carpet	1	yellow	
5	L8212012	子母扣	Clip	2		√
6	L5109015	前地毯前门固定槽	Carpet channel，front door	2		
7	L5109014	塑料卡扣	Plastic clip	4		√
8	L5110021	前地毯前毛毡	Front felt	1		√
9	L5110022	前地毯后毛毡	Rear felt	1		√
10	L5130818	橡胶堵盖	Plug	2	34*40	√
11	L5101017	翻边孔堵盖Φ28	Flued opening plug Φ28	10		√
12	L5101019	橡胶堵盖Φ18	Plug Φ18	14		√
13	L5101018	橡胶堵盖Φ28	Plug Φ28	9		√
14	L5101016	翻边孔堵盖Φ26	Flued opening plug Φ26	1		√
15	L5130817	塑料堵盖	Plastic plug	1		√
16	L5130834	后座椅坐垫Φ8定位销	Rear seat positioning pin	2	canceled	
17	L5101022	橡胶堵盖Φ40	Plug Φ40	6		√


18	L5130832	后座椅安装挂钩	Rear seat mount hook	2		√
19	L5130833	后座椅挂钩塑料套	Hook sleeve	2		√

6.21 地板 Floor attachment

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
20	LCA5130818	橡胶堵盖	Plug	4	30*36	√

6.22 驾驶员座椅　Driver's seat







6.22 驾驶员座椅　Driver's seat

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX6800100A2B01	驾驶员座椅总成	Driver's seat assy	1	Leather，yellow	√
1	LAX6800100A2B02	驾驶员座椅总成	Driver's seat assy	1	Leather，black	√
1	LBA6800100A2B01	驾驶员座椅总成	Driver's seat assy	1	Fabric，yellow	√
1	LBA6800100A2B02	驾驶员座椅总成	Driver's seat assy	1	Fabric，black	√
1-1	LAX6808000A2B01	前排头枕总成	Front pillow	1	Leather，yellow	√
1-1	LAX6808000A2B02	前排头枕总成	Front pillow	1	Leather，black	√
1-1	LBA6808000B01	前排头枕总成	Front pillow	1	Fabric，yellow	√
1-1	LBA6808000B02	前排头枕总成	Front pillow	1	Fabric，black	√
1-2	LAX6802100	驾驶员座围边	Driver's seat surrounding	1		√
1-3	L6804102B01	前靠调角器圆手柄	Front seat backrest adjuster	1	yellow	√
1-3	L6804102B02	前靠调角器圆手柄	Front seat backrest adjuster	1	black	√
1-4	Q32008	六角法兰面螺母	Hex flange nut	6		√
1-5	301-0823T1F30	内六角花形圆柱头螺钉	Screw	6		√
1-6	L6804400	滑轨部装	Front seat slider	2		√
1-7	L6801301	安全带安装座	Safety belt seat	1		
1-8	301-0823TF30	内六角花形圆柱头螺钉	Screw	4		√
1-9	L6800101B02	塑料垫片	Plastic washer	4		

6.23 副驾驶员座椅　Passenger's seat







6.23 副驾驶员座椅　Passenger's seat

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX6900100A2B01	前座椅总成	Passenger's seat assy	1	Leather，yellow	√
1	LAX6900100A2B02	前座椅总成	Passenger's seat assy	1	Leather，black	√
1	LBA6900100A2B01	前座椅总成	Passenger's seat assy	1	Fabric，yellow	√
1	LBA6900100A2B02	前座椅总成	Passenger's seat assy	1	Fabric，black	√
1-1	LAX6808000A2B01	前排头枕总成	Front pillow	1	Leather，yellow	√
1-1	LAX6808000A2B02	前排头枕总成	Front pillow	1	Leather，black	√
1-1	LBA6808000B01	前排头枕总成	Front pillow	1	Fabric，yellow	√
1-1	LBA6808000B02	前排头枕总成	Front pillow	1	Fabric，black	√
1-2	LAX6902100	前座围边	Passenger's seat surrounding	1		√
1-3	L6804102B01	前靠调角器圆手柄	Front seat backrest adjuster	1	yellow	√
1-3	L6804102B02	前靠调角器圆手柄	Front seat backrest adjuster	1	black	√
1-4	Q32008	六角法兰面螺母	Hex flange nut	6		√
1-5	301-0823T1F30	内六角花形圆柱头螺钉	Screw	6		√
1-6	L6804400	滑轨部装	Front seat slider	2		√
1-7	301-0823TF30	内六角花形圆柱头螺钉	Screw	4		√
1-8	L6800101B02	塑料垫片	Plastic washer	4		
1-9	L6801301	安全带安装座	Safety belt seat	1		

6.24 后座椅　Rear seat





6.24 后座椅　Rear seat


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LCA7008100B01	后座椅头枕	Rear pillow	2	Fabric，yellow	√
1	LCA7008100B02	后座椅头枕	Rear pillow	2	Fabric，black	√
1	LCA7008100A2B01	后座椅头枕	Rear pillow	2	Leather，yellow	√
1	LCA7008100A2B02	后座椅头枕	Rear pillow	2	Leather，black	√
2	LCA7007013	后靠背锁扣	Rear seat backrest buckle	2		√
3	LCA7005120	后靠背右侧锁体组件	Rear seat backrest locker，right	1		√
4	301-0823T1F30	内六角花型圆柱头螺钉	Screw	4		√
5	LCA7007012	后靠背右安装支架	Rear seat backrest bracket，right	1		√
6	LCA7005130	后座椅靠背解锁按钮组件	Rear seat backrest switch	1		√
6-1	LCA7005131	后座椅靠背解锁按钮	Rear seat backrest switch button	1		√
6-2	LCA7005132	后座椅靠背解锁按钮座	Rear seat backrest switch seat	1		√
7	LCA7007011	后靠背左安装支架	Rear seat backrest bracket，left	1		√
8	LCA7003000B01	后座软垫	Rear seat cushion	1	Fabric,yellow	√
8	LCA7003000B02	后座软垫	Rear seat cushion	1	Fabric,black	√
8	LCA7003000A2B01	后座软垫	Rear seat cushion	1	leather,yellow	√
8	LCA7003000A2B02	后座软垫	Rear seat cushion	1	leather,black	√
9	L5130833	后座椅挂钩塑料套	Hook sleeve	2		√
10	L5130832	后座椅安装挂钩	Rear seat mount hook	2		√

11	Q32208T13F3	六角头螺母和锥形弹性垫圈组合件	Hex nut and washer	2		√
12	LCA7005110	后靠背左侧锁体组件	Rear seat backrest locker，left	1		√

6.24 后座椅 Rear seat

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
13	LCA7005100B01	后座椅靠背	Rear seat backrest	1	Fabric，yellow	√
13	LCA7005100B02	后座椅靠背	Rear seat backrest	1	Fabric，black	√
13	LCA7005100A2B01	后座椅靠背	Rear seat backrest	1	leather，yellow	√
13	LCA7005100A2B02	后座椅靠背	Rear seat backrest	1	leather，black	√

6.25 安全约束装置　Safety belts





6.25 安全约束装置　Safety belts


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L5811100B10	左前安全带总成	Left safety belt	1	guangda，yellow	
1	L5811100B02	左前安全带总成	Left safety belt	1	guangda，black	
1	LAA5811100B1B10	左前安全带总成	Left safety belt	1	E-Mark，yellow	
1	LAA5811100B1B02	左前安全带总成	Left safety belt	1	E-Mark，black	√
1	LAX5811100B1B10	左前安全带总成	Left safety belt	1	guangda，pre-loaded，yellow	
1	LAX5811100B1B10	左前安全带总成	Left safety belt	1	guangda，pre-loaded，black	
1-1	L5811102B10	安全带盖板	Safety belt cap	1	yellow	
1-1	L5811102B02	安全带盖板	Safety belt cap	1	black	√
2	L5811200B10	右前安全带总成	Right safety belt	1	guangda，yellow	
2	L5811200B02	右前安全带总成	Right safety belt	1	guangda，black	
2	LAA5811200B1B10	右前安全带总成	Right safety belt	1	E-Mark，yellow	
2	LAA5811200B1B02	右前安全带总成	Right safety belt	1	E-Mark，black	√
2	LAX5811200B1B10	右前安全带总成	Right safety belt	1	guangda，pre-loaded，yellow	
2	LAX5811200B1B10	右前安全带总成	Right safety belt	1	guangda，pre-loaded，black	
3	L5811101B10	左前安全带锁扣	Left safety belt buckle	1	guangda，yellow	
3	L5811101B02	左前安全带锁扣	Left safety belt buckle	1	guangda，black	
3	LAA5811101B1B10	左前安全带锁扣	Left safety belt buckle	1	E-Mark，yellow	
3	LAA5811101B1B02	左前安全带锁扣	Left safety belt buckle	1	E-Mark，black	√

4	L5811201B10	右前安全带锁扣	Right safety belt buckle	1	guangda，yellow	
4	L5811201B02	右前安全带锁扣	Right safety belt buckle	1	guangda，black	

6.25 安全约束装置 Safety belts

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
4	LAA5811201B1B10	右前安全带锁扣	Right safety belt buckle	1	E-Mark，yellow	
4	LAA5811201B1B02	右前安全带锁扣	Right safety belt buckle	1	E-Mark，black	√
5	231-(7/16) " 35TF3	六角法兰面螺栓	Hex flange bolt	2		√
6	LCA5812110B10	左后安全带卷收器总成	Rear safety belt，left	1	guangda，yellow	
6	LCA5812110B02	左后安全带卷收器总成	Rear safety belt，left	1	guangda，black	√
7	Q1410616L	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	2		√
8	LCA5812120B10	左后安全带锁扣总成	Rear safety belt buckle，left	1	guangda，yellow	
8	LCA5812120B02	左后安全带锁扣总成	Rear safety belt buckle，left	1	guangda，black	
8	LCA5812120A2B10	左后安全带锁扣总成	Rear safety belt buckle，left	1	E-Mark，yellow	
8	LCA5812120A2B02	左后安全带锁扣总成	Rear safety belt buckle，left	1	E-Mark，black	√
9	LCA5812220B10	右后安全带锁扣总成	Rear safety belt buckle，right	1	guangda，yellow	
9	LCA5812220B02	右后安全带锁扣总成	Rear safety belt buckle，right	1	guangda，black	
9	LCA5812220A2B10	右后安全带锁扣总成	Rear safety belt buckle，right	1	E-Mark，yellow	
9	LCA5812220A2B02	右后安全带锁扣总成	Rear safety belt buckle，right	1	E-Mark，black	√
10	LCA5812210B10	右后安全带卷收器总成	Rear safety belt，right	1	guangda，yellow	
10	LCA5812210B02	右后安全带卷收器总成	Rear safety belt，right	1	guangda，black	√

6.26 标识牌 Logo emblem






6.26 标识牌 Logo emblem

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LCA3921011A2	车身前标识牌	Front Logo emblem“LLL”	1		√
2	LCA3921012A2	车身尾标识牌	Rear Logo emblem“LLL”	1		√
3	LAX3113211	轮毂中心标牌	Wheel emblem	4		√
4	LCB3921015	车尾车型标牌	Rear Logo emblem“LF7161A”	1		√
5	LCA3921019A2	车尾车型标识Ⅱ	Rear Logo emblem“520i”	1		√
6	L3921013B2	车尾车名标识牌	Rear Logo emblem“LIFAN”	1		√
7	L3921018A2	车侧门标牌	Side emblem“1.6L”	2		√

7.Air conditioner

7.01 控制开关　A/C controller






7.01 控制开关　A/C controller

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX8112100	控制面板总成	A/C control panel	1	hengan,manuel	√
1	LAX8112100D1	控制面板总成	A/C control panel	1	Tenglong，Manuel	√
1-1	LAX8112161	旋钮一	Knob 1	2		√
1-2	LAX8112162	旋钮二	Knob 2	1		√
2-1	L8100104	地板门拉索	A/C control cable 1	1		√
2-2	L8100105	大门板拉索	A/C control cable 2	1		√
2-3	L8100108	小门板拉索	A/C control cable 3	1		√
4	Q2714213	十字槽盘头自攻螺钉	Screw	4		√

7.02 冷凝器　A/C condenser





7.02 冷凝器　A/C condenser


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L8105200	冷却风扇总成	Cooling fan	1		√
1-1	L8105210	冷却风扇罩	Cooling fan shield	1		√
1-2	L8105220	冷却风扇电机	Cooling fan motor	1		√
1-3	L8105203	冷却风扇扇叶	Cooling fan blade	1		√
2	Q1460630T1F30	六角头螺栓、弹簧垫圈和平垫圈组合	Hex bolt and washer	3		√
3	Q1410625T1F30	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	2		√
4	L8105100	冷凝器带储液器总成	A/C condenser	1	Hengan	
	L8105100C1	冷凝器带储液器总成	A/C condenser	1	Tenglong	
4-1	Q150B0625	六角头螺栓	Hex bolt	1	M6×25	√
4-2	L8105160	右支架组件	Right bracket，condenser	1		
4-3	Q174B0612	六角头头部带十字槽螺栓	Bolt	4	M6×12	√
4-4	L8105150	左支架组件	Left bracket，condenser	1		
4-5	Q2140530	十字槽盘头螺钉	Screw	4	M5×30	
4-6	L8105140	支撑架组件	Lower bracket，condenser	2	Hengan，tenglong	
4-7	Q1400625	六角头螺栓和平垫圈组合	Hex bolt and washer	1	M6×25	
4-8	Q1400816	六角头螺栓和平垫圈组合	Hex bolt and washer	1	M8×16	
4-9	Q33008	全金属六角法兰面锁紧螺母	Nut	1	M8	√
4-10	Q33006	全金属六角法兰面锁紧螺母	Nut	1	M6	√


4-11	Q40108	平垫圈	Flat washer	1		√
4-12	L8105120	储液器	Coolant receiver	1		√

7.02 冷凝器 A/C condenser

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
4-13	Q40305	弹性垫圈	Elastic washer	4		√
4-14	Q40105	平垫圈	Flat washer	4		√
4-15	Q40306	弹性垫圈	Elastic washer	4		√
4-16	Q40106	平垫圈	Flat washer	4		√
4-17	L8105130	压力开关	Pressure switch	1	Hengan	√
4-17	L8105130B1	压力开关	Pressure switch	1	Tenglong	
4-18	L8105110	冷凝器	Condenser body	1		√

7.03 空调管路　A/C pipeline





7.03 空调管路　A/C pipeline

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L8108501	单管夹片	Mono tube clip	1		√
2	Q2734816	十字槽大半圆头自攻螺钉	Screw	1		√
3	L8108500	蒸发器进出管总成	Evaporator pipe assy	1	hengan	√
3	L8108500B1	蒸发器进出管总成	Evaporator pipe assy	1	tenglong	√
3-1	Q67405100	扎带	Tie	1		
3-2	17×1.8-G-N-GB/T 3452.1-2005	O型圈	Ring seal	1		√
3-3	8×1.8-G-N-GB/T 3452.1-2005	O型圈	Ring seal	1		√
4	Q1410625T1F30	六角头螺栓和锥形弹性垫圈组合	Hex bolt and taper elastic washer	1	M6×25	√
5	L8108502	双管夹片	Twin tube clip	1		√
6	Q33006	全金属六角法兰面锁紧螺母	Nut	2		√
7	L8107109	膨胀阀安装双头螺柱	Bolt，expansion valve	2		√
8	L8106010	膨胀阀	Expansion valve	1		√
9	LBA8103120	压缩机皮带张紧轮组件	Compressor tensioner	1		√
9-1	Q33010	全金属六角法兰面锁紧螺母	Nut	1		√
9-2	LBA8103123	张紧轮防护罩	Tensioner cap	1		√
9-3	LBA8103124	皮带轮	Pulley	1		√
9-4	LBA8103122	主轴轴套	Tensioner shaft sleeve	1		√
9-5	LBA8103121	主轴	Tensioner shaft	1		√

9-6	Q14608100Q	六角头螺栓	Hex bolt	1		√
10	LBA8103101B1	压缩机支架	Compressor bracket	1	Aotecar	√

7.03 空调管路 A/C pipeline


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
10	LBA8103101C1	压缩机支架	Compressor bracket	1	Jianshe	√
11	Q151C1040	六角头螺栓	Hex bolt	1		√
12	LBA8103100B1	压缩机总成	Compressor	1	Aotecar	√
12	LBA8103100C1	压缩机总成	Compressor	1	Jianshe	
12-1	LBA8103110B1	压缩机离合器总成	Compressor clutch	1	Aotecar	√
12-1	LBA8103110C1	压缩机离合器总成	Compressor clutch	1	Jianshe	
12-2	L8103102	压缩机热保护器	Compressor fuse	1	Jianshe	
12-2	LBA8103102B1	压缩机热保护器	Compressor fuse	1	Aotecar	√
13	Q1840890	六角法兰面螺栓	Hex flange bolt	3	Jianshe	√
13	Q18408105	六角法兰面螺栓	Hex flange bolt	4	Aotecar	√
14	LBA8103109	压缩机皮带	Compressor belt	1		√
15	LBA8108200B1	压缩机排气管总成	Compressor exhaust pipe	1	Aotecar	√
15	LBA8108200C1	压缩机排气管总成	Compressor exhaust pipe	1	Jianshe	
15-1	11.2×2.65-G-N-GB/T 3452.1-2005	0形圈	Ring seal	1		√
15-2	13.2×1.8-G-N-GB/T 3452.1-2005	0形圈	Ring seal	2		√
15-3	Q1840830	六角法兰面螺栓	Hex flange bolt	1	Aotecar	√
15-3	Q1840625	六角法兰面螺栓	Hex flange bolt	1	Jianshe	√
16	Q1410625T1F30	六角头螺栓和锥形弹性垫圈组合件	Hex bolt and taper elastic washer	1		√


17	L8108303	单管夹片2	Mono tube clip II	1		√
18	L8108300	储液器出液管总成	Coolant receiver pipe	1	hengan	√

7.03 空调管路 A/C pipeline

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
18	L8108300C1	储液器出液管总成	Coolant receiver pipe	1	tenglong	√
18-1	6.9×1.8-G-N-GB/T 3452.1-2005	O形圈	Ring seal	2		√
18-2	8×1.8-G-N-GB/T 3452.1-2005	O形圈	Ring seal	2		√
18-3	L8108322	护套II	Sleeve II	1		
18-4	L8108321	护套I	Sleeve I	1		
19	LBA8108400	压缩机吸气管总成	Compressor suction pipe	1	Jianshe	
19	LBA8108400B1	压缩机吸气管总成	Compressor suction pipe	1	Aotecar	√
19-1	14×2.65-G-N-GB/T 3452.1-2005	O形圈	Ring seal	1		√
19-2	15.5×1.8-G-N-GB/T 3452.1-2005	O形圈	Ring seal	2		√
19-3	Q1840830	六角法兰面螺栓	Hex flange bolt	1	Aotecar	√
19-3	Q1840625	六角法兰面螺栓	Hex flange bolt	1	Jianshe	
20	L8108302	单管夹片1	Mono tube clip I	1		√
21	Q151C1025	六角头螺栓	Hex bolt	3		√
22	L8108301	管夹	Tube clip	1		√
23	L8103140	压缩机卸压阀	Compressor safety valve	1	Jianshe	
23	LBA8103140B1	压缩机卸压阀	Compressor safety valve	1	Aotecar	√
24	L8403106	塑料卡扣	Plastic clip	1		√

7.04 蒸发器　A/C evaporator





7.04 蒸发器　A/C evaporator


P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	L8106300	蒸发器芯总成	Evaporator core	1		√
2	L8121010	新风进风罩带滤网总成	Air changer cover with filter	1		√
2-1	L8121013	新风进风罩滤网	Air changer filter	1		√
2-2	L8121011	新风进风罩	Air changer cover	1		√
3	Q33006	全金属六角法兰面锁紧螺母	Nut	2		√
4	Q40206	大垫圈	Washer	2		√
5	L8121017	新风进风罩外板	Air changer cover panel	1		√
6	L8121016	新风门橡胶边	Seal,Air changer valve	1		
7	Q2214825	十字槽自攻螺钉带垫片组合	Screw	1		√
8	L8121014	新风门组件	Air changer valve frame	1		
8-1	L8121015	新风门	Air changer valve	1		
9	L8107103	白齿轮	White gear	1		
10	L8107102	黑齿轮	Black gear	2		
11	LAX8100150F1	新风门控制电机总成	Air changer valve motor	1		
12	L8114200	蒸发器温度传感器	Temperature sensor,evaporator	1		√
13	L8100120	蒸发箱组件	Evaporator shell	1		√
14	L8118010	恒温调节器	Evaporator thermostat	1	hengan	√
14	L8118010C1	恒温调节器	Evaporator thermostat	1	tenglong	

15	Q67516	A型蜗杆传动式软管环箍	Hoop	1		√
16	L8108101	冷凝水滴水管	Drain pipe	1		√

7.04 蒸发器 A/C evaporator

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
17	Q32008	六角法兰面螺母	Hex flange nut	1		√
18	Q39748202	A型簧片螺母	Nut	3		√
19	Q2214819	十字槽盘头自攻螺钉和大垫圈组合件	Screw and washer	3		√
20	Q1840625	六角法兰面螺栓	Bolt	1		√
21	LAX8102100	蒸发风机总成	Evaporator blower	1	hengan	√
21	LAX8102100B1	蒸发风机总成	Evaporator blower	1	tenglong	
21-1	L3745100	空调鼓风机电机	Evaporator blower motor	1	tenglong	√
21-1	LAX3745100	空调鼓风机电机	Evaporator blower motor	1	hengan	√
21-2	L3745170	空调鼓风机调速模块	Blower adjuster	1	tenglong	√
21-2	LAX3745170	空调鼓风机调速模块	Blower adjuster	1	hengan	√
22	L8100102	塑料卡	Plastic clip	1		√
23	193-0603T2F3	内螺纹金属卡	Metal clip	1		√
24	L8100101	空调器支架	A/C bracket	1		√
25	Q2140510	十字槽盘头螺钉	Screw	1		√
	LAX8100100	车内空调器（HVAC）总成	HVAC assy.	1	hengan	√
	LAX8100100D1	车内空调器（HVAC）总成	HVAC assy.	1	tenglong	

7.05 通风管路　Air distribution






7.05 通风管路　Air distribution

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	LAX8117111	左风道1	Left ventilation 1	1		√
2	L8117113	海绵条	Sponge strip	1		
3	LAX8117112	左风道2	Left ventilation 2	1		√
4	Q2734816	十字槽大半圆头自攻螺钉	Screw	5		√
5	L5306403	海绵条	Sponge strip	1		
6	L5306405	海绵条	Sponge strip	1		
7	LAX8117121B02	右风道	Right ventilation	1		√
8	LAX8117150	中间过渡风道	Lower ventilation	1		√
9	L5306404	海绵条	Sponge strip	1		
10	L8117132	海绵条	Sponge strip	1		
11	LAX8117130	下部风道总成	Lower ventilation	1		√

7.06 暖风热交换机　Heater





7.06 暖风热交换机　Heater

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
1	335-4225F30	内六角花形大盘头螺钉	Screw	2		√
2	L8108611	密封护板	Seal plate 1	1		√
3	L8108612	护板泡沫密封垫	Sponge seal	1		√
4	L8108613	压板橡胶密封垫	Rubber seal	1		√
5	L8108614	密封压板	Seal plate 2	1		√
6	LBA8108600C1	空调热水管总成	A/C water pipe	1		√
7	Q67525	A型蜗杆传动式软管环箍	Hoop	2		√
8	L8101100	暖风水箱总成	A/C water tank	1		√
9	20×3.55-G-N-GB/T 3452.1-2005	O形圈	Ring seal	2		√

8.Other parts

8. 其他零部件　Other parts

P/N	PARTS CODE	PARTS NAME	PARTS NAME	QTY	DESCRIPTION	Supply
	GZJCY	电脑诊断仪	Computer diagnostic meter	demand		√
	B3901121A2	剪式千斤顶	Screw jack	1		√
	B3901122A2	剪式千斤顶摇把	Jack crank	1		√
	L3910100A2	灭火器总成	Fire extinguisher	1		√
	L3910200	灭火器架	Fire extinguisher bracket	1		√
