

AUXILIARY POWER OUTLETS


Component Index

- Auxiliary Power Outlet-Console
- Auxiliary Power Outlet-Front
- Auxiliary Power Outlet-Rear
- Fuse Block-Rear
- SP201

Preliminary

AUXILIARY POWER OUTLETS

Circuit Schematic

**156-0**

AUXILIARY POWER OUTLETS

Circuit Operation

Battery voltage is applied to the accessory socket through the AUX POWER 1 fuse 46 and AUX POWER 2 fuse 15.

Preliminary

AUXILIARY POWER OUTLETS

Component Location Index

(Refer to Section 201 for photographs.)

Component	Photo No.
Auxiliary Power Outlet-	
Console	At the rear of the lower console 85
Auxiliary Power Outlet-	
Front	In the center of the I/P, beside the cigar lighter 73
Auxiliary Power Outlet-	
Rear	Lower part of right D-Pillar 109
Fuse Block-Rear	Under the left rear seat 52
SP201	Near right front of lower console 80
Connector	
C307 (18-MD GRY)	Beneath rear of lower console 86
Ground	
G201	Near right front of lower console 80
G401	On lower left D-pillar 109