


Front camera for driver assist systems , (QK2)

From July 2018



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Data bus diagnostic interface, Front camera for driver assist systems, Fuse holder C, Windscreen heater for front sensors

- J533 Data bus diagnostic interface
- R242 Front camera for driver assist systems
- SC Fuse holder C
- SC39 Fuse 39 on fuse holder C
- T2fy 2-pin connector, brown
- T12a 12-pin connector, black
- T20f 20-pin connector, red
- Z113 Windscreen heater for front sensors

- 108 Earth connection 2, in front left wiring harness
- 273 Earth connection 5, in front wiring harness
- 639 Earth point, left A-pillar
- B163 Positive connection 1 (15), in interior wiring harness
- B466 Connection 2, in main wiring harness
- B467 Connection 3, in main wiring harness
- * see applicable current flow diagram for fuses in interior

- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = purple
- vi = purple
- ge = yellow
- or = orange
- rs = pink