

ELECTRICAL

Wiring Systems and Power Management - Component Locator - Passenger Compartment/Roof Component Views - Escalade, Suburban, Tahoe, Yukon

PASSENGER COMPARTMENT/ROOF COMPONENT VIEWS

OVERHEAD CONSOLE COMPONENTS




Fig. 1: Overhead Console Components

Courtesy of GENERAL MOTORS COMPANY

Items

- 1: E31L Sunshade Mirror Lamp - Left **E31L Sunshade Mirror Lamp - Left**
 2: E37EL Dome/Reading Lamps - Front Overhead Console Left **E37EL Dome/Reading Lamps - Front Overhead Console Left**
 3: S25 Garage Door Opener (UG1) **S25 Garage Door Opener (UG1)**

Items

- 4: S72 Sunroof Switch (CF5) **S72 Sunroof Switch (CF5)**
- 5: S12 Dome Lamp Switch **S12 Dome Lamp Switch**
- 6: S43 Content Theft Deterrent Sensor Disable Switch (UTT) **S43 Content Theft Deterrent Sensor Disable Switch (UTT)**
- 7: S45B Liftgate Control Switch - Interior (TB5 or TC2) **S45B Liftgate Control Switch - Interior (BT5/TC2)**
- 8: E31R Sunshade Mirror Lamp - Right **E31R Sunshade Mirror Lamp - Right**
- 9: E37ER Dome/Reading Lamps - Front Overhead Console Right **E37ER Dome/Reading Lamps - Front Overhead Console Right**
- 10: E38 Flood Lamp - Center Console **E38 Flood Lamp - Center Console**
- 11: P14 Passenger Air Bag Disabled Indicator **P14 Passenger Air Bag Disabled Indicator**
- 12: A10 Inside Rearview Mirror **A10 Inside Rearview Mirror**
- 13: S51 Telematics Button Assembly (UE1)
- 14: B174W Frontview Camera - Windshield (UFL, UHX, or UGN) **B174W Frontview Camera - Windshield (UFL)** **B174W Frontview Camera - Windshield (UHX)** **B174W Frontview Camera - Windshield (UVH)**

HEADLINER COMPONENTS




Fig. 2: Headliner Components

Courtesy of GENERAL MOTORS COMPANY

Items

- 1: P22A Video Display - 2nd Row (U42) **P22A Video Display - 2nd Row X1 (U42)** **P22A Video Display - 2nd Row X2 (U42)**
 2: E37H Dome/Reading Lamps - Left Roof Rail (U42) **E37H Dome/Reading Lamps - Left Roof Rail (U42)**
 3: E37J Dome/Reading Lamps - Right Roof Rail (U42) **E37J Dome/Reading Lamps - Right Roof Rail (U42)**

Items

- 4: P22B Video Display - 3rd Row (DNU) **P22B Video Display - 3rd Row**
- 5: B77RF Radio Volume Compensator Interior Noise Microphone - Right Front (NKC) **B77RF Radio Volume Compensator Interior Noise Microphone - Right Front (NKC)**
- 6: E37C Dome/Reading Lamps - 3rd Row **E37C Dome/Reading Lamps - 3rd Row (-DNU)**
- 7: B77R Radio Volume Compensator Interior Noise Microphone - Rear (NKC) **B77R Radio Volume Compensator Interior Noise Microphone - Rear (NKC)**
- 8: E37B Dome/Reading Lamps - 2nd Row **E37B Dome/Reading Lamps - 2nd Row (-U42)**
- 9: A34 HVAC Controls - Auxiliary **A34 HVAC Controls - Auxiliary (-AZ3)**
- 10: B77RF Radio Volume Compensator Interior Noise Microphone - Right Front (NKC) **B77RF Radio Volume Compensator Interior Noise Microphone - Right Front (NKC)**
- 11: B24 Cellular Phone Microphone **B24 Cellular Phone Microphone**
- 12: B77LF Radio Volume Compensator Interior Noise Microphone - Left Front (NKC) **B77LF Radio Volume Compensator Interior Noise Microphone - Left Front (NKC)**

LEFT FRONT OF PASSENGER COMPARTMENT VIEWS (Z75)




Fig. 3: Left Front of Passenger Compartment Views (Z75)

Courtesy of GENERAL MOTORS COMPANY

Items

- 1: B63LR Side Impact Sensor - Left Rear **B63LR Side Impact Sensor - Left Rear**
- 2: F112D Seat Belt Retractor Pretensioner - Driver **F112D Seat Belt Retractor Pretensioner - Driver**
- 3: M101L Seat Belt Retractor Motor Module - Left (AX7) **M101L Seat Belt Retractor Motor Module - Left (AX7)**
- 4: E8A Door Sill Plate Lamp - Driver (Z75) **E8A Door Sill Plate Lamp - Driver (Z75)**
- 5: B80 Park Brake Switch (without J71) **B80 Park Brake Switch (-J71)**
- 6: X51L Fuse Block - Instrument Panel Left **X51L Fuse Block - Instrument Panel Left X1 X51L Fuse Block - Instrument Panel Left X2 X51L Fuse Block - Instrument Panel Left X3**
- 7: K157 Video Processing Control Module (UVH) **K157 Video Processing Control Module X1 (UVH) K157 Video Processing Control Module X2 (UVH)**

Items

8: K9 Body Control Module [K9 Body Control Module X1](#) [K9 Body Control Module X2](#) [K9 Body Control Module X3](#) [K9 Body Control Module X4](#) [K9 Body Control Module X5](#) [K9 Body Control Module X6](#) [K9 Body Control Module X7](#)

9: X85 Steering Wheel Air Bag Coil [X85 Steering Wheel Air Bag Coil X1](#) [X85 Steering Wheel Air Bag Coil X2 \(Z75\)](#)

10: K36 Inflatable Restraint Sensing and Diagnostic Module [K36 Inflatable Restraint Sensing and Diagnostic Module X1](#) [K36 Inflatable Restraint Sensing and Diagnostic Module X2](#)

LEFT REAR OF PASSENGER COMPARTMENT VIEWS (Z75)




Fig. 4: Left Rear of Passenger Compartment Views (Z75)

Courtesy of GENERAL MOTORS COMPANY

Items

Items

- 1: B63LR Side Impact Sensor - Left Rear **B63LR Side Impact Sensor - Left Rear**
2: E8Q Door Sill Plate Lamp - Left Rear (Z75) **E8Q Door Sill Plate Lamp - Left Rear (Z75)**


PASSENGER SEAT COMPONENTS VIEW

Fig. 5: Passenger Seat Components View

Courtesy of GENERAL MOTORS COMPANY

Items

- 1: K53P Seat Blower Assembly - Passenger Back (KB6) **K53P Seat Blower Assembly - Passenger Back (KB6)**
- 2: M56P Seat Recline Motor - Passenger **M56P Seat Recline Motor - Passenger**
- 3: E14C Seat Heating Element - Passenger Back (KA1 or KB6) **E14C Seat Heating Element - Passenger Back (KA1/KB6)**
- 4: F106P Seat Side Air Bag - Passenger **F106P Seat Side Air Bag - Passenger**
- 5: M52P Seat Lumbar Support Horizontal Motor - Passenger (without Y91 or Z75) **M52P Seat Lumbar Support Horizontal Motor - Passenger**
- 6: A14P Seat Lumbar Support Pump - Passenger (Y91 or Z75 without ULT) **A14P Seat Lumbar Support Pump - Passenger (Y91/Z75-ULT)**

PASSENGER SEAT CUSHION COMPONENTS (WITHOUT ULT)




Fig. 6: Passenger Seat Cushion Components (without ULT)

Courtesy of GENERAL MOTORS COMPANY

Items

- 1: K55P Seat Blower Assembly - Passenger Cushion (KB6) [K55P Seat Blower Assembly - Passenger Cushion \(KB6\)](#)
- 2: E1B Accent Lamp - Passenger Seat (AN3 or A95) [E1B Accent Lamp - Passenger Seat \(A95/AN3\)](#)
- 3: M55P Seat Rear Vertical Motor - Passenger [M55P Seat Rear Vertical Motor - Passenger](#)

Items

- 4: K85 Passenger Presence Module **K85 Passenger Presence Module**
- 5: M50P Seat Front Vertical Motor - Passenger **M50P Seat Front Vertical Motor - Passenger**
- 6: M51P Seat Horizontal Motor - Passenger **M51P Seat Horizontal Motor - Passenger**
- 7: B88P Seat Belt Switch - Passenger **B88P Seat Belt Switch - Passenger**
- 8: K29 Seat Heating Control Module (KA1) **K29 Seat Heating Control Module X1 (KA1)**
- 9: E14D Seat Heating Element - Passenger Cushion (KA1 or KB6) **E14D Seat Heating Element - Passenger Cushion (KA1/KB6)**
- 10: S64P Seat Adjuster Switch - Passenger **S64P Seat Adjuster Switch - Passenger X1 (-ULT)** **S64P Seat Adjuster Switch - Passenger X2 (-ULT)**
- 11: F113P Seat Belt Anchor Pretensioner - Passenger **F113P Seat Belt Anchor Pretensioner - Passenger**

PASSENGER SEAT CUSHION COMPONENTS (ULT)




Fig. 7: Passenger Seat Cushion Components (ULT)

Courtesy of GENERAL MOTORS COMPANY

Items

1: G31P Seat Lumbar/Bolster Pump - Passenger (ULT) [G31P Seat Lumbar/Bolster Pump - Passenger \(ULT\)](#)

2: K85 Passenger Presence Module [K85 Passenger Presence Module](#)

Items

- 3: K40P Seat Memory Control Module - Passenger (AG2 or ULT) **K40P Seat Memory Control Module - Passenger X1 (AG2/ULT) K40P Seat Memory Control Module - Passenger X2 (AG2/ULT) K40P Seat Memory Control Module - Passenger X3 (AG2/ULT)**
- 4: M55P Seat Rear Vertical Motor - Passenger **M55P Seat Rear Vertical Motor - Passenger**
- 5: M51P Seat Horizontal Motor - Passenger **M51P Seat Horizontal Motor - Passenger**
- 6: M55P Seat Rear Vertical Motor - Passenger **M55P Seat Rear Vertical Motor - Passenger**
- 7: E1B Accent Lamp - Passenger Seat (AN3 or A95) **E1B Accent Lamp - Passenger Seat (A95/AN3)**
- 8: K55P Seat Blower Assembly - Passenger Cushion (KB6) **K55P Seat Blower Assembly - Passenger Cushion (KB6)**
- 9: K134P Seat Bolster Memory Control Module - Passenger (ULT) **K134P Seat Bolster Memory Control Module - Passenger**

DRIVER SEAT BACK COMPONENTS




Fig. 8: Driver Seat Back Components

Courtesy of GENERAL MOTORS COMPANY

Items

- 1: F106DA Seat Side Air Bag - Driver Inboard (AYQ) **F106DA Seat Side Air Bag - Driver Inboard (-ULT) F106DA Seat Side Air Bag - Driver Inboard (ULT)**
- 2: K53D Seat Blower Assembly - Driver Back (KB6) **K53D Seat Blower Assembly - Driver Back (KB6)**

cardiagn.com

Items

- 3: A14D Seat Lumbar Support Pump - Driver (A45, with Y91 or Z75 without ULT) **A14D Seat Lumbar Support Pump - Driver (A45+Y91/Z75-ULT)**
- 4: M52D Seat Lumbar Support Horizontal Motor - Driver (without Y91 or Z75) **M52D Seat Lumbar Support Horizontal Motor - Driver**
- 5: F106D Seat Side Air Bag - Driver **F106D Seat Side Air Bag - Driver**
- 6: E14A Seat Heating Element - Driver Back (KA1 or KB6) **E14A Seat Heating Element - Driver Back (KA1/KB6)**
- 7: M56D Seat Recline Motor - Driver **M56D Seat Recline Motor - Driver**

DRIVER SEAT CUSHION COMPONENTS (WITHOUT ULT)




Fig. 9: Driver Seat Cushion Components (without ULT)

Courtesy of GENERAL MOTORS COMPANY

Items

1: K40D Seat Memory Control Module - Driver (A45 or ULT) K40D Seat Memory Control Module - Driver X1 (A45/ULT) K40D Seat Memory Control Module - Driver X2 (A45/ULT) K40D Seat Memory Control Module - Driver X3 (A45/ULT) K40D Seat Memory Control Module - Driver X4 ((J45+A45)/ULT) K40D Seat Memory Control Module - Driver X5 (A45/ULT)

Items

- 2: M55D Seat Rear Vertical Motor - Driver **M55D Seat Rear Vertical Motor - Driver**
- 3: E1A Accent Lamp - Driver Seat (AN3 or A95) **E1A Accent Lamp - Driver Seat (A95/AN3)**
- 4: F113D Seat Belt Anchor Pretensioner - Driver **F113D Seat Belt Anchor Pretensioner - Driver**
- 5: P45LR Seat Haptic Movement Motor - Driver Left Rear (UEU, UFL UHX, or UGN) **P45LR Seat Haptic Movement Motor - Driver Left Rear (UFL/UHX/UGN)**
- 6: S64D Seat Adjuster Switch - Driver **S64D Seat Adjuster Switch - Driver (ULT)** **S64D Seat Adjuster Switch - Driver X1 (-ULT)**
- 7: E14B Seat Heating Element - Driver Cushion (KA1 or KB6) **E14B Seat Heating Element - Driver Cushion (KA1/KB6)**
- 8: P45RR Seat Haptic Movement Motor - Driver Right Rear (UEU, UFL UHX, or UGN) **P45RR Seat Haptic Movement Motor - Driver Right Rear (UFL/UHX/UGN)**
- 9: B88D Seat Belt Switch - Driver **B88D Seat Belt Switch - Driver**
- 10: K55D Seat Blower Assembly - Driver Cushion (KB6) **K55D Seat Blower Assembly - Driver Cushion (KB6)**
- 11: M51D Seat Horizontal Motor - Driver **M51D Seat Horizontal Motor - Driver**
- 12: B62D Seat Position Sensor - Driver **B62D Seat Position Sensor - Driver**
- 13: M50D Seat Front Vertical Motor - Driver **M50D Seat Front Vertical Motor - Driver**

DRIVER SEAT CUSHION COMPONENTS (ULT)




Fig. 10: Driver Seat Cushion Components (ULT)

Courtesy of GENERAL MOTORS COMPANY

Items

- 1: G31D Seat Lumbar/Bolster Pump - Driver (ULT) [G31D Seat Lumbar/Bolster Pump - Driver \(ULT\)](#)
- 2: M55D Seat Rear Vertical Motor - Driver [M55D Seat Rear Vertical Motor - Driver](#)
- 3: K134D Seat Bolster Memory Control Module - Driver (ULT) [K134D Seat Bolster Memory Control Module - Driver](#)

cardiagn.com

Items

- 4: F113D Seat Belt Anchor Pretensioner - Driver **F113D Seat Belt Anchor Pretensioner - Driver**
- 5: P45LR Seat Haptic Movement Motor - Driver Left Rear (UEU, UFL UHX, or UGN) **P45LR Seat Haptic Movement Motor - Driver Left Rear (UFL/UHX/UGN)**
- 6: S64D Seat Adjuster Switch - Driver **S64D Seat Adjuster Switch - Driver (ULT)** **S64D Seat Adjuster Switch - Driver X1 (-ULT)**
- 7: E14B Seat Heating Element - Driver Cushion (KA1 or KB6) **E14B Seat Heating Element - Driver Cushion (KA1/KB6)**
- 8: P45RR Seat Haptic Movement Motor - Driver Right Rear (UEU, UFL UHX, or UGN) **P45RR Seat Haptic Movement Motor - Driver Right Rear (UFL/UHX/UGN)**
- 9: B88D Seat Belt Switch - Driver **B88D Seat Belt Switch - Driver**
- 10: E1A Accent Lamp - Driver Seat (AN3 or A95) **E1A Accent Lamp - Driver Seat (A95/AN3)**
- 11: K55D Seat Blower Assembly - Driver Cushion (KB6) **K55D Seat Blower Assembly - Driver Cushion (KB6)**
- 12: M51D Seat Horizontal Motor - Driver **M51D Seat Horizontal Motor - Driver**
- 13: B62D Seat Position Sensor - Driver **B62D Seat Position Sensor - Driver**
- 14: K40D Seat Memory Control Module - Driver (A45 or ULT) **K40D Seat Memory Control Module - Driver X1 (A45/ULT)** **K40D Seat Memory Control Module - Driver X2 (A45/ULT)** **K40D Seat Memory Control Module - Driver X3 (A45/ULT)** **K40D Seat Memory Control Module - Driver X4 ((J45+A45)/ULT)** **K40D Seat Memory Control Module - Driver X5 (A45/ULT)**

CENTER SEAT COMPONENTS (AZ3)




Fig. 11: Center Seat Components (AZ3)

Courtesy of GENERAL MOTORS COMPANY

Items

1: X80D Accessory Power Receptacle - Center Console Compartment X80D Accessory Power Receptacle - Center Console Compartment (AZ3) X80D Accessory Power Receptacle - Center Console Compartment (D07)

Items

- 2: X83 Auxiliary Audio Input X83 Auxiliary Audio Input (except IO3) X83 Auxiliary Audio Input X1 X83 Auxiliary Audio Input X83 Auxiliary Audio Input X2 (D07)
- 3: X80E Accessory Power Receptacle - Center Seat (AZ3) X80E Accessory Power Receptacle - Center Seat (AZ3)


2ND ROW LEFT BUCKET SEAT COMPONENTS (ATN)

Fig. 12: 2nd Row Left Bucket Seat Components (ATN)

Courtesy of GENERAL MOTORS COMPANY

Items

- 1: M107LR Folding Seat Motor - 2nd Row Left (ATN or ATT) **M107LR Folding Seat Motor - 2nd Row Left**
- 2: B124LR (ATN or ATT) **B88LR Seat Belt Switch - Left Rear**
- 3: E14F Seat Heating Element - Left Rear Cushion (KA6) **E14F Seat Heating Element - Left Rear Cushion**
- 4: K29R Seat Heating Control Module - Rear (KA6) **K29R Seat Heating Control Module - Rear X1**

2ND ROW RIGHT BUCKET SEAT COMPONENTS (ATN)




Fig. 13: 2nd Row Right Bucket Seat Components (ATN)

Courtesy of GENERAL MOTORS COMPANY

Items

- 1: B124RR (ATN or ATT) **B88RR Seat Belt Switch - Right Rear**
- 2: M107RR Folding Seat Motor - 2nd Row Right (ATN or ATT) **M107RR Folding Seat Motor - 2nd Row Right**
- 3: E14H Seat Heating Element - Right Rear Cushion (KA6) **E14H Seat Heating Element - Right Rear Cushion**

cardiagn.com

2ND ROW SEAT CUSHIONS COMPONENTS (ATT)




Fig. 14: 2nd Row Seat Cushions Components (ATT)

Courtesy of GENERAL MOTORS COMPANY

Items

- | | |
|---|---|
| 1: E14H Seat Heating Element - Right Rear Cushion (KA6) | <u>E14H Seat Heating Element - Right Rear Cushion</u> |
| 2: E14F Seat Heating Element - Left Rear Cushion (KA6) | <u>E14F Seat Heating Element - Left Rear Cushion</u> |

2ND ROW BENCH SEAT CUSHIONS BOTTOM COMPONENTS (ATT)




Fig. 15: 2nd Row Bench Seat Cushions Bottom Components (ATT)

Courtesy of GENERAL MOTORS COMPANY

Items

- 1: K29R Seat Heating Control Module - Rear (KA6) [K29R Seat Heating Control Module - Rear X1](#) [K29R Seat Heating Control Module - Rear X2](#)
- 2: M107LR Folding Seat Motor - 2nd Row Left (ATN or ATT) [M107LR Folding Seat Motor - 2nd Row Left](#)
- 3: M107RR Folding Seat Motor - 2nd Row Right (ATN or ATT) [M107RR Folding Seat Motor - 2nd Row Right](#)

3RD ROW SEAT BACK COMPONENTS (AS8)




Fig. 16: 3rd Row Seat Back Components (AS8)

Courtesy of GENERAL MOTORS COMPANY

Items

- 1: M109LR Folding Seat Back Unlatch Motor - 3rd Row Left (AS8) [M109LR Folding Seat Back Unlatch Motor - 3rd Row Left](#)
- 2: M109RR Folding Seat Back Unlatch Motor - 3rd Row Right (AS8) [M109RR Folding Seat Back Unlatch Motor - 3rd Row Right](#)
- 3: M108RR Folding Seat Motor - 3rd Row Right (AS8) [M108RR Folding Seat Motor - 3rd Row Right](#)
- 4: M108LR Folding Seat Motor - 3rd Row Left (AS8) [M108LR Folding Seat Motor - 3rd Row Left](#)
- 5: K169 Folding Seat Control Module - 3rd Row (AS8) [K169 Folding Seat Control Module - 3rd Row X1](#) [K169 Folding Seat Control Module - 3rd Row X2](#)

FRONT CENTER OF THE PASSENGER COMPARTMENT COMPONENTS




Fig. 17: Front Center of The Passenger Compartment Components

Courtesy of GENERAL MOTORS COMPANY

Items

- 1: P19AC Speaker - Subwoofer (UQA, UQH or UQS) **P19AC Speaker - Subwoofer (UQA/UQH/UQS)**
2: B119 Multi-axis Acceleration Sensor (UGN) **B119 Multi-axis Acceleration Sensor (UGN)**