


2004 ELECTRICAL

Relay & Control Unit Locations - TSX

RELAY & CONTROL UNIT LOCATIONS


ENGINE COMPARTMENT



GC1820775

Fig. 1: Locating Relays & Control Units (Engine Compartment)

DASHBOARD




G01820776

Fig. 2: Locating Relays & Control Units (Dashboard - 1 Of 3)


IMMOBILIZER CONTROL UNIT-RECEIVER

AUDIO-HVAC-DISPLAY MODULE
Consists of the audio system, the
climate control system, and the
navigation system (if equipped)



G01820777

Fig. 3: Locating Relays & Control Units (Dashboard - 2 Of 3)




G01820778

Fig. 4: Locating Relays & Control Units (Dashboard - 3 Of 3)

ROOF & TRUNK

2004 Acura TSX

2004 ELECTRICAL Relay & Control Unit Locations - TSX




G01820779

Fig. 5: Locating Relays & Control Units (Roof & Trunk)

DOOR & SEAT

Driver's Door




DOOR MULTIPLEX CONTROL UNIT
(Built into the power window master switch)

G01820780

Fig. 6: Locating Relays & Control Units (Driver's Door)

Front Passenger's Seat



G01820781

Fig. 7: Locating Relays & Control Units (Front Passenger's Seat)