


Electromechanical steering

From July 2018



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Power steering control unit, Onboard supply control unit,
Data bus diagnostic interface, Fuse holder A

- G85 Steering angle sender
- G269 Steering moment sender
- J500 Power steering control unit
- J519 Onboard supply control unit
- J533 Data bus diagnostic interface
- SA Fuse holder A
- SA6 Fuse 6 on fuse holder A
- T2ee 2-pin connector, black
- T3be 3-pin connector, black
- T20f 20-pin connector, red
- T73a 73-pin connector, black
- V187 Electromechanical power steering motor

- 810 Earth point on central tube for dash panel, centre left
- 811 Earth point on central tube for dash panel, centre right
- B383 Connection 1 (powertrain CAN bus, high), in main wiring harness
- B390 Connection 1 (powertrain CAN bus, low), in main wiring harness
- B472 Connection 8, in main wiring harness

- * For left-hand drive models
- *2 see applicable current flow diagram for fuses in engine compartment
- *3 For right-hand drive models