


## Cigar Lighter Housing Replacement


### Removal Procedure

**Warning:** Refer to [Battery Disconnect Warning](#) in the Preface section.



1. Disconnect the negative battery cable.
2. Remove the cigar lighter from the cigar lighter housing.
3. Remove the floor console. Refer to [Front Floor Console Replacement](#).
4. Remove the cigar lighter housing from the instrument panel.
5. Disconnect the cigar lighter electrical connector.

### Installation Procedure



1. Connect the cigar lighter electrical connector.
2. Install the cigar lighter housing in the instrument panel.
3. Install the floor console. Refer to [Front Floor Console Replacement](#).
4. Install the cigar lighter in the cigar lighter housing.
5. Connect the negative battery cable.