

CABIN AIR FILTERS

Passenger Compartment Air Filter - HHR

REMOVAL & INSTALLATION


NOTE: Manufacturer's terminology for this filter is passenger compartment air filter.

NOTE: Numbers in parenthesis refer to numbers in figures.

CABIN AIR FILTER

Removal & Installation


1. Squeeze the sides of the instrument panel compartment (glove box) and pull the compartment out of the instrument panel opening past the stops. Pull outward on the compartment assembly releasing the 3 hinge points from the instrument panel assembly. See **Fig. 1**.



G00435490

Fig. 1: Removing Instrument Panel Compartment (Glove Box)
Courtesy of GENERAL MOTORS CORP.

2. Remove the passenger compartment air filter cover and air filter. See **Fig. 2**.
3. To install, reverse removal procedure.



G00435491

Fig. 2: Locating Passenger Compartment Air Filter And Cover
Courtesy of GENERAL MOTORS CORP.