

CHERY A19 Service Manual 2014

01

FOREWORD

This manual contains on-vehicle diagnosis and service procedures for Chery A19.

It is very important to read and be familiar with this manual thoroughly for proper repair and maintenance. This manual should be kept in a handy place for quick and easy reference.

The contents in this manual, including all illustrations and specifications, are current at the time of printing. As modifications affecting repair and maintenance occur, relevant information supplementary to this volume will be made available at Chery dealers.

Chery Automobile Co., Ltd. reserves all rights. Specifications and contents in this manual are subject to change without notification, and the Chery Automobile Co., Ltd. takes no legal obligations and responsibilities.

All rights reserved. Any unit or individual shall not reproduce or copy this manual in any form or by any means, or transmit it on the network by any form for any purpose without written permission of Chery Automobile Co., Ltd.

This manual only applies to the model listed below:

A19 1.5 L MT

CAUTION:

This manual is only for specialized technicians. If non-specialized or uncertified individuals perform repairs or maintenance privately only referring to this manual or without proper equipment and tools, it may cause damage to the customer's vehicle and injury to you and other persons nearby.

In order to prevent dangerous operation and damage to the vehicle, be sure to follow the instructions shown below:

- The contents in this manual must be read thoroughly. Have a good understanding of all the contents written in the PRECAUTION of "INTRODUCTION" section.
- Before performing the repair procedures, be sure to put on protective tools properly to avoid personal injury.
- When performing the repair procedures, be sure to use specified and recommended tools to prevent damage to the customer's vehicle. Be sure to confirm the safety of the technicians before operating to avoid personal injury.
- If a part needs to be replaced, use Chery genuine part with the same part number. Do not use any inferior quality part.
- Observe the "WARNING" and "CAUTION" in this manual carefully in order to reduce the risk of personal injury and vehicle damage due to improper operation during service and maintenance.

FOREWORD	01
INTRODUCTION	02
PREPARATION	03
SERVICE SPECIFICATIONS	04
MAINTENANCE	05
SQR477F ENGINE MANAGEMENT SYSTEM	06
SQR477F ENGINE MECHANICAL	07
SQR477F FUEL SUPPLY SYSTEM	08
SQR477F EMISSION CONTROL SYSTEM	09
SQR477F INTAKE SYSTEM	10
SQR477F EXHAUST SYSTEM	11
SQR477F COOLING SYSTEM	12
SQR477F LUBRICATION SYSTEM	13
SQR477F IGNITION SYSTEM	14
SQR477F STARTING SYSTEM	15
SQR477F CHARGING SYSTEM	16
QR515MHA TRANSMISSION	17
CLUTCH	18
DRIVE SHAFT	19
DIFFERENTIAL	20
AXLE	21
SUSPENSION	22
TIRE AND WHEEL	23
BRAKE CONTROL SYSTEM	24
BRAKE	25
PARKING BRAKE	26
STEERING COLUMN	27

HYDRAULIC ASSIST STEERING	28
AIR CONDITIONING	29
SUPPLEMENTAL RESTRAINT SYSTEM	30
SEAT BELT	31
ENGINE IMMOBILIZER	32
LIGHTING SYSTEM	33
WIPER AND WASHER	34
DOOR LOCK	35
INSTRUMENT CLUSTER	36
AUDIO SYSTEM	37
REVERSING RADAR SYSTEM	38
HORN	39
OTHER SYSTEM	40
WINDSHIELD/WINDOW GLASS	41
REAR VIEW MIRROR	42
INSTRUMENT PANEL	43
SEAT	44
ENGINE HOOD/DOOR	45
EXTERIOR	46
INTERIOR	47
BODY DIMENSIONS	48
WIRE HARNESS	49

