


MULTI-PLEXED INDICATOR CONTROL UNIT

Component Index

- Dash Fuse Box
- Data Link Connector (DLC) C-39 (16-BLK)
- Lamp Switch
- Meter Assembly
- Multi-plexed Indicator Control Unit
- Powertrain Control Module (PCM)
- Taillamp Relay


MULTI-PLEXED INDICATOR CONTROL UNIT

Circuit Schematic




MULTI-PLEXED INDICATOR CONTROL UNIT

Circuit Schematic



MULTI-PLEXED INDICATOR CONTROL UNIT

Circuit Schematic



MULTI-PLEXED INDICATOR CONTROL UNIT

Component Location Index

(Refer to Section 201 for photographs.)

Component	Photo No.
Dash Fuse Box	Behind left I/P side trim panel 42
Data Link Connector (DLC)	
C-39 (16-BLK)	Below left side of I/P, near engine hood release 45
Lamp Switch	In the combination switch
Meter Assembly	Left side of I/P 55
Multi-plexed Indicator	
Control Unit	Under rear of console 72
Powertrain Control Module	
(PCM)	Left side of engine compartment 26
Taillamp Relay	In the dash fuse box 44
Connector	
H-4 (52-GRY)	Left side of engine compartment 31
H-8 (20-BLU)	Behind right kick panel 61
H-15 (22-WHT)	Behind left kick panel 47
H-16 (16-WHT)	Behind left kick panel 46
H-17 (12-WHT)	Behind right kick panel 61
H-18 (22-BLK)	Behind right kick panel 61
I-22 (14-GRN)	Top of meter assembly 54
I-23 (16-GRN)	Top of meter assembly 54
I-24 (30-GRN)	Top of meter assembly 54
I-35 (13-BLK)	Under left side of I/P 49
Ground	
B-9	Under center console 71