


CIGARETTE LIGHTER

Component Index

[Dash Fuse Box](#)

CIGARETTE LIGHTER

Circuit Schematic



CIGARETTE LIGHTER

Component Location Index

(Refer to Section 201 for photographs.)

Component	Photo No.
Dash Fuse Box Behind left dash side trim panel	36
Connector	
H-14 (22-BLU) Behind left kick panel	42
Ground	
C-46 Behind left kick panel	40

Circuit Operation

With the starter switch in ACC or ON, battery voltage is applied to CIGAR LIGHTER fuse CB-20 and to the cigarette lighter. When the cigarette lighter is depressed, the cigarette lighter element completes the circuit to ground. When the element becomes sufficiently heated, it is spring-released and the circuit opens.