

GENERAL INFORMATION

HOW TO USE THIS MANUAL	GI- 1	ARRANGEMENT OF PARTS	GI- 5
RANGE OF TOPICS	GI- 1	CLEANING OF PARTS	GI- 5
SERVICING PROCEDURE	GI- 1	REASSEMBLY	GI- 5
SYMBOLS	GI- 3	ADJUSTMENT	GI- 6
ADVISORY MESSAGES	GI- 3	RUBBER PARTS AND TUBING	GI- 6
TEXT SEQUENCE	GI- 3	HOSE CLAMPS	GI- 6
UNITS	GI- 4	TORQUE FORMULAS	GI- 6
FUNDAMENTAL PROCEDURES	GI- 5	WISE	GI- 6
PREPARATION OF TOOLS AND		ELECTRICAL SYSTEM	GI- 7
MEASURING EQUIPMENT	GI- 5	CONNECTORS	GI- 7
SPECIAL SERVICE TOOLS	GI- 5	NEW STANDARDS	GI- 8
DISASSEMBLY	GI- 5	ABBREVIATIONS	GI-10
INSPECTION DURING REMOVAL,			
DISASSEMBLY	GI- 5		

HOW TO USE THIS MANUAL


RANGE OF TOPICS

- This manual contains the procedures for performing all of the required service operations. The procedures are divided into the following five basic operations.
 - (1) Removal/Installation
 - (2) Disassembly/Assembly
 - (3) Replacement
 - (4) Inspection
 - (5) Adjustment
- Simple operations which can be performed easily just by looking at the vehicle, such as removal/installation of parts, jacking, vehicle lift, cleaning of parts, and visual inspection, have been omitted.

SERVICING PROCEDURE

Inspection, Adjustment

- The procedures for inspections and adjustments are divided into steps. Important points in regard to the location and contents of the procedures are explained in detail and are shown in the illustrations.



Caution

- Connect the gauge set from under the vehicle to prevent contact with the drive belt and the cooling fan.

HOW TO USE THIS MANUAL

Repair procedure

1. Most repair operations begin with an overview illustration. It identifies the components, shows how the parts fit together, and describes visual part inspection. However, only the removal/installation procedures which need to be performed methodically have written instructions.
2. Expendable parts, tightening torques, and symbols for oil, grease, and sealant are shown in the overview illustration. In addition, symbols indicating parts which require the use of special service tools for removal/installation are also shown.
3. The procedures are numbered and the part that is the main point of that procedure is shown in the illustration with the corresponding number. Occasionally, there are important points or information concerning a procedure. Refer to this information when servicing the related part.

