








SPECIAL TOOLS



Front Differential

Mazda Tool Number






Ford Tool Number

49 M005 581	Mounting Bracket, Engine/Differential 205-329 (15-105A)	
49 S120 710	Universal Flange Holding Wrench 205-072 (15-030A)	
49 H027 002	Remover, Bearing/Gear 205-310 (15-091)	
49 0727 570	Holding Fixture, Dial Indicator Gauge 205-044 (15-008)	
49 8531 565	Gauge, Master Pinion 205-059 (15-020)	
49 0305 555	Preload Sleeve 205-060 (15-023)	
49 0259 720	Universal Flange Holding Wrench 205-072 (15-030A)	

SPECIAL TOOLS

49 0839 425C	Remover, Bearing/Gear 205-310 (15-091)	
	Thurst Pad for 205-071 307-115 (17-019)	
	Remover, Mainshaft Needle Bearing Sleeve 308-191 (16-056)	
49 G030 338	Installer, Front Differential Bearing Cup 204-281 (14-056)	Graphic not available
49 F027 004	Commercially available	Not applicable
49 F027 005	Installer, Front Differential Oil Seal 204-282 (14-057)	Graphic not available

SPECIAL TOOLS

49 U027 003	Installer, Drive Pinion Bearing 205-082 (15-037)	
	Installer, Drive Pinion Bearing 205-068 (15-042)	
49 G030 795	Installer, Front Differential Oil Seal 204-283 (14-058)	Graphic not available
49 0350 555	Gauge, Master Pinion 205-059 (15-020)	
49 0350 565	Gauge, Master Pinion 205-059 (15-020)	
49 0350 567	Gauge, Master Pinion 205-059 (15-020)	
49 0350 568	Gauge, Master Pinion 205-059 (15-020)	