

PREPARATION


SQR484F ENGINE MANAGEMENT SYSTEM	03-3	BRAKE	03-30
Tools	03-3	Tools	03-30
SQR484F ENGINE MECHANICAL	03-5	PARKING BRAKE	03-31
Tools	03-5	Tools	03-31
SQR484F FUEL SUPPLY SYSTEM	03-12	STEERING COLUMN	03-32
Tools	03-12	Tools	03-32
SQR484F EMISSION CONTROL SYSTEM	03-13	HYDRAULIC ASSIST STEERING	03-33
Tool	03-13	Tool	03-33
SQR484F INTAKE SYSTEM	03-14	ELECTRONIC POWER STEERING	03-34
Tools	03-14	Tools	03-34
SQR484F EXHAUST SYSTEM	03-15	AIR CONDITIONING	03-35
Tools	03-15	Tools	03-35
SQR484F COOLING SYSTEM	03-16	SUPPLEMENTAL RESTRAINT SYSTEM	03-36
Tools	03-16	Tools	03-36
SQR484F LUBRICATION SYSTEM	03-17	SEAT BELT	03-37
Tools	03-17	Tool	03-37
SQR484F IGNITION SYSTEM	03-18	ENGINE IMMOBILIZER	03-38
Tool	03-18	Tools	03-38
SQR484F STARTING SYSTEM	03-19	LIGHTING SYSTEM	03-39
Tools	03-19	Tools	03-39
SQR484F CHARGING SYSTEM	03-20	WIPER AND WASHER	03-40
Tool	03-20	Tool	03-40
QR525MHE TRANSMISSION	03-21	DOOR LOCK	03-41
Tools	03-21	Tools	03-41
QR019CHB CVT	03-23	INSTRUMENT CLUSTER	03-42
Tools	03-23	Tools	03-42
CLUTCH	03-24	AUDIO SYSTEM	03-43
Tools	03-24	Tool	03-43
DIFFERENTIAL	03-25	REVERSING RADAR SYSTEM	03-44
Tools	03-25	Tool	03-44
AXLE	03-26	HORN	03-45
Tools	03-26	Tool	03-45
SUSPENSION	03-28	WINDSHIELD/WINDOW GLASS	03-46
Tools	03-28	Tools	03-46
BRAKE CONTROL SYSTEM	03-29	REAR VIEW MIRROR	03-47
Tools	03-29	Tool	03-47

INSTRUMENT PANEL	03-48	Tool	03-50
Tools	03-48	EXTERIOR	03-51
SEAT	03-49	Tool	03-51
Tool	03-49	INTERIOR	03-52
ENGINE HOOD/DOOR	03-50	Tool	03-52

SQR484F ENGINE MANAGEMENT SYSTEM




Tools

Special Tool


X-431 3G Diagnostic Tester	 RCH0000001
----------------------------	--

03

General Tools


Fuel Injector Cleaning Analyzer	 RCH0000062
Ignition Timing Light	 RCH0000016
Digital Multimeter	 RCH0000002

Cylinder Pressure Gauge



RCH0000044

Fuel Pressure Gauge



RCH0000048

Oscilloscope








RCH0000061






SQR484F ENGINE MECHANICAL

Tools


Special Tools

Crankshaft Front Oil Seal Guide Tool	 RCH0000049
Crankshaft Front Oil Seal Installer	 RCH0000067
Camshaft Oil Seal Installer	 RCH0000017
Valve Spring Compression Adapter	 RCH0000050
Valve Spring Compressor	 RCH0000028

03


Crankshaft Rear Oil Seal Installer	 RCH0000031
Valve Oil Seal Installer	 RCH0000034
Valve Oil Seal Guide Sleeve	 RCH0000035
Clutch Pressure Plate Installer	 RCH0000018
Valve Oil Seal Remover	 RCH0000037

Valve Cotter Installer




RCH0000029

Flywheel Holding Tool




RCH0000040

Oil Filter Remover




RCH0000054

Camshaft Timing Tool



RCH0000033

Crankshaft Timing Tool




RCH0000027

General Tools


03

Piston Installer




RCH0000039

Dial Indicator and Magnetic Holder




RCH0000023

Outer Diameter Micrometer




RCH0000064

Vernier Caliper




RCH0000019

Precision Ruler




RCH0000063

Feeler Gauge




RCH0000060

Cylinder Gauge




RCH0000065

Caliper Gauge




RCH0000069

Digital Multimeter



RCH0000002

Flexional Magnetic Rod




RCH0000042

Engine Hoist




RCH0000043

Engine Equalizer




RCH0000026

Transmission Carrier




RCH0000005

Fuel Pressure Gauge




RCH0000048

Cylinder Pressure Gauge



RCH0000044

Engine Service Platform



RCH0000057

03


SQR484F FUEL SUPPLY SYSTEM

Tools

Special Tool

03


Fuel Tank Pressure Cap Remover



RCH0000004


General Tools

Digital Multimeter



RCH0000002

Fuel Pressure Gauge



RCH0000048

Transmission Carrier




RCH0000005

SQR484F EMISSION CONTROL SYSTEM

Tool

General Tool

Digital Multimeter



RCH0000002

03


SQR484F INTAKE SYSTEM

Tools

Special Tool

03


X-431 3G Diagnostic Tester



RCH0000001


General Tools

Digital Multimeter



RCH0000002

Precision Ruler



RCH0000063

Feeler Gauge





RCH0000060

SQR484F EXHAUST SYSTEM

Tools

General Tools

Precision Ruler	 RCH0000063
Feeler Gauge	 RCH0000060

03


SQR484F COOLING SYSTEM

Tools

General Tools


03

Digital Multimeter




RCH0000002

Cooling System Pressure Tester



RCH0000055

Freezing Point Tester




RCH0000007

SQR484F LUBRICATION SYSTEM

Tools

Special Tools

Oil Pan Remover and Scraper	 RCH0000056
Oil Filter Remover	 RCH0000054

03

General Tool

Oil Pressure Tester	 RCH0000006
---------------------	--


SQR484F IGNITION SYSTEM

Tool

General Tool

03

Digital Multimeter




RCH0000002

SQR484F STARTING SYSTEM

Tools

Special Tool

X-431 3G Diagnostic Tester




RCH0000001

03

General Tool

Digital Multimeter



RCH0000002


SQR484F CHARGING SYSTEM

Tool

General Tool

03

Digital Multimeter







RCH0000002

QR525MHE TRANSMISSION


Tools

Special Tools

Input Shaft Oil Seal Installer	 RCH0000008
Differential Oil Seal Installer	 RCH0000009
Installer Joint	 RCH0000010
Bearing Remover	 RCH0000011
Punch	 RCH0000015

03

Puller




03

General Tools


Transmission Carrier



Engine Equalizer





Hydraulic Press



QR019CHB CVT



Tools

Special Tools

Puller	 RCH0000059
Differential Oil Seal Installer	 RCH0000009

03

General Tools

Engine Equalizer	 RCH0000026
Transmission Carrier	 RCH0000005


CLUTCH

Tools

Special Tool

03

Clutch Pressure Plate Installer



RCH0000018


General Tools

Vernier Caliper



RCH0000019

Digital Multimeter





RCH0000002

DIFFERENTIAL



Tools

Special Tools

Bearing Remover	 RCH0000011
Punch	 RCH0000015

03

General Tools

Hydraulic Press	 RCH0000012
Dial Indicator and Magnetic Holder	 RCH0000023


AXLE

Tools

Special Tool

03


Ball Pin Separator



RCH0000024

General Tools

Dial Indicator and Magnetic Holder




RCH0000023

Transmission Carrier




RCH0000005

Hydraulic Press




RCH0000012

Bearing Remover



RCH0000011

Engine Equalizer



RCH0000026

03


SUSPENSION

Tools

Special Tool

03


Spring Compressor



RCH0000021


General Tools

Transmission Carrier



RCH0000005

Engine Equalizer




RCH0000026

BRAKE CONTROL SYSTEM

Tools

Special Tool

X-431 3G Diagnostic Tester




RCH0000001

03

General Tool

Digital Multimeter



RCH0000002


BRAKE

Tools

Special Tool

03


Brake Caliper Piston Pressing Tool



RCH0000053

General Tools

Dial Indicator and Magnetic Holder




RCH0000023

Vernier Caliper



RCH0000019

Digital Multimeter




RCH0000002

PARKING BRAKE

Tools

General Tools

Digital Multimeter



RCH0000002

Vernier Caliper



RCH0000019

03


STEERING COLUMN

Tools

Special Tool

03


Steering Wheel Remover



RCH0000014

General Tool

Electric Drill




RCH0000013

HYDRAULIC ASSIST STEERING

Tool

Special Tool

Ball Pin Separator



03


ELECTRONIC POWER STEERING

Tools

Special Tools


03

Ball Pin Separator



RCH0000024


X-431 3G Diagnostic Tester



RCH0000001

General Tool

Digital Multimeter



RCH0000002

AIR CONDITIONING

Tools


General Tools

Refrigerant Recycling Machine



RCH0000046

Digital Multimeter



RCH0000002

03


SUPPLEMENTAL RESTRAINT SYSTEM

Tools

Special Tool

03


X-431 3G Diagnostic Tester



RCH0000001

General Tool

Digital Multimeter




RCH0000002

SEAT BELT

Tool

General Tool

Digital Multimeter



RCH0000002

03


ENGINE IMMOBILIZER

Tools

Special Tool

03


X-431 3G Diagnostic Tester



RCH0000001

General Tool

Digital Multimeter




RCH0000002

LIGHTING SYSTEM

Tools

Special Tool

X-431 3G Diagnostic Tester




RCH0000001

03

General Tool

Digital Multimeter



RCH0000002


WIPER AND WASHER

Tool

General Tool

03

Digital Multimeter




RCH0000002

DOOR LOCK

Tools

Special Tool

X-431 3G Diagnostic Tester




RCH0000001

03

General Tool

Digital Multimeter



RCH0000002


INSTRUMENT CLUSTER

Tools

Special Tool

03


X-431 3G Diagnostic Tester



RCH0000001

General Tool

Digital Multimeter




RCH0000002

AUDIO SYSTEM

Tool

General Tool

Digital Multimeter



RCH0000002

03


REVERSING RADAR SYSTEM

Tool

General Tool

03

Digital Multimeter




RCH0000002

HORN

Tool

General Tool

Digital Multimeter



RCH0000002

03


WINDSHIELD/WINDOW GLASS

Tools

Special Tool

03


Interior Crow Plate



RCH0000025

General Tool

Digital Multimeter




RCH0000002

REAR VIEW MIRROR

Tool

General Tool

Digital Multimeter



RCH0000002

03


INSTRUMENT PANEL

Tools


Special Tools

03

Steering Wheel Remover



Interior Crow Plate




SEAT

Tool

General Tool

Digital Multimeter



RCH0000002

03


ENGINE HOOD/DOOR

Tool

General Tool

03

Interior Crow Plate




RCH0000025

EXTERIOR

Tool

General Tool

Interior Crow Plate



RCH0000025

03


INTERIOR

Tool

General Tool

03

Interior Crow Plate



RCH0000025

