

COMPONENT AND SYSTEM INDEX

Name	Group-page	Name	Group-page
AUDIO SYSTEM.....	8F-1	FRAME AND BUMPERS	13-1
ANTENNAS	8F-4	FUEL SYSTEMS.....	14-1
RADIOS	8F-1	ACCELERATOR PEDAL AND THROTTLE CABLE ...	14-18
SPEAKERS	8F-7	FUEL DELIVERY	14-2
BATTERY/STARTER/GENERATOR SERVICE	8B-1	FUEL TANKS.....	14-15
BATTERY	8B-1	SEQUENTIAL MULTI-PORT FUEL INJECTION—	
GENERATOR.....	8B-5	GENERAL DIAGNOSIS	14-35
STARTER	8B-3	SEQUENTIAL MULTI-PORT FUEL INJECTION—	
BATTERY/STARTING/CHARGING SYSTEMS		ON-BOARD DIAGNOSTICS	14-47
DIAGNOSTICS	8A-1	SEQUENTIAL MULTI-PORT FUEL INJECTION—	
BATTERY TEST PROCEDURES ON-VEHICLE	8A-3	SERVICE PROCEDURES.....	14-55
FAULT CODES—ON BOARD DIAGNOSTICS	8A-21	SEQUENTIAL MULTI-PORT FUEL INJECTION—	
GENERAL INFORMATION	8A-1	SYSTEM OPERATION.....	14-20
GENERATOR TEST PROCEDURES ON VEHICLE ...	8A-18	SPECIFICATIONS	14-72
IGNITION OFF DRAW (IOD)	8A-9	HEATING AND AIR CONDITIONING	24-1
SPECIFICATIONS	8A-26	AUTOMATIC TEMPERATURE CONTROL (ATC)	
STARTER TEST PROCEDURES ON VEHICLE	8A-11	SELF-DIAGNOSTICS.....	24-21
BODY	23-1	COMPONENT SERVICE PROCEDURES.....	24-7
BODY COMPONENT SERVICE	23-7	GENERAL INFORMATION	24-1
BODY DIAGNOSTIC PROCEDURES	23-2	MANUAL AIR CONDITIONING SYSTEM	
GENERAL SERVICE INFORMATION.....	23-1	SELF-DIAGNOSTICS.....	24-19
PAINT	23-4	REFRIGERANT SERVICE PROCEDURES.....	24-3
WINDSHIELD	23-5	HORNS	8G-1
BRAKES.....	5-1	IGNITION SYSTEMS	8D-1
ANTI-LOCK BRAKE SYSTEM—TEVES		3.3L AND 3.5L ELECTRONIC IGNITION SYSTEM—	
MARK IV SYSTEM	5-75	SYSTEM OPERATION	8D-1
BRAKE DISC (ROTOR)	5-46	3.3L AND 3.5L ELECTRONIC IGNITION SYSTEMS—	
BRAKE SUPPORT ASSEMBLY	5-21	SERVICE PROCEDURES.....	8D-11
FRONT DISC BRAKES	5-27	3.3L ELECTRONIC IGNITION SYSTEM—DIAGNOSTIC	
GENERAL INFORMATION	5-1	PROCEDURES	8D-9
HYDRAULIC SYSTEM CONTROL VALVES	5-23	IGNITION SWITCH AND INTERLOCK.....	8D-17
KELSEY HAYES DOUBLE PIN CALIPER ASSEMBLY	5-30	SPECIFICATIONS	8D-23
MASTER CYLINDER.....	5-69	INSTRUMENT PANEL AND GAUGES.....	8E-1
PARKING BRAKES.....	5-50	INTRODUCTION.....	0-1
POWER BRAKES	5-72	LAMPS	8L-1
REAR DISC BRAKES	5-37	BULB APPLICATION.....	8L-12
REAR WHEEL DRUM BRAKES.....	5-14	EXTERIOR LAMPS.....	8L-8
SERVICE ADJUSTMENTS.....	5-4	HEADLAMP ALIGNMENT.....	8L-3
WHEEL BEARINGS.....	5-74	ILLUMINATED ENTRY SYSTEM	8L-12
WHEEL CYLINDERS.....	5-19	LAMP BULB SERVICE	8L-5
CHIME WARNING/REMINDER SYSTEM.....	8U-1	LAMP DIAGNOSIS.....	8L-1
COOLING SYSTEM	7-1	LUBRICATION AND MAINTENANCE	0-1
ACCESSORY DRIVE BELTS	7-19	CHASSIS AND BODY.....	0-15
ENGINE BLOCK HEATER.....	7-21	DRIVETRAIN.....	0-13
GENERAL INFORMATION	7-1	ENGINE	0-7
SERVICE PROCEDURES	7-8	GENERAL INFORMATION	0-1
SPECIFICATIONS	7-22	OVERHEAD CONSOLE	8C-1
ELECTRICAL	8-1	POWER LOCKS.....	8P-1
EMISSION CONTROL SYSTEMS.....	25-1	POWER MIRRORS.....	8T-1
EVAPORATIVE EMISSION CONTROLS	25-1	POWER SEATS.....	8R-1
EXHAUST EMISSION CONTROLS	25-9	POWER WINDOWS	8S-1
ENGINE	9-1	REAR WINDOW DEFOGGER	8N-1
3.3L ENGINE	9-7	RESTRAINT SYSTEMS.....	8M-1
3.5L ENGINE	9-38	SPEED CONTROL SYSTEM.....	8H-1
STANDARD SERVICE PROCEDURES.....	9-1	STEERING	19-1
EXHAUST SYSTEM AND INTAKE MANIFOLD	11-1	GENERAL INFORMATION	19-1
GENERAL INFORMATION	11-1	POWER STEERING GEAR	19-17
SERVICE PROCEDURES	11-4	POWER STEERING PUMPS.....	19-1
TORQUE SPECIFICATION.....	11-13	SAGINAW TILT STEERING COLUMN.....	19-25

SPECIFICATIONS AND TIGHTENING REFERENCE . .	19-34
SUSPENSION AND DRIVESHAFTS	2-1
DRIVESHAFTS	2-40
FRONT SUSPENSION	2-4
FRONT SUSPENSION SERVICE PROCEDURES	2-6
GENERAL INFORMATION	2-1
REAR SUSPENSION	2-52
SPECIFICATIONS	2-71
TRANSAXLE	21-1
42LE FOUR SPEED AUTOMATIC TRANSAXLE	21-1
42LE HYDRAULIC SCHEMATICS	21-98
42LE ON-BOARD DIAGNOSTICS	21-81

42LE SPECIFICATIONS	21-111
TURN SIGNALS AND HAZARD WARNING FLASHER . . .	8J-1
WHEELS—TIRES	22-1
SPECIFICATIONS	22-8
TIRE SERVICE PROCEDURES	22-1
WHEELS SERVICE PROCEDURES	22-6
WINDSHIELD WIPER AND WASHER SYSTEMS	8K-1
WIRING DIAGRAMS	8W-1
COMPONENT IDENTIFICATION	8W-12
GENERAL INFORMATION	8W-1
SPLICE LOCATIONS	8W-27
WIRING DIAGRAMS	8W-37