




Fig. 51: Ground Distribution Circuit (1 of 7)




Fig. 52: Ground Distribution Circuit (2 of 7)



Diagram illustrating the wiring connections for the instrument panel harness, showing connections to the console harness and the seat indicator harness.

Legend:

- BLK: Black
- 34: Wire number
- 16: Wire number
- J309: Instrument Panel Harness
- J300: Console Harness
- J301: Seat Indicator Harness

Connections:

- Instrument Panel Harness (J309) connects to Console Harness (J300) via wire 34 (BLK).
- Instrument Panel Harness (J309) connects to Seat Indicator Harness (J301) via wire 16 (BLK).
- Console Harness (J300) connects to Seat Indicator Harness (J301) via wire 16 (BLK).
- Seat Indicator Harness (J301) connects to the seat indicator and branch via wire 16 (BLK).
- Instrument Panel Harness (J309) connects to the instrument panel harness near the HVAC controls and HVAC control module via wire 16 (BLK).








Fig. 56: Ground Distribution Circuit (6 of 7)




Fig. 57: Ground Distribution Circuit (7 of 7)

HEADLIGHTS