



2012 Audi A5 • S5

Quick Reference Guide

Vorsprung durch Technik **Audi** 

This Quick Reference Guide provides you with a brief overview of selected procedures and functions in your vehicle. It does not replace the Owner's Manual with its important explanations and warnings.

Cockpit

1 Hood release

2 Data Link Connector for On Board Diagnostics (OBD II)

3 Adjusting the exterior mirrors

Adjust the knob:

-  Left exterior mirror
-  Heating the exterior mirror
-  Right exterior mirror

The mirror glass moves in the direction that the knob is pressed

4 Power windows

WARNING

Be careful when closing the windows. Check to see that no one is in the way, or serious personal injury could result.

5 Memory seat buttons


6 Door handle and central locking switch

-  locked
-  unlocked

7 Audi side assist

8 Light switch and Instrument lighting





9 Steering wheel position adjuster

⚠ WARNING

The column should only be adjusted when the vehicle is at a complete standstill.

10 Cruise control or adaptive cruise control

11 Turn signal and high beam lever with lane assist button

12 Multifunction steering wheel controls

13 Instruments and indicator lights

14 Windshield wiper controls and trip computer buttons

15 Ignition lock

16 Sound system/MMI display

17 **Emergency flashers**

 PASSENGER AIR BAG OFF indicator light

18 Sound system/Audi multimedia

19 Audi drive select

20 **Electronic Stability Control (ESC)**

 Sun shade

On vehicles equipped with a sound system, buttons **19** and **20** are located on the shift gate.

21 Climate control

22 Shift lever for automatic transmission

23 Electromechanical parking brake

24 START ENGINE STOP button

25 MMI control console

Convenience key

Opening and closing the vehicle

With convenience key, you can lock and unlock your vehicle without using the remote control key. You only need to carry the remote control key with you.

Unlocking the vehicle:

Grasp one of the door handles or the handle recess on the luggage compartment lid.

Locking the vehicle:

Place the selector lever in the P position. Touch the sensor **1** on one of the door handles.

Opening the rear lid:

Press the  button on the remote control key or pull the  release button inside of the driver's door.

Closing the rear lid:

Pull the rear lid down at the grip on the inside and allow it to drop gently to close it.



WARNING

When you lock your vehicle from the outside, do not leave anyone - especially children - inside the vehicle. Remember, when you lock the vehicle from the outside the windows cannot be opened from the inside.

WARNING

Always ensure that no one is within range of the rear lid when it is moving, in particular close to the hinges - fingers or hands can be pinched.

WARNING

When you leave the vehicle, always remove the ignition key and take it with you. This will prevent passengers (children, for example) from accidentally being locked in the vehicle should they accidentally press the power locking switch in the front doors.

Starting the engine

Convenience key:

You can switch on the ignition and start/stop the engine using the START ENGINE STOP button without having the key inserted in the ignition lock.

Switching the ignition on and off:

Insert the key into the ignition lock.

Manual transmission: Do **not** depress the clutch.

Press on the key.

Automatic transmission: Do **not** depress the brake pedal.

Press on the key.

The key can only be removed when the ignition is switched off.

Starting the engine:

Insert the key into the ignition lock.

Manual transmission: Depress the clutch and engage Neutral.


Automatic transmission: Depress the brake pedal and move the selector lever into P or N.

Briefly press on the key.

Stopping the engine when the vehicle is standing:

Automatic transmission: Move the selector lever into P or N.

Briefly press on the key.



Automatic transmission

Selector lever positions

- P** Park
- R** Reverse
- N** Neutral (Idle)
- D** Drive
- S** Sport

Releasing the selector lever lock and engaging a gear: Switch the ignition on, press the brake pedal and press the lock button on the selector lever.

Place the selector lever in the D or S position to drive forward.

tiptronic: To shift manually, move the selector lever to the right out of the D position. The driver information system displays the gears.



Shifting up/down:

Press the selector lever forward/back.

Adjusting the seats

1 Upper thigh support

2 Adjusting the lumbar support:

Press on the respective area of the switch.

3 Adjusting seat height and forward/back position:


-  Front of the seat cushion up/down
-  Back of the seat cushion up/down
-  Seat up/down
-  Seat forward/back

4 Adjusting the backrest/headrest:

-  Backrest forward/back
-  Head restraint up/down

5 Entry assistance:

Pull the lever up and tilt the backrest forward or back.



Adjusting the headrests

Adjust the head restraint so the upper edge is as even as possible with the top of your head.



⚠ WARNING

Thoroughly review your Owner's Manual for warnings and other important information about proper restraint use and what you can do to reduce the risk of injury in accidents. Failure to properly use restraint systems can cause serious personal injury.

⚠ WARNING

Never install rear facing child seats or infant carriers on the passenger seat. A child will be seriously injured or killed when the passenger airbag inflates.

⚠ WARNING

Always fasten safety belts before driving off. Always make sure passengers are properly restrained. Children 12 years old and younger must ride in the rear seat and be properly restrained as indicated in the Owner's Manual. The airbag is supplemental and does not replace safety belt use.

⚠ WARNING

Front seat passengers must never ride in a moving vehicle with the seatback reclined. The risk of personal injury increases with increasing rearward angle of the seatback. Safety belts only offer protection when the seatback is upright and belts are properly positioned on the body. Adjust your seats only when the vehicle is at a complete standstill.

⚠ WARNING

The airbag system cannot protect you properly if you are seated too close to any of the airbag locations. When adjusting their seat positions, it is important that both the driver and front passenger keep their upper bodies at a minimum safe distance of 10 inches (25 cm) between the chest and the steering wheel/instrument panel.

Climate control



Left switch – driver's side

Right switch – passenger's side

Rotary switch: Temperature selection

AUTO **Automatic mode:** Set the desired temperature and press the button.

Recirculation mode

Fan speed

Air distribution

Defrost the windshield/side windows

Rear window defroster

Heated seats


AC **Switch the air conditioning system on/off**

OFF **Switching on/off**

Panoramic tilting sunroof

Opening/closing

Press/pull the switch in the direction of the arrow. Press/pull the switch again when the desired position is reached.



WARNING

Be careful when closing the panoramic tilting sunroof. Check to see that no one is in the way, or serious personal injury could result.




Electromechanical parking brake

Stopping and engaging the parking brake: Pull the (P) button.

Releasing the parking brake: Press the brake pedal and press the (P) button.

Releasing automatically: The parking brake releases itself automatically when the safety belt is fastened and you begin driving.



Adaptive cruise control

The adaptive cruise control is a combined cruise control and distance regulation system.

Switching on/off: Pull/press the lever (3).

Storing the speed: Press the button (1).

Changing the stored speed:

Press the lever (3) up (faster) or down (slower).

Increasing/decreasing the distance:

Press the switch (2) to the right/left.

WARNING

Improper use of the adaptive cruise control can cause collisions, other accidents and serious personal injury. Always read and heed the Warnings in the Owner's Manual.

Fuel


The label on the inside of the fuel filler flap indicates the correct fuel type.



Fuel filler flap

Opening: Press the left side of the fuel filler flap.

Closing: Press the fuel filler flap in until it latches.



Engine oil

For the applicable oil specifications, refer to the Owner's Manual.



Tire pressures

The label with the correct tire pressures is located on the driver's door pillar or on the inside of the fuel filler flap.

Multi Media Interface/ Sound system

Components

1 Driver information system

2 Multifunction steering wheel

Roll the **left thumbwheel** to select a menu item in the driver information system. Press the thumbwheel to confirm the menu item.

Press the **MODE button** to switch between the active radio source, navigation system and telephone.

Press the **voice recognition button** briefly to activate the voice recognition system. After the <Beep>, you can say the desired commands.

To deactivate, press and hold the **voice recognition button** until you hear the message <Cancel>.

Roll the **right thumbwheel** to control the volume.

Press the right thumbwheel to repeat the last navigation announcement.





⚠ WARNING

Distraction causes accidents:

- Never enter data while driving!
- Obey traffic laws & road signs!
- Refer to the Owner's Manual!

3 Sound system/MMI display

4 On/Off button

Switching on/off: Press briefly/press and hold.

Adjusting the volume: Turn.

Mute: Press briefly

5 Function buttons

Call up main functions such as **MEDIA**.

6 Control knob

To select a menu item: Turn the knob.

To confirm your selection: Press the knob.

7 Control buttons


Activate the functions currently shown in the corners of the MMI display.

8 Joystick

To move the crosshairs in a map view (navigation) or to control the DVD menu.

Operating concept

All functions are controlled using the same operating concept.



A Calling up menus in the display corners: Press the appropriate button.

B Selecting: Turn the knob.

C Confirming: Press the knob.

Storing a radio station



1 Press the **RADIO** function button.




2 Turn the control knob and select the desired station.




3 Press the control knob to confirm.



4 Press the "Presets" control button.
5 Turn the control knob and select "Store <station name>".



6 Press the control knob. The next free memory preset is selected.



7 Turn the control knob and select the desired preset.
8 Press the control knob to confirm.



- 1 Press the **NAV** function button.



- 2 Turn the control knob and select "City/ZIP".
- 3 Press the control knob to confirm.



- 4 Turn the control knob to select the first letter of the destination.
- 5 Press the control knob to confirm.



- 6 Enter the remaining letters of the destination using the same procedure until the desired location name is displayed.




- 7 Press/hold the control knob longer when the city appears in the list.
- 8 Turn/press to select the city and enter detailed destination information if necessary.



- 9 Select the menu item "Start route guidance".
- 10 Press the control knob to confirm. The route is calculated.

Driver assistance systems



Use the **CAR** button to adjust or operate many driver assistance systems in your Audi.

For detailed information on this, please see your vehicle Owner's Manual.

Establishing a Bluetooth™ cell phone connection

You can quickly connect your Bluetooth-compatible cell phone with the MMI or sound system.

Connecting to the MMI:

- Switch the ignition, MMI and cell phone on.
- Activate “Bluetooth” on the cell phone.
- Press the **TEL** function button.
- Select the menu item “Search for new cell phones”.
- Press the **SETUP** function button.
- Press the “Bluetooth” control button.
- Highlight the menu item “Search for Bluetooth devices” and confirm.
- Select and confirm your cell phone in the display.
- Select “Handsfree” and confirm.
- Confirm the PIN number with “Yes”.
- Enter the PIN number on the cell phone.
- Also confirm the system prompt on the cell phone if necessary.

Connecting with the sound system:

- Switch the ignition, sound system and cell phone on.
- Select the menu in the cell phone that searches for Bluetooth-compatible devices (such as the cell phone prep or handsfree system).
- Connect the cell phone with the cell phone prep.
- Enter the PIN number on the cell phone.
- Also confirm the system prompt on the cell phone if necessary.


For additional information on indicator lights, refer to your vehicle Owner's Manual.

	Dynamic steering		Tire pressure low (check immediately)		Cruise control activated (CAN)		Brake malfunction (USA)		Ignition switch defective
	Electronic power control		Turn signals/ Emergency flasher		Anti-lock brake system (USA)		Brake malfunction (CAN)		Open road (adaptive cruise control)
	Electronic Stability Control (ESC)		Safety belt		Anti-lock brake system (CAN)		Cooling system malfunction		Driving in traffic (adaptive cruise control)
	Electronic Stability Control (ESC)		Malfunction Indicator Lamp		Parking brake (USA)		Engine oil pressure too low		Request for driver to assume control (adaptive cruise control)
	Safety systems (USA)		High beam		Parking brake (CAN)		Refill engine oil now		
	Safety systems (CAN)		Cruise control activated (USA)		Alternator malfunction		Steering defective		

© 2011 AUDI AG

Audi is constantly improving their products. Modifications in form, equipment and technology are possible. No legal commitment is implied by the information, illustrations, and descriptions in this Quick Reference Guide. Reprinting, reproduction or translation, in whole or in part, is not permitted without written permission from Audi of America, Inc. All rights are expressly reserved by Audi of America, Inc. Subject to modification without notice. Concept and design: Pfriemer GmbH. Printed in Germany.

Audi A5 • S5
Kurzanleitung
Nordamerika
Englisch 11.2011
122.562.8T0.21



1225628T021

www.audi.com